HIGH TECH FIRE PROTECTION

PO Box 156 • Minot, ME 04258-0156

Phone: (207)998-2551.Fax: (207)998-4187

NFPA Letter of Compliance

FIRE SPRINKLER SYSTEMS 24-HOUR SERVICE

Date: February 10, 2016

To: Johnathan Cohen

From: Richard Smith

Re: Sprinkler System Compliance Letter

High Tech Fire Protection has installed a new NFPA 13 sprinkler system for (416-420 Fore Street) located in Portland, ME. This system is in accordance with contract # 041615-3.

High Tech Fire Protection hereby guarantees the design, materials and workmanship to meet the requirements necessary for an approved NFPA #13 Automatic Fire Sprinkler System per State and local authority.

Sincerely, Richard Smith High Tech Fire Protection 207-998-2551 RSmith@htfp.me

Specializing in Commercial and Residential Fire Sprinkler Systems Design • Installation • Inspection • Service



State of Maine Department of Public Safety Fire Sprinkler System Permit



FSP11871

420 FORE STREET

Located at: In the Town of: Occupancy/Use: Type of System: 420 FORE ST PORTLAND Business NFPA 13

Permission is hereby given to:

HIGH TECH FIRE PROTECTION CO., INC. Contractor License # FSC102

to begin installation according to plans submittal approved by the Office of State Fire Marshal. No departure from the application submittal shall be made without prior approval in writing. This permit is issued under the provisions of Title 32, Chapter 20, Section 1337. Nothing herein shall excuse the holder of this permit from failure to comply with local ordinances, zoning laws, or other pertinent legal restrictions. This permit shall be displayed at the construction site or be made readily available.

Permit issued 7/28/2015

Permit expires at midnight on 01/27/2016

The expiration date applies only if the installation has not begun by that date and no permission has been granted to extend the date. Once installation begins, then the permit is valid as long as work is continuous.

John E Morus

John E. Morris Commissioner

The type of Fire Department Connection and its location is to be according to the Local Fire Department.

Within 30 days of the completion of a new fire sprinkler system or an addition to an existing fire sprinkler system, a sprinkler system contractor shall provide to the commissioner a copy of the permit signed by the certified responsible managing supervisor representing that the fire sprinkler system has been installed according to specifications of the approved plan.

Inspection 7-18-15-11-7-15, 11-28-15 Dates:

Job completed, tested and verified by date of Pd Mi

RMS for this job: Poulin Edward M.

A certificate shall be filled out and signed by both representatives. Copies shall be prepared for approving authorities, owners, our contractors. It is understood the owner's representative's signature in no way prejudices any claim against contractor for faulty material, poor workmanship, or failure to comply with approving authority's requirements or local ordinances. PROPERTY NAME 416 - 420 FORE STREET DATE 210/16 PROPERTY ADDRESS 416 - 420 FORE STREET DATE 210/16 PROPERTY ADDRESS 4164 State Fire Marshal's Office Marshal's Office PLANS ADDRESS #164 State House Station Augusta, Maine 04333-0164 Installation conforms to accepted plans Installation conforms to accepted plans Yes No Has person in charge of fire equipment been instructed as to location of control valves and care and maintenance of this new equipment? Image: Yes No	Upon completion of work, inspection and tests shall be made by the contractor's representative and witnessed by an owner's representative. All defects shall be corrected and system left in service before contractor's personnel finally laave the job. All defects shall be corrected and system left in service before contractor's personnel finally laave the job. Accertificate shall be finally laave the job. A certificate shall be filed out and signed by both representatives. Copies shall be prepared for approving authorities, owners, and contract for faulty material, poor workma failure to comply with approving authority's representatives. Device the owner's representative of approving authorities, owners, and contract for faulty material, poor workma failure to comply with approving authority's representatives. PROPERTY NAME 41.6 - 42.0 FORE STREET DATE DATE DATE PROPERTY ADDRESS 41.6.4 State House Station Augusta, Maine 04.3.3.30.1.6.4 PLANS Accepted by State Fire Marshall's Office PLANS Accepted plans State State State State State PLANS Accepted plans State State State State State State State PLANS Hos copies of the following been left on the premises? </th <th>Actors. Inship, or 14 No No No No No No No No No</th>	Actors. Inship, or 14 No No No No No No No No No
PROPERTY NAME 416 - 420 FORE STREET PATE D////w PROPERTY ADDRESS 416 - 420 FORE STREET ACCEPTED BY State Fire Marshall State Fire Fire Fire Fire Marshall Fire	PROPERTY NAME 416 - 420 FORE STREET DATE 210 PROPERTY ADDRESS 416 - 420 FORE STREET ACCEPTED BY State Fire Marshal's Office ADDRESS #164 State House Station Augusta, Maine 04333-0164 Marshal's Office Marshal's Office PLANS ADCEPTED BY State Fire Marshal's Office Marshal's office off	No No No No No No No No
PROPERTY ADDRESS 416 - 420 FORE STREET PLANS ADDRESS #164 State Fire Marshal's Office PLANS ADDRESS #164 State House Station Augusta, Maine 04333-0164 Fieldebio content be accepted plane Fieldebio content bear instructed on to leadion for control uses and cars and maintenance of this new apploment? Fieldebio content bear instructions	PROPERTY ADDRESS 416 - 420 FORE STREET ACCEPTED BY State Fire Marshal's Office PLANS ACCEPTED BY State Fire Marshal's Office Installation conforms to accepted plans Equipment used is approved If no, explain deviations. Image: Control values and care and maintenance of this new equipment? Has person in charge of fire equipment been instructed as to location of control values and care and maintenance of this new equipment? Image: Ves INSTRUCTIONS Has copies of the following been left on the premises? Image: Ves 2. Care and maintenance instructions Image: Ves Image: Ves 3. NFPA 25 (Owners Manual) Image: Ves Image: Ves LOCATION OF SYSTEM Supplies buildings Image: Ves Image: Ves MAKE MODEL Ves Image: Ves Image: Ves SPRINKLERS GLOBE GL5601 2015 1/2" 107 155" GLOBE GL5615 2015 1/2" 1 200" 200" SPRINKLERS GLOBE GL5635 2015 1/2" 1 200"	No No No No No No No No
ACCEPTED BY State Fire Marshal's Office PLNS #164 State House Station Augusta, Maine 04333-0164 Intersections By Yes By No Has parent in durgs of the quereant were inducted on to include By Yes By No Has parent in durgs of the quereant were inducted on to include By Yes By No Has parent in durgs of the quereant were inducted on to include By Yes By No 1: System concents flatuations By Yes By No 1: System concents flatuations By Yes By No 1: System concents flatuations By Yes By Yes 1: System concents flatuations By Yes By Yes 1: System concents flatuations By Yes By No CLOCHEN GLOBE GLOBE GLOBE BLSEO1 2015 1/2* 107 155* GLOBE GLOBE GLOBE GLOBE 2015 1/2* 1 200* GLOBE GLOBE GLOBE GLOBE 1/2* 3 155* GLOBE GLOBE GLOBE GLOBE 1/2* 3 155* GLOBE GLOBE GL	ACCEPTED BY State Fire Marshal's Office ACCEPTED BY State Fire Marshal's Office ADDRESS #164 State House Station Augusta, Maine 04333-0164 Installation conforms to accepted plans Equipment used is approved If no, explain deviations. Image: State Fire Marshal's Office Has person in charge of fire equipment been instructed as to location of control valves and care and maintenance of this new equipment? Image: State Fire Marshal's Office INSTRUCTIONS Has copies of the following been left on the premises? Image: State Fire Marutions Image: State Fire Marutions INSTRUCTIONS Has copies of the following been left on the premises? Image: State Fire Marutions Image: State Fire Marutions Image: State Fire Marutions LOCATION OF SYSTEM Supplies buildings Entrice Building Entrice Marutions Image: State Fire Marutions Image: State Fire Marutions SPRINKLERS GLOBE GL5601 2015 1/2" 107 155" GLOBE GL5635 2015 1/2" 17 155" GLOBE GL5635 2015 1/2" 1 200"	No No No No No No No No
PLNS ADDRESS #164 State House Station Augusta, Maine 04333-0164 Institution Institution <td>PLANS ADDRESS # 164 State House Station Augusta, Maine 04333-0164 Installation conforms to accepted plans Equipment used is approved if no, explain deviations. Image: Station Augusta, Maine 04333-0164 Installation conforms to accepted plans Equipment used is approved if no, explain deviations. Image: Station Augusta, Maine 04333-0164 INSTRUCTIONS Has person in charge of fire equipment been instructed as to location of control valves and care and maintenance of this new equipment? Image: Station Augusta, Image: Station Aug</td> <td>No No No No No No No No</td>	PLANS ADDRESS # 164 State House Station Augusta, Maine 04333-0164 Installation conforms to accepted plans Equipment used is approved if no, explain deviations. Image: Station Augusta, Maine 04333-0164 Installation conforms to accepted plans Equipment used is approved if no, explain deviations. Image: Station Augusta, Maine 04333-0164 INSTRUCTIONS Has person in charge of fire equipment been instructed as to location of control valves and care and maintenance of this new equipment? Image: Station Augusta, Image: Station Aug	No No No No No No No No
Installation conforme to accepted pione and control where approved if no. explain devictions. Effective Provession of the provession of the provider of the presevide of the provider of the provider of the provider	Installation conforms to accepted plans Equipment used is approved if no, explain deviations. X Yes X Has person in charge of fire equipment been instructed as to location of control valves and care and maintenance of this new equipment? If no, explain? X Yes X INSTRUCTIONS Has copies of the following been left on the premises? 2. Care and maintenance instructions 3. NFPA 25 (Owners Manual) X Yes X Yes X LOCATION OF SYSTEM Supplies buildings For Fire Buildingy X Yes X MAKE MODEL YEAR OF MANUFACTURE ORIFICE SIZE QUANTITY TEMPERATURE 107 SPRINKLERS GLOBE GL5601 2015 1/2" 107 155" GLOBE GL5615 2015 1/2" 17 155" GLOBE GL5635 2015 1/2" 1 200"	No No No No No No No No
of conclusions and card and monitonence of this new equipment? His copies of the following bases left on the premises? 2. Core constructions 2. Core constructions 2. Core constructions instructions 2. Core constructions 3. NFRA 25 (owners Marule) UDCAMEN or SPRIMULERS GLOBE GLOBE	of control values and care and maintenance of this new equipment? If no, explain? Mass copies of the following been left on the premises? 1. System components instructions 2. Care and maintenance instructions 3. NFPA 25 (Owners Manual) Image: System components instructions 3. NFPA 25 (Owners Manual) LOCATION OF SYSTEM Supplies buildings Image: Care and maintenance instructions 3. NFPA 25 (Owners Manual) Image: Care and maintenance instructions 3. NFPA 25 (Owners Manual) Image: Care and maintenance instructions 3. NFPA 25 (Owners Manual) LOCATION OF SYSTEM Supplies buildings Image: Care and maintenance instructions 3. NFPA 25 (Owners Manual) Image: Care and maintenance instructions 3. NFPA 25 (Owners Manual) LOCATION OF SYSTEM Supplies buildings Image: Care and maintenance instructions 3. NFPA 25 (Owners Manual) Image: Care and maintenance instructions 3. NFPA 25 (Owners Manual) Supplies buildings Image: Care and maintenance instructions GLOBE GL5601 2015 1/2" 107 155" SPRINKLERS GLOBE GL5615 2015 1/2" 1 200" SPRINKLERS GLOBE GL5635 2015 1/2" 1 200"	No No No No No
INDERCOLLING The parame component is instruction. Description 2. Core and mainterance instructions. 2. Core and mainteran	MSTRUCTIONS His copies of the following been ref. to be permission Image: System components instructions 1. System components instructions 2. Care and maintenance instructions Image: System components instructions 2. Care and maintenance instructions 3. NFPA 25 (Owners Manual) Image: System components instructions LOCATION OF SYSTEM Supplies buildings Image: Supplies buildings Image: System components instructions MAKE MODEL YEAR OF MANUFACTURE ORIFICE SIZE QUANTITY GLOBE GL5601 2015 1/2" 107 155" GLOBE GL5615 2015 1/2" 17 155" GLOBE GL5635 2015 1/2" 1 200"	I No No No
SYSTEM Opplete submining Prive During Constrained of the system Opplete submining Opplete submining </td <td>SYSTEM Supplies buildings MAKE MODEL YEAR OF MANUFACTURE ORIFICE SIZE QUANTITY TEMPERATUR GLOBE GL5601 2015 1/2" 107 155" GLOBE GL5601 2015 1/2" 3 200" SPRINKLERS GLOBE GL5615 2015 1/2" 17 155" GLOBE GL5635 2015 1/2" 1 200"</td> <td>RE RATINO</td>	SYSTEM Supplies buildings MAKE MODEL YEAR OF MANUFACTURE ORIFICE SIZE QUANTITY TEMPERATUR GLOBE GL5601 2015 1/2" 107 155" GLOBE GL5601 2015 1/2" 3 200" SPRINKLERS GLOBE GL5615 2015 1/2" 17 155" GLOBE GL5635 2015 1/2" 1 200"	RE RATINO
MAXE MODE Point weak weak Point 155* GLOBE GLS501 2015 1/2" 3 200° SPRINCLERS GLOBE GLS615 2015 1/2" 1 200° GLOBE GLS615 2015 1/2" 1 200° 1 200° GLOBE GLS626 2015 1/2" 3 155' 1 200° 1 200° 1 200° 1 200° 1 200° 1 200° 1 200° 1 200° 1 200° 1 200° 1 200° 1 200° 1 200° 1 200° 1 200° 1 200° 1 200° 1 200° 1 200° 1	SPRINKLERS GLOBE GL5601 2015 1/2" 107 155" GLOBE GL5601 2015 1/2" 3 200" GLOBE GL5601 2015 1/2" 17 155" GLOBE GL5615 2015 1/2" 17 155" GLOBE GL5635 2015 1/2" 1 200"	RE RATINO
SPRINKLERS CLOBE GL5601 2015 1/2" 3 200' SPRINKLERS GLOBE GL5635 2015 1/2" 17 155' GLOBE GL5635 2015 1/2" 34 155' GLOBE GL5632 2015 1/2" 3 155' Filmos & Type of pipe SCHEDULE 10 / 40 STEEL Seconds Seconds Seconds Type of pipe Make Model Maumum time to operate through test connection. Seconds ALARM VALC Value Value System Sender GLOB. Seconds FLOW INDICT. Type of pipe Make Model Maumum time to operate through test connection. Make Model Seconds Pai Pai Model Seconds OPT valve </td <td>SPRINKLERS GLOBE GL5601 2015 1/2" 3 200° GLOBE GL5615 2015 1/2" 17 155° GLOBE GL5635 2015 1/2" 1 200°</td> <td></td>	SPRINKLERS GLOBE GL5601 2015 1/2" 3 200° GLOBE GL5615 2015 1/2" 17 155° GLOBE GL5635 2015 1/2" 1 200°	
SPRINKLEPS GLOBE GLS615 2015 1/2* 17 155* GLOBE GLS626 2015 1/2* 1 200* GLOBE GLS626 2015 1/2* 34 155* GLOBE GLS626 2015 1/2* 3 155* GLOBE GLS632 2015 1/2* 3 155* GLOBE GLS641 2015 1/2* 3 155* GLOBE GLS641 2015 1/2* 3 155* TIMOS SCHEDULE 10 / 40 STEEL Vige of filing Seconds Seconds TIMOS Type of pipe SCHEDULE 10/ VIFLSU Seconds Seconds Vigue Airm Device Model Maximum time to operate through test connection. Seconds Seconds Seconds Vigue Make Model Serial no. Make Model Serial no. Make Model Serial no. Make Model Serial no. Serial no.	SPRINKLERS GLOBE GL5615 2015 1/2" 17 155" GLOBE GL5635 2015 1/2" 1 200"	
BRC DEC CLOBE GLOBE <	GLOBE GL5635 2015 1/2" 1 200" GLOBE GL5635 2015 1/2" 1 200"	
Decode Close Close <t< td=""><td></td><td></td></t<>		
BIOR GLOBE <		
Decode GLOBE		
Dry Dry Otopic Dry PIPING & FITTINGS Type of pipe SCHEDULE 10 / 40 STEEL Type of fittings CAST / MALLEABLE IRON Maximum time to operate through test connection. ALARW FLOW INDICT. Type Make Model Minutes Seconds Vane Jyse of pipe SCHEDULE 10 / 40 STEEL Type Make Model Minutes Seconds Vane Jyse of pipe SCHEDULE 10 / 40 Steel Model Minutes Seconds Vane Jyse of fittings CAST / MALLEABLE IRON Make Model Minutes Vane Jyse of pipe SCHEDULE 10 / 40 Steel Make Model Minutes Vane Jyse of pipe SCHEDULE 10 / 40 Steel Minutes Seconds Seconds Vane Jyse of pipe SCHEDULE 10 / 40 Steel Seconds Seconds Seconds Vane Jyse of pipe SCHEDULE 10 / 40 Steel Seconds Seconds Seconds DRY PIPE OFFER Time to trip through test connection1 Water pressure Air Trip point reached connection1 Time water pressure Air TEST Minutes Seconds Pai Pai Pai Minutes Seconds Veloci Seconds Pai Pai Pai Minutes Seconds No <tr< td=""><td></td><td></td></tr<>		
Type of fittings CAST / MALLEABLE IRON Maximum time to operate through test connection. Maximum time to operate through test connection. Make Model Maximum time to operate through test connection. OR Type Make Model Minutes Seconds ORY PIPE Time to trip Water Air Trip point Time water Alarm OPERATION OPERATION Minutes Seconds Marke Make Model Secial no. Make Model Secial no. OPERATION Time to trip Mater Alarm Time to trip Weter Pressure Care OPERATION Minutes Seconds Yes No Plai Plai Plai Plai <th< td=""><td></td><td></td></th<>		
ALARM VALVE FLOW INDICT. Value Alarm Device Maximum time to operate through test connection. Type Make Model Minutes Seconds Value System Sensor WHM 2010 General General General DRY PIPE OPERATION TEST Make Model Serial no. Make Model Serial no. Minutes Seconds Psi Pressure Air pressure Time water reached dir pressure Alarm operated pressure Alarm operated pressure Alarm operated pressure Alarm dir pressure Alarm mother Alarm operated pressure	TITING OF THE AND THE POINT	
FLOW INDICT. Type Make Model Model Model Model Model Seconds UQUE VQUE Opy valve 0.0.D. <	Huminum time to exercise through test con	nection.
Vane System Sensor WFN 257/m C.O.D. Dry valve Dry valve O.O.D. Model Serial no. Make Model Serial no. Make Model Serial no. DRY PIPE Time to trip through test connection1 Water pressure Air pressure Trip point dif pressure Time water recohed Alorm operated Without Seconds Psi Psi Psi Minutes Seconds Yes No Without Operation Immediation of the manual trip, remote, or both control stations? Yes No PELUGE & VALVESY Piping supervised Dese each circuit operate supervision loss alarm? Dese each circuit operate valve release? Mainutes Seconds Yes No Is there an accessible facility in each circuit for testing? Yes No If no, explain. Immediate of operate release valve release? Mainutes Seconds Seconds VALVESY Location and floor Make & Model Setting Static Pressure (flowing) If no, explain. Immediate operate release valve releases? No Minutes		
DRY PIPE Make Model Serial no. Make Model Serial no. Make Model Serial no. Make Serial no. Make Serial no. Make Model Serial no. Make Model Serial no. Make Serial no. Make Model Serial no. Make Model Serial no. Mare Serial no. Serial no. <t< td=""><td>Vane System Sensor WFID 25 N SS</td><td></td></t<>	Vane System Sensor WFID 25 N SS	
DEV Make Model Sand Make Make <th< td=""><td>Dry valve Q.O.D.</td><td></td></th<>	Dry valve Q.O.D.	
Drep HPE- OPERATION TEST Time to trip through test connection1 Ime to trip pressure Water pressure Air pressure Trip point cir pressure Trip point cir pressure reached test outlet1 operated properly Minutes Seconds Psi Psi Psi Psi Psi Psi No Without 0.0.0. 0.0.0. 0.0.0. 0.0.0. 0.0.0. Image to trip through test 0.0.0. Psi Psi Psi Psi Minutes Seconds Yes No Without 0.0.0. If no, explain Image to trip through test Pneumatic Electric Hydraulic Image to trip through test No No PELUGE & PREACTION VALVES Operate from the manual trip, remote, or both control stations? Image to trip through test No If no, explain. Image to trip through test No Dest valve operate from the manual trip, remote, or both control stations? Image to trip through test No Image to trip through test No Maximum time of operate release Make Model Model Test operate supervision loss alarm? No Vest No Image test operate (flowing) Flow rate Pressure Location and floor Make & Model Setting Static Pressure Residual Pressure (flowing) Flow rate <td>Make Model Serial no. Make Model Serial</td> <td>no.</td>	Make Model Serial no. Make Model Serial	no.
OPERATION TEST Imme to trip trough test connection1 Water pressure Air pressure Imp point dir pressure reached test outlet1 operated properly Minutes Seconds Psi Psi Psi Psi Psi Minutes Seconds Yes No Without (0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0, 0		Alarm
Minutes Seconds Psi Psi <th< td=""><td>DRY PIPE Time to trip Water Air Trip point reached connection1 OPERATION through test pressure pressure air pressure test outlet1 p</td><td>perated properly</td></th<>	DRY PIPE Time to trip Water Air Trip point reached connection1 OPERATION through test pressure pressure air pressure test outlet1 p	perated properly
Operation Operation Presence Presence If no, explain Image: Constraint of the state of the s	Minutes Seconds PSI PSI PSI I I I I I I I I I I I I I I	
Q.O.D. If no, explain DeluGE & PREACTION VALVES Operation Image: Presence of the manual trip, remote, or both control stations? Image: Presence of the manual trip, remote, or both control stations? DeluGE & PREACTION VALVES Does valve operate from the manual trip, remote, or both control stations? Image: Presence of the manual trip, remote, or both control stations? Image: Presence of the manual trip, remote, or both control stations? Make Model Does each circuit operate supervision loss alarm? No If no, explain. Make Model Does each circuit operate supervision loss alarm? No Minutes Seconds Vers No Yes No Yes No Minutes Seconds PressURE Location and floor Make & Model Setting Static Pressure Residual Pressure (flowing) Flow (gpm) PRESSURE REDUCING Image: Pressure Image: Pressure Flow (gpm)	Q.O.D.	
Operation Image: Pneumatic Pneumatic Image: Pneumatic <	Q.O.D.	
DELUGE & PREACTION VALVES Piping supervised Image: supervised		
DELUGE & Preaction VALVES Does valve operate from the manual trip, remote, or both control stations? Image: Control station of the control static s		🗆 No
PREACTION VALVES Does valve operate from the manual trip, render, or both conditionation. Index operate from the manual trip, render, or both conditionation. No If no, explain. Is there an accessible facility in each circuit for testing? If no, explain. Does each circuit operate supervision loss alarm? Does each circuit operate valve release? Maximum time of operate release Make Model Yes No Yes No Minutes Seconds Location and floor Make & Setting Setting Static Pressure Residual Pressure (flowing) Flow rate PRESSURE REDUCING Inlet (psi) outlet (psi) Inlet (psi) outlet (psi) Flow (gpm)	Piping supervised	
Is there on occessible robinity in each circuit rol coding? Does each circuit operate supervision loss alarm? Does each circuit operate valve release? Maximum time of operate release Make Model Does each circuit operate supervision loss alarm? Does each circuit operate valve release? Maximum time of operate release Yes No Yes No Minutes Seconds Location and floor Make & Model Setting Static Pressure (flowing) Residual Pressure (flowing) Flow rate PRESSURE REDUCING Inlet (psi) outlet (psi) Inlet (psi) outlet (psi) Flow (gpm)	PREACTION Does valve operate from the manual trip, femote, or both control actions.	
Make Model Yes No Yes No Minutes Seconds Image: Second	Does each circuit operate Does each circuit operate Maximum time of operate	te release
Location and floor Make & Model Setting Static Pressure Itelation (flowing) PRESSURE REDUCING Inlet (psi) outlet (psi) Inlet (psi) outlet (psi)	Make Model Minutes Sea	conds
Location and floor Make & Model Setting Static Pressure Itelation (flowing) PRESSURE REDUCING Inlet (psi) outlet (psi) Inlet (psi) outlet (psi)		
REDUCING		.e
	Location Make & Setting Stutic Pressure (forward)	