



- ☒ NO EXCEPTIONS TAKEN
- ☐ MAKE CORRECTIONS NOTED
- ☐ AMEND & RE-SUBMIT

- ☐ SUBMIT SPECIFIED ITEM
- ☐ REJECTED-SEE REMARKS
- ☐ SEE COMMENTS BELOW

CHECKING IS ONLY FOR GENERAL CONFORMANCE WITH THE DESIGN CONCEPT OF THE PROJECT AND GENERAL COMPLIANCE WITH THE INFORMATION GIVEN IN THE CONTRACT DOCUMENTS. ANY ACTION SHOWN IS SUBJECT TO THE REQUIREMENTS OF THE DRAWINGS AND SPECIFICATIONS. CONTRACTOR IS RESPONSIBLE FOR DIMENSIONS WHICH SHALL BE CONFIRMED AND CORRELATED AT THE JOB SITE, FABRICATION PROCESSES AND TECHNIQUES OF CONSTRUCTION, COORDINATION OF THE WORK WITH THAT OF OTHER TRADES AND THE SATISFACTORY PERFORMANCE OF THE WORK.

Stephen P. Doel
SIGNATURE

7/31/13
REVIEW DATE

Project: Marriott Hotel - Portland, Maine

Submittal: Patterson Kelley C-1050 Boiler

Comments: NONE

Project Name: Marriott Courtyard
 321 commercial Street
 Portland, Maine 04101

Architect:

Contractor: Opechee Construction Corporation
 11 Corporate Drive
 Belmont, NH 03220

Subcontractor: Warren Mechanical, Inc.
 P.O. Box 149
 Westbrook, Maine 04098-0149




Supplier: Power & Process, Inc.
 P.O. Box 7056
 Prospect, Ct. 06712

Manufacturer: Patterson-Kelley

Section: 230000/2.7 Boilers

Contractor Review

Architect's Review



Model #: _____ Serial # _____

Start-Up Date: _____

© 2010 Harsco Industrial, Patterson-Kelley
Printed: 7/1/2013

[illegible]

1	INTRODUCTION	4
2	SAFETY	4
2.1	General.....	4
2.2	Training	4
2.3	Safety Features	5
2.4	Safety Labels	5
2.5	Safety Precautions	6
3	INSTALLATION	8
3.1	Receiving and Storage	8
3.2	Compliance with Codes	8
3.3	Setup	9
3.4	Electrical Connections.....	10
3.5	Inlet Air and Exhaust Venting.....	12
3.6	Gas Piping.....	24
3.7	Boiler Water Piping	26
3.8	Pre-Start Check List.....	29
3.9	Safety Checks	30
3.10	Initial Adjustments	31
3.11	Burner Adjustment	34
4	OPERATION	36
4.1	General.....	36
4.2	Normal Lighting and Shut-Down Procedures.....	36
4.3	Typical Boiler Utility Requirements	37
5	MAINTENANCE	37
5.1	Maintenance and Inspection Schedule	37
5.2	Cleaning the Burner	39
5.3	After All Repairs or Maintenance	39
5.4	Sequence of Operation	40
5.5	Troubleshooting	41
6	PARTS/TECHNICAL SUPPORT	44
6.1	Wiring Diagrams.....	46
6.2	Boiler Parts List	49
7	LIMITED WARRANTY.....	53
8	MACH® BOILER FIRE TEST REPORT	54
	APPENDIX 1 – MAINTENANCE LOG.....	55
	APPENDIX 2 – MACH® BOILER ALTITUDE DERATE SCHEDULE.....	56



⚠ WARNING

If the information in this manual is not followed exactly, a fire or explosion may result causing property damage, personal injury or loss of life.

Do not store or use gasoline or other flammable vapors or liquids in the vicinity of this or any other appliance.

Installation and service must be performed by a qualified installer, service agency, or the gas supplier.

⚠ WARNING

It is essential to read, understand, and follow the recommendations of this manual before installing, operating, or servicing this equipment.

⚠ WARNING

Installation and service must be performed by a qualified and knowledgeable individual who has been trained on the MACH® boiler. The same features which permit this boiler to achieve high-efficiency performance make it unlike most other boilers of this general size, so it is important to understand how this boiler operates.

What to do if you smell gas:

- Do not try to light any appliance.
- Do not touch any electrical switch; do not use any phone in your building.
- Immediately call your gas supplier from a neighbor's phone. Follow the gas supplier's instructions.
- If you cannot reach your gas supplier, call the fire department.

1 INTRODUCTION

The MACH® gas-fired boiler is fully modulating using a variable speed combustion blower, sophisticated microprocessor controls, modulating gas safety shut off / control valves and a unique aluminum alloy heat exchanger capable of operating in a fully condensing mode to provide maximum efficiency in a minimum amount of space. The high-quality materials and thoroughly tested design of the boiler should provide years of trouble-free service if the instructions in this manual are followed carefully.

This manual covers installation of MACH® boilers. The model numbers may be followed by a prefix or suffix letter in some cases to indicate special features or different options.

While details may differ slightly, basic operation is the same for all models. Boilers may be built to operate with natural gas or liquefied petroleum gas (propane). Check the rating plate for correct fuel usage and gas pressures.

The boiler is only a part of the complete heating system. This boiler may be fully operational and yet because of poor circulation, improper control or other site related characteristics, not deliver heat to the desired location. Additional equipment such as temperature sensors, pumps, flow switches, balancing valves, and check valves will be required for satisfactory operation of any system. Harsco Industrial, Patterson-Kelley cannot be responsible for the design or operation of such systems and a qualified engineer or contractor must be consulted.

2 SAFETY

2.1 GENERAL

The MACH® gas-fired boiler **must** be:

- Installed, operated, and serviced in accordance with instructions contained in this manual and other supplemental MACH® boiler manuals.
- Installed by qualified personnel in accordance with designs prepared by qualified engineers including: structural, mechanical, electrical, and other applicable disciplines.
- Operated and serviced in accordance with a comprehensive safety program determined and established **by the customer**. Do not attempt to operate or service until such a program has been established.
- Operated and serviced by experienced, qualified, properly trained personnel in accordance with all applicable codes, laws, and regulations.

NOTICE! Each safety device must be maintained and checked per the recommended schedule. Refer to Section 5.1 of this manual.

2.2 TRAINING

Proper training is the best protection against accidents.



It is essential to read, understand, and follow the recommendations of this manual before installing, operating, or servicing this equipment. Failure to do so could result in fire or explosion and serious injury, death, and/or property damage.

Operating and service personnel must be thoroughly familiar with the basic construction of the MACH® boiler, the use and locations of the controls, the operation of the boiler, adjustment of its various mechanisms, and all applicable safety precautions. If any of the provisions of this manual are not fully and completely understood, contact the Harsco Industrial, Patterson-Kelley Technical Service toll free at (877) 728-5351.

2.3 SAFETY FEATURES

It is the responsibility of the customer to maintain the safety feature, such as but not limited to: guards, safety labels, safety controls, interlocks and lockout devices.

2.4 SAFETY LABELS

The following words are used in this manual to denote the degree of seriousness of the individual hazards.



DANGER indicates an imminently hazardous situation which, if not avoided, **will** result in death or serious injury. This signal word is to be limited to the most extreme situations.



WARNING indicates a potentially hazardous situation which, if not avoided, **could** result in death or serious injury.



CAUTION indicates a potentially hazardous situation which, if not avoided, **may** result in minor or moderate injury. It may also be used to alert against unsafe practices.

NOTICE/NOTE - NOTICE is the preferred signal word to address practices not related to personal injury. The safety alert symbol is not used with this signal word.



© 1998 HCS, Inc. 800-748-0241


Reorder No. 6020-V2WHPK

The safety labels shown above are affixed to your boiler. Although the labels are of high quality, they may become dislodged or unreadable over time. Contact Harsco Industrial, Patterson-Kelley toll-free at (877) 728-5351 for replacement labels.

2.5 SAFETY PRECAUTIONS

Provide a suitable location for the boiler away from normal personnel traffic. Ensure that you have adequate working space, adequate clearances, proper ventilation and lighting, a structure sufficiently strong and rigid to support the weight of the boiler, all piping and accessories.

2.5.1 Electrical Hazards



- Shock hazard! Properly lockout/tag out the electrical service and all other energy sources before working on or near the boiler.
- Shock hazard! Do not spray water directly on this boiler or on any electrical components.
- Electrical hazard! Do not alter wiring connections.

2.5.2 Burn, Fire and Explosion Hazards



General Warning



©1998 HCS, Inc. 800-748-0241

Recorder No. 6020-V2WHPK



Hot Surface

- Burn, fire and explosion hazards! Installation must be in strict conformance to all applicable codes and standards including NFPA 54, ANSI Z223.1 and CAN/CSA B.149.1. Install all required vent lines for gas devices. Refer to Section 3.7.1.
- Hazard from incorrect fuels! Possible fire, explosion, overheating, and damage. Do not use any fuels except the design fuels for the unit.
- Over fire hazards! High pressure in gas or propane supply could result in over firing of this appliance or other devices supplied from the same source.
- Fire and explosion hazards! Close the main gas shutoff before servicing boiler.
- Fire and explosion hazards! Do not store or use gasoline or other flammable vapors or liquids in the vicinity of this or any other gas fired appliance.
- Burn hazard! Possible hot surfaces. Do not touch gas vent during firing operation. Use only factory recommended vent components.
- Burn hazard! Pipes, vents, and boiler components could be hot. Do not touch piping or stack surfaces during operation or immediately after shutdown of the boiler.
- Burn hazard! Hot fluids. Use caution when servicing or draining the boiler.
- Fire and explosion hazards! Use caution when servicing burner. Propane (LPG) is heavier than air and may linger in the combustion chamber, vent lines, or elsewhere.
- Gas leak hazard! Make sure the burner is installed correctly and burner hood is securely fastened following any maintenance performed on them. These connections cannot be tested after the burner is assembled.
- Gas leak hazard! All threaded gas connections must be made using a pipe compound that is resistant to liquefied petroleum. **Do not** use Teflon™ tape on threaded gas piping.
- Gas leak hazard! Check entire gas train for leaks after installation. If there is a smell of gas, shut down the boiler and obtain immediate assistance from trained service personnel and/or your local fire department.
- Excess pressure hazard! Possible fire and explosion from excess gas pressure. Make sure that gas inlet pressure does not exceed 14 inches W.C. to the regulator.
- Fire and explosion hazard! Failure to maintain all gas train components may result in malfunction of regulators and/or gas safety shut off / control valves. Annual inspection by factory-trained personnel for proper set-up and operation is recommended.
- Over fire and under fire hazards! Possible fire, explosion, overheating, and component failure. Do not attempt to adjust firing rate of the boiler. The firing rate must be adjusted **only** by factory trained personnel.

⚠ WARNING

Gas may lose its odor. Proper gas sensing equipment and procedures should be used for leak checks.

2.5.3 Crush Hazards



- Lifting hazards! Use properly rated lifting equipment to lift and position the boiler. The load is unbalanced. Test balance before lifting 3 ft. above the floor. Do not allow personnel beneath the lifted load. Refer to approximate weights in the table.
- Bump hazard from overhead ductwork and piping. Install components with adequate vertical clearance.

Boiler Size	Weight in Pounds
750,000 Btu	650
900,000 Btu	700
1,050,000 Btu	750

2.5.4 Chemical Hazards



- Chemical hazards from cleaning products. Use caution when cleaning the system. The use of professional assistance is recommended. Use safe procedures for the disposal of all cleaning solutions.
- Combustion Condensate – an acidic pH of approximately 3.0 to 5.0 can be expected. Use PVC, CPVC, or other corrosion resistant piping for drainage. Collection and disposal must be in accordance with all applicable regulations. A condensate neutralization kit is available. Please contact your local Harsco Industrial, Patterson-Kelley representative.

2.5.5 Pressure Hazards



- Pressure hazard! Hot fluids. Install isolation valves on boiler water inlet and outlet. Make sure isolation valves are closed before servicing boiler.
- Pressure hazard! Hot fluids. Annually test safety relief valve for proper operation. Do not operate boiler with faulty relief valve.

2.5.6 Slip, Fall Hazards



- Tripping hazard! Do not install piping on floor surfaces. Maintain clear path around boiler.
- Slip and fall hazard! Use drip pan to catch water while draining the boiler. Maintain dry floor surfaces.
- Slip and fall hazard! **Do not** locate intake or exhaust terminations directly above a walkway; dripping of condensation can cause icing of the walking surface. (see section 3.6.3)

3 INSTALLATION

3.1 RECEIVING AND STORAGE

3.1.1 Initial Inspection

Upon receiving the boiler, inspect it for signs of shipping damage. Since some damage may be hidden, we recommend unpacking the boiler, removing the top, front, and sides covers and inspect the boiler. Verify that the total number of pieces shown on the packing slip agrees with those actually received.

NOTICE! Note any damage, suspected potential damage, or shortage of materials on the freight bill and immediately notify the carrier. File all claims for shortage or damage with the carrier. Claims for hidden damages must be filed with your carrier within 7 days. The boiler carton is equipped with a "Tip (N) Tell". If "Tip (N) Tell" arrow point is blue, that indicates that the package has been on its side or tipped over in transit.

3.1.2 Storage Prior to Installation

If the boiler is not installed immediately, it must be stored in a location adequately protected from the weather and freezing conditions, preferably indoors. If this is not possible, then it should remain in the shipping container and be covered by a tarpaulin or other waterproof covering.

NOTICE! Controls and other equipment that are damaged or fail due to weather exposure are not covered by warranty.

3.2 COMPLIANCE WITH CODES

The MACH® boiler with standard components and with many options complies with American National Standard/CSA Standard ANSI Z21.13/CSA 4.9, latest edition, Gas-Fired Low Pressure Steam and Hot Water Boilers.

The heat exchanger is constructed and stamped in accordance with ASME Boiler and Pressure Vessel Code, Section IV for 80 psig maximum operating pressure and/or 200° F maximum temperature.

Installation of the boiler must conform to all the requirements of all national, state and local codes established by the authorities having jurisdiction or, in the absence of such requirements, to the National Fuel Gas Code, ANSI Z223.1/NFPA 54, latest edition in the U.S. In Canada, the equipment shall be installed in accordance with the current Installation Code for Gas Burning Appliances and Equipment, CAN/CSA-B.149, latest edition, and applicable Provincial Regulations for the class, which should be carefully followed in all cases. Authorities having jurisdiction should be consulted before installations are made.

Where required by local codes, the installation must conform to American Society of Mechanical Engineers Safety Code for Controls and Safety Devices for Automatically Fired Boilers (ASME CSD-1).

In the Commonwealth of Massachusetts (a) this unit must be installed by a licensed pipe fitter / plumber, (b) field installed gas cocks must be "T" handle type, (c) piping of condensate shall conform to the State Plumbing Code, and (d) refer to the Massachusetts supplement for further details.

3.3 SETUP


3.3.1 Foundation

Provide a firm, level foundation, preferably of concrete.

NOTICE! The boiler may be installed on a combustible floor, however the boiler must **never** be installed on carpeting.

3.3.2 Placement



The boiler must be level to function properly. To assist in leveling the boiler, the four (4) adjustable leg bolts (1/2"- 13 NC) must be installed. The adjustable legs are also necessary to provide adequate floor clearance and prevent distortion of the cabinet, (twisting, etc.) in addition to leveling.



Adjustable Legs for Leveling and Floor Clearance

3.3.3 Clearances

If the boiler is to be installed near combustible surfaces, six (6") inches minimum clearance to the combustible surface must be maintained. Failure to provide for the service access clearances, even with non-combustible surfaces, may cause future problems servicing the boiler. The boiler must be installed in a space large in comparison to the boiler as described in the National Fuel Gas Code, NFPA 54/ANSI Z223.1, Latest Edition.



Clearances from Adjacent Walls, Ceiling, and Obstructions
Side Clearances for a Row of Boilers

Type of Surface	Dimensions (inches)			
	A	B	C†	D
CSA Minimum Clearances to Combustibles	24	24*	24	24
Recommended Service Clearances	30	24*	24	24**

† "C" dimension includes clearance to remove the burner. Do not put pipes, ducts, etc. in this area above the boiler.

*CSA minimum. Actual clearance depends upon venting requirements.

** Service access need be only on one side of a boiler or row of boilers. Boilers may be installed immediately adjacent to each other. However, Harsco Industrial, Patterson-Kelley recommends this clearance between **each boiler** when there is insufficient access at the rear to allow for service and adjustment.

⚠ CAUTION

Bumping hazard from overhead ducts! Install all components with adequate vertical clearances.

3.4 ELECTRICAL CONNECTIONS

The boiler is wired for 120 volts, single phase, 60 hertz. The total operating amperage is indicated on the rating nameplate. MACH® boiler units C750/C900/C1050 require less than 8 amps. Before starting the boiler, check to ensure that the proper electrical service is connected to the boiler.

An external electrical disconnect (not supplied with the boiler) with 15 amp overload protection is required. The boiler must be grounded in accordance with local codes or in the absence of such requirements, in the U.S. with National Electrical Codes, ANSI/NFPA No. 70 latest edition and in Canada to the current Canadian Electrical Code, Part I, CSA C22.1.

NOTICE! A dedicated earth ground (green wire) is required to avoid nuisance shutdowns. Do not ground through the conduit. It is also important that proper polarity be maintained.

The electrical boxes are located on the top rear of the boiler. For wiring details, refer to Terminal Block Assignments in section 6.1


3.4.1 High Voltage (TB2) Terminal Block

The boiler power circuit requires 120 VAC, 60 hertz, with a dedicated neutral and ground as labeled. Electrical service must be rated for 8 amps minimum. Before starting the boiler, check to ensure that the proper voltage and amperage are connected to the boiler and that the boiler is connected to a suitable fused disconnect switch or circuit breaker. There must be less than 1.0V from Neutral (TB2-3) to Ground (TB2-8)

120VAC Switched Output- This contact closes when the boiler is switched on. This provides 120VAC 5Amp service to TB2-10. The neutral for this circuit is provided on TB2-3. When the boiler is switched off, this terminal is switched off as well.

3 Way Valve- This output is normally energized, keeping the three way valve providing heat to the building. The Domestic Hot Water (DHW) call for heat de-energizes this circuit, causing the 3 way valve to self close, thereby providing heat to the DHW loop. This output provides 120VAC 0.5Amp service to TB2-11. The neutral for this circuit is provided on TB2-4.

DHW Pump Relay w/Delay Off - This output is enabled when there is a call for DHW. When the call for heat is removed, the output remains enabled for a period of time. This output provides 120VAC 0.5Amp service to TB2-12. The neutral for this circuit is provided on TB2-5.



Circ Pump Relay w/Delay Off - This output is enabled when there is a call for heat. When the call for heat is removed, the output remains enabled for a period of time. This output provides 120VAC 0.5Amp service to TB2-13. The neutral for this circuit is provided on TB2-6.

Damper Relay - This output is enabled when the call for heat is enabled. This output provides 120VAC service to TB2-14. The neutral for this circuit is provided on TB2-7. This circuit is for pilot duty only.

Master Alarm Relay – This contact closes in the event of an alarm output from the boiler control, connecting TB2-15 and TB2-16.

Flame Detected Relay – This contact closes whenever the boiler is firing, connecting TB2-17 and TB2-18.

3.4.2 Low Voltage (TB1) Terminal Block

Enable/Disable– TB1-1 and TB1-2 are used for enabling the boiler. Closing this circuit allows the boiler to run. Opening this circuit prevents the boiler from running. This circuit is energized by the boiler. It has a 24VAC potential. Devices connected to these terminals must be rated for 24VAC

External Interlock – TB1-3 and TB1-4 are used for attachment of an additional field safety device to the boiler control circuit. Closing this circuit allows the boiler to run. Opening this circuit prevents the boiler from running. This circuit is energized by the boiler with a 5V potential. Devices connected to these terminals must be rated for 5V.

Outdoor Temp Sensor – TB1-5 and TB1-6 are connected to the outdoor temperature sensor. The temperature control must be programmed to run an outdoor air schedule. The outdoor air sensor and programming help are available from the local Harsco Industrial, Patterson-Kelley Representative. This circuit is energized by the boiler with a 5V potential. The temperature sensor must be a NTC having 12k@25°C.

DHW Stat/Sensor – TB1-7 and TB1-8 are connected to the DHW temperature sensor or thermostat. This circuit is energized by the boiler with a 5V potential. The temperature sensor must be a NTC having 12k@25°C.

Header Temp Sensor – TB1-9 and TB1-10 are connected to the header temperature sensor. This circuit is energized by the boiler with a 5V potential. The temperature sensor must be a NTC having 12k@25°C.

DHW Flow Switch – TB1-11 is energized by the boiler with a 5V potential. This circuit connects through a flow switch on the domestic side of a domestic hot water system. The flow switch should close upon flow to provide a closed circuit back to TB1-12.

Analog Input– Remote signal for controlling the boiler. The boiler can be operated in a remote setpoint or a remote firing rate control mode. Input 0-10VDC signal on TB1-13 only. The 0V Analog Input is provided on TB1-14. The temperature control must be programmed to run with the analog input.

MODBUS® – TB1-17 and TB1-18 are used for connecting a MODBUS® building management system. (See the ENVI® Control Advanced Users Guide for more information)

Cascade – TB1-19 and TB1-20 are used to connect between boilers that are part of a Master/Member Network. Up to 24 boilers may be connected together. (See the ENVI® Control Advanced Users Guide for more information)

3.5 INLET AIR AND EXHAUST VENTING

3.5.1 Applicable Codes & Standards

CODES

United States:

NFPA 54/ANSI Z223.1

National Fuel Gas Code

NFPA/ANSI 211

Chimneys, Fireplaces, Vents and Solid Fuel Burning Appliances

Canada

CAN/CSA B149.1

Installation Codes for Gas Burning Equipment

STANDARDS

UL 1738

Venting Systems for Gas-Burning Appliances, Categories II, III, and IV

ULC S636-95

Standard for Type BH Venting Systems

Sheet Metal and

Thermoplastic Duct Construction Manual

Air Conditioning Contractors

National Association (SMACNA)

These codes and standards contain information for the venting of gas fired appliances, including, but not limited to vent sizing, location, clearance to combustibles, and safe installation practices. The installation must comply with both the above Federal Codes and with state, provincial and local codes.

⚠ WARNING

Design and installation of venting systems should be done only by qualified and knowledgeable venting systems personnel and in accordance with vent system manufacturer's installation instructions. Installing a boiler or vent system using improper installation methods or materials can result in serious injury or death due to fire or asphyxiation.

⚠ WARNING

Before connecting a boiler to a venting system, it must be determined whether the boiler is to be installed in a conventional or Direct Vent configuration. In the US, provisions for combustion and ventilation air must be in accordance with NFPA 54/ANSI Z223.1, *National Fuel Gas Code*, latest edition, or applicable provisions of the local building codes. In Canada, combustion and ventilation air openings shall comply with CAN/CSA B-149.1 *Natural Gas and Propane Installation Code*.

⚠ WARNING

For correct installation of vent system, read all of these instructions and refer to vent manufacturer's instructions.

Failure to use a proper vent system (types and materials), as described in this manual will void the boiler warranty and may result in rapid deterioration of the venting system, creating a health or life safety hazard.

Faulty vent installation can allow toxic fumes to be released into living areas. This may cause property damage, serious bodily injury or death.

3.5.1.1 Gas Vent Categories

Several codes and standards have categorized appliances in accordance with the flue gas temperature and pressure produced by the appliance. Categories are defined as follows:

- **Category II** An appliance that operates with a non-positive vent static pressure and with a vent temperature that may cause excessive condensate production in the vent.

- **Category IV** An appliance that operates with a positive vent static pressure and with a vent temperature that may cause excessive condensate production in the vent.
- **Direct Vent** An appliance that is constructed and installed so that all air for combustion is derived directly from outdoors and all flue gases are discharged to the outdoors.

3.5.1.2 Venting Materials for Flue/Exhaust Systems

The MACH® C750, C900 and C1050 boilers are dual-certified as both Category II and Category IV appliances, which vent with a temperature that is likely to cause condensation in the vent. Refer to Section 3.5.3.2 for requirements of Category II installations and Section 3.5.3.3 for requirements of Category IV installations. Any venting system used with the MACH® boiler must comply with the applicable venting system category as specified in the latest edition of NFPA 54/ANSI Z223.1 in the US or the latest edition of CAN/CSA B-149.1 in Canada.

WARNING

The venting materials listed below are intended for the venting of gas burning appliances only. Do not use these venting materials for venting liquid or solid fuel (such as oil, kerosene, wood or coal) appliances.

Maintain clearances to combustibles as listed in the vent manufacturer's installation instructions or as set forth in the codes and standards listed in this section.

Do not use these vent pipes for incinerators of any sort.

This boiler is not certified for use with PVC venting. Use of PVC vent may result in vent failure and possible serious injury or death.

According to ANSI Z21.13./CSA 4.9, Gas-Fired Low Pressure Steam and Hot Water Boilers, Table XVII "Maximum Allowable Temperatures of Typical Non-Metallic Vent Material" the maximum allowable temperature for PVC is 158°F (70°) and for CPVC is 210°F (100°C).

Table of Acceptable Materials for Venting Systems

Manufactured Venting

US and Canada

Factory Fabricated Metallic Vent Systems listed and labeled to UL1738 (Titled: *Venting Systems for Gas-Burning Appliances, Categories II, III, and IV*)

Non-metallic Venting

Within the US

CPVC pipe conforming to ASTM F441, fittings conforming to ASTM F439 (Sch 80). Joints are to be sealed with solvent conforming to ASTM F493.

Within Canada

CPVC Pipe, Fittings and Sealant listed and labeled to ULC S-636 *Standard for Type BH Venting Systems*
Table 1.3.2 Applicable Vent Materials By Boiler Model

As per ANSI Z21.13b-2012 * CSA 4.9b-2012:

- * The use of cellular core PVC, CPVC and Radel as venting materials is prohibited.
- * The use of external insulation on plastic vent pipe is prohibited.

Table of Applicable Vent Materials by MACH® Boiler Model

Model	AL29-4C	316L SS	CPVC	PVC
US C750 – C1050	X	X	X	No
CAN C750 – C1050	X	X	Note 2	No

Note 2: In Canada, any CPVC used for venting must be listed to ULC S636.

3.5.2 Combustion Air

Combustion air must be free from dust, lint, etc. The presence of such materials in the air supplied to the burner could cause nuisance "Low Air" shutdowns or premature burner failure. The boiler should not be operated during construction while the possibility of drywall dust, demolition dust, etc. exists.

The combustion air supply must be completely free of chemical fumes which may be corrosive when burned in the boiler. Common chemicals which must be avoided are fluorocarbons and other halogenated compounds, most commonly present as refrigerants or solvents, such as Freon, trichloroethylene, perchlorethylene, chlorine, etc. These chemicals, when burned, form acids which quickly attack the boiler and the boiler stack. The result is improper combustion and premature boiler failure.

⚠ WARNING

Under no circumstances shall the boiler room ever be under a negative pressure. Particular care should be taken when exhaust fans, compressors, air-handling units or other equipment may rob air from the boiler. Note that this equipment might be in rooms other than the boiler room.

3.5.2.1 Air Inlet Requirements – United States (NFPA 54/ANSI Z223.1 & NFPA/ANSI 211)

When air is supplied from inside the building, the total required volume shall be the sum of the required volume for all the appliances located in the mechanical room. Adjacent rooms furnished with fixed openings communicating directly with the mechanical room are considered part of the required volume. The minimum volume is 50 ft³ per 1000 Btu/hr (4.8 m³/kW) of installed appliance input capacity.

Openings used to connect indoor spaces to obtain the required minimum volume shall be sized as follows:

- When rooms are on the same floor, each opening shall have an area equal to 1 square inch for each 1000 Btu/hr (2200 mm² / kW) of installed appliance input capacity, but not less than 100 square inches. One opening should commence less than 12 inches above the floor and the other less than 12 inches below the ceiling. The minimum dimension of air openings shall be 3 inches.
- When rooms are on different floors, each opening shall have an area equal to 2 square inches for each 1000 Btu/hr (4400 mm² / kW) of installed appliance input capacity.

When combustion air is supplied from outside the building, the boiler room shall be provided with one or two openings to ensure adequate combustion air and proper ventilation.

When using one permanent opening, the opening shall commence within 12 inches of the ceiling and shall communicate directly with the outdoors or through a vertical or horizontal duct that communicates to the outdoors.

- Minimum free area of the opening is 1 square inch for each 3000 Btu/hr (700 mm² / kW) of installed appliance input capacity, and
- Not less than the sum of the areas of all vent connectors in the room.

When using two permanent openings, one opening shall commence within 12 inches above the floor and the other within 12 inches below the ceiling, preferably on opposite walls. The openings shall communicate directly, or by way of ducts, with free outdoor air. The minimum net free area of the openings shall be calculated in accordance with the following:

- When air is taken directly from outside the building, each opening (minimum of two, as outlined above), 1 square inch for each 4,000 Btu per hour (550 mm²/kW) of total boiler input is required.
- When air is taken from the outdoors through a vertical duct into the mechanical room, 1 square inch per 4,000 Btu per hour (550 mm²/kW) of total boiler input is required.
- When air is taken from the outdoors through a horizontal duct into the mechanical room, 1 square inch per 2,000 Btu per hour (1100 mm²/kW) of total boiler input is required.

NOTICE!

1. The required size of openings for combustion and ventilation air shall be based on the net free area of the opening.
2. Screens shall be not smaller than ¼"
3. Motorized louvers shall be interlocked with the appliance so that they are proven open prior to main burner ignition and operation.

Table of US Minimum area of ventilation openings per boiler (sq inches)

MACH® Boiler MODEL	AIR SOURCE					
	INDOOR AIR SUPPLY		OUTDOOR AIR SUPPLY			
	SAME FLOOR	DIFF FLOORS	ONE OPENING	TWO OPENINGS		
				DIRECT	VERT DUCT	HORIZ DUCT
C750	750	1500	250	188	188	375
C900	900	1800	300	225	225	450
C1050	1050	2100	350	263	263	525

3.5.2.2 Air Inlet Requirements – Canada (CAN/CSA B149.1)

- A. Ventilation of the space occupied by fuel burning appliance(s) or equipment shall be supplied by a ventilation opening at the highest practicable point communicating with the outdoors. The total cross sectional area of the ventilation opening must be either 10% of the net free area required for combustion air or 10 sq. in. (6500 mm²), whichever is greater.
- B. Use the following opening calculation for MACH® or MODU-FIRE® FD boilers:
When combustion air is supplied for a forced draft burner by natural airflow from the outdoors and there is no draft regulator or draft hood in the same space, there shall be a permanent opening with a cross sectional area not less than 1 sq. in/ 30,000 Btu/Hr (70 mm²/kW) of the total rated input to the burner(s). This opening must not interfere with the ventilation air opening defined in paragraph A.
- C. Use the following opening calculation for P-K THERMIFIC® boilers or other natural draft or fan-assist appliances:
When combustion air is supplied for natural or fan-assisted burners by natural airflow from the outdoors, there shall be a permanent opening with a cross sectional area not less than 1 sq. in/ 7000 Btu/Hr (321 mm²/kW) up to and including 1,000,000 Btu/Hr plus 1 sq. in. / 14,000 Btu/Hr (155 mm²/kW) in excess 1,000,000 Btu/Hr. This opening must be either located at or ducted to a point not more than 18 in. (450 mm) nor less than 6 in. (150 mm) above floor level. This opening is in addition to the ventilation air opening defined in paragraph A.
- D. When combustion air is supplied by natural airflow into a space containing both types of appliance described in paragraphs B and C, the cross sectional area of the opening shall be not less than the sum of the cross sectional areas for all appliances in the space as calculated by the applicable method . This opening is in addition to the ventilation air opening defined in paragraph A.

- E. When a duct is used to meet the requirement for combustion air supply, as described in paragraphs A through D, above, the opening of the duct shall be located so there is no possibility of cold air affecting steam or water piping, electrical equipment or mechanical equipment.
- F. When combustion air is supplied by mechanical means, an airflow-sensing device must be installed. It must be wired into the pre-ignition limit string to prevent the burner from starting or to stop an operating burner in case of air supply failure.
- G. When all combustion air is supplied through a make-up air heater, and the appliance is interlocked to the heater, the requirements of paragraphs A through F do not apply.

NOTICE!

1. The free area of a combustion air supply opening is calculated by deducting the blockage area of any fixed louvers, grilles or screens from the total area of the opening.
2. Screens shall be not smaller than ¼"
3. Motorized louvers shall be interlocked with the appliance so that they are proven open prior to main burner ignition and operation

Table of Canadian Minimum Area of Combustion and Ventilation Air Openings

MACH® Boiler		Required Combustion Air Opening		Ventilation Air Opening	
Model #	Input (Btu/Hr)	in ²	mm ²	in ²	mm ²
C750	750,000	25	16,129	10	6,452
C900	900,000	30	19,355	10	6,452
C1050	1,050,000	35	22,581	10	6,452

3.5.3 Flue Venting

This boiler is not certified for use with Type "B" vent nor with PVC venting.

⚠ CAUTION

All boiler venting systems should be designed by a qualified venting professional experienced in venting system design. The information contained herein should be used as a guide only and is not intended to be used in lieu of qualified technical expertise.

3.5.3.1 VENT SIZING

The vent must be sized in accordance with the ASHRAE Systems and Equipment handbook, Chapter 30 or according to the vent manufacturer's recommendations. When using manufactured venting systems, consult your vent supplier for correct sizing and structural support requirements.

Table of Vent Design Parameters

MACH® Boiler Model	Frictional Resistance	Stack Temperature	CO ₂ Natural Gas	CO ₂ LP Gas
C750 – C1050	0.22"	210°F	9.0%	10.4%

3.5.3.2 CATEGORY II INSTALLATIONS

The MACH C750, C900 and C1050 are dual-certified for both Category II and Category IV operation. Category II appliances operate with a non-positive vent static pressure and with a vent temperature that may cause excessive condensate production in the vent. There are several requirements for reliable operation of the boilers under Category II conditions:

1. A stainless steel vent adapter is required to mate the boiler exhaust connection and the vent pipe. See the table below for the applicable part numbers.
2. A normally-closed motorized damper is required on the boiler's air intake. See the table below for the applicable part numbers.
3. The draft, measured inside the vent at the rear of the boiler, **must not exceed -0.04" W.C.** Excessive negative draft will cause nuisance trips such as flame failures.
4. The vent system must be properly drained of condensate before returning to the boiler. Please see Section 3.5.3.6 for information on installing condensate drains in the exhaust vent.






Table of Required Stainless Steel Vent Adapters and Category II Motorized Dampers

Boiler Size	Nominal Stack Size	Stainless Vent Adapter	Normally-Closed Motorized Damper	A	B	C	D
C750	6"	2620000181 (OEM)	1004906943	6"	6"	9"	1.38"
C900	8"	2620000366	1004906944	8"	8"	11"	2.38"
C1050	8"	2620000366	1004906944	8"	8"	11"	2.38"

The normally-closed motorized damper operates on 120 VAC and features an end limit switch wired into the boiler's external interlock circuit. Upon a call for heat, the boiler's damper relay will energize and drive the damper open. Once the damper reaches the fully-open position, the end limit switch makes contact and closes the external interlock circuit allowing the boiler to fire. The diagram below shows the wiring necessary to install the normally-closed motorized damper.



ENVI® Control



CAUTION

Use caution if installing a barometric damper in the exhaust vent. The vent pressure **must be negative** (Category II) from the barometric to the vent termination at all times to prevent leakage of harmful flue gases into the room. Leakage of flue gases can cause serious injury or death.

3.5.3.3 CATEGORY IV INSTALLATIONS

If the vent installation is designed for Category IV conditions only (condensing – positive pressure) as it is defined in ANSI Z21.13/CSA 4.9, latest edition. The vent material must be as listed in Table in section 3.5.1.2 and can be run horizontally or vertically.

Vent installations shall be in accordance with NFPA54/ANSI Z223.1, the *National Fuel Gas Code*, or CAN/CSA-B149.1, the *Natural Gas and Propane Installation Code*, or applicable provisions of the local building codes.

WARNING

Do not use a barometric damper if operating with a positive stack pressure (Category IV). Harmful flue gases may leak into the room which can cause serious injury or death.

3.5.3.4 CPVC VENT SYSTEM INSTALLATION

Install CPVC vent systems in accordance with this manual and the SMACNA *Thermoplastic Duct Construction Manual*. Install manufactured vent systems in accordance with the manufacturer's listing and instructions.

When venting this boiler using CPVC vent material, the following operating and installation conditions must be met:

Operating Parameters

Maximum Water Temperature Set Point 180°F

- Flue Gas Limit 200°F

Installation Parameters

- Cement and primer must conform to ASTM F493
- Three feet of venting closest to the boiler must not be enclosed
- The vent shall not be insulated

Table of CPVC Support Spacing (Feet)

Vent Size	Sch 40	Sch 80
4	4	4-1/2
6	4-1/2	5
8	5	5-1/2
10	5-1/2	6
12	6	6-1/2


Table of Stainless Steel Adapter for CPVC Part Numbers

Boiler Size	Nominal Stack Size	Stainless Adapter for CPVC Part Number
C750	6"	2620000237
C900	8"	2620000238
C1050	8"	2620000238

A customer supplied adapter is required to be installed between the boiler and the CPVC venting. Below is a table containing the available adapter for each size MACH® boiler. Installer should use Adapters listed below or equivalent.

3.5.3.5 Required Clearances

Provide clearances between combustion air intake, exhaust vent, roof and wall surfaces, doors and window, and snow line. Refer to Figure below: Termination Clearances – Forced Draft and Direct Vent Installations.



Reference: NFPA 54/ANSI Z223.1 National Fuel Gas Code

WARNING

Do not locate intake or exhaust terminations directly above a walkway; dripping of condensation can cause icing of the walking surface. Maintain a minimum clearance of 4 ft (1.22 m) horizontally from any electric or gas meter, regulator or relief equipment.

Conventional Vent Systems Clearances

The following termination clearance requirements are for conventional, non-direct vent installations.

- The vent system shall terminate at least 3 ft above a forced air inlet within 10 feet horizontally.
- The vent system shall terminate at least 4 ft below, 4 ft horizontally from or 1 ft above any door, operable window or gravity inlet into any building. The bottom of the vent terminal shall be at least 12 in. above grade or highest expected snow line (if applicable).
- Through the wall terminations shall not terminate over public walkways or over an area where condensate or vapor could create a nuisance or hazard or could be detrimental to the operation of regulators, relief valves or other equipment.

Direct Vent (Sealed Combustion) Systems Clearances

- The vent terminal shall be located at least 12 in. from any air opening into a building. The bottom of the vent terminal shall be at least 12 in. above grade. Both the vent and air intake terminals must be at least 12 in. above the highest expected snow line.
- Through the wall terminations shall not terminate over public walkways or over an area where condensate or vapor could create a nuisance or hazard or could be detrimental to the operation of regulators, relief valves or other equipment.

Interior Component Clearances

All vent system components shall be installed so as to maintain the following required minimum clearances:

	Combustible	Non-Combustibles
Unlisted single wall metal pipe	Do NOT Use	Do NOT Use
Single wall CPVC pipe	18 in.	As required for installation & access
UL 1738 listed Category IV vent	Per manufacturer's listing	Per manufacturer's listing

NOTE! Make sure that the weight of the vent is **not supported** by the boiler vent collar. **The collar is not designed to support the weight of the vent.** The CPVC or manufactured vent system shall be supported in accordance with the manufacturer's instructions. Horizontal vent sections shall be supported in a manner to prevent sags or low spots where condensate can collect. Structural supports must be connected to building elements of sufficient strength to withstand the weight of the vent system and any bending forces imposed by the venting system.

3.5.3.6 Flue Connection


WARNING

The boiler vent should not be connected into any portion of another mechanical draft system without consulting the vent manufacturer. The boiler shall not be connected to any part of a vent system serving a Category I or II appliance, nor shall a Category I or II appliance be connected to any part of the vent system serving this appliance. Improper interconnection of venting systems may result in leakage of flue gases into occupied spaces.

The connection from the boiler to the vent should be as direct as possible and the upward slope of any horizontal breaching should be at least 1/4 inch per linear foot.

The complete exhaust with drain system is shown in the figure below. The appliance connector should incorporate provisions to drain condensate formed in the vent system. The connector should include an appropriate drain section (not provided).


NOTICE! The condensate formed from natural gas flue gases is acidic. The condensate shall be drained in accordance with local code requirements. A condensate neutralizer may be required by local code.



3.5.3.7 Vent Terminations

The vent shall extend at least three (3) feet above the roof, or at least two (2) feet above the highest part of any structure within ten (10) feet of the vent. This is illustrated in the following diagram. Additionally the boiler vent shall terminate at least 3 ft above a forced air inlet located within 10 ft.

Reference: NFPA 54/ANSI Z223.1 National Fuel Gas Code



To prevent the possible re-circulation of flue gases, the vent designer must take into consideration such things as prevailing winds, eddy zones, building configurations, etc. Harsco Industrial, Patterson-Kelley cannot be responsible for the effects such adverse conditions may have on the operation of the boilers. Dimensions listed above are minimums and may not be sufficient for conditions at a specific job site.

Vertical vents are allowed to be terminated with a variety of ends, including plain straight pipe, elbow or vent tee. Horizontal vents must be terminated as illustrated in section 3.5.5. A bird screen with 1" x 1" openings is recommended for the termination. Harsco Industrial, Patterson-Kelley does not recommend using a vent rain cap of any type.

3.5.4 Venting for Multiple Boilers

The venting instructions in this manual apply to a **single** boiler.

Venting systems for multiple boilers must be designed by experienced and knowledgeable professionals. The venting system must prevent backflow of exhaust gas through idle boilers.

3.5.5 Sealed Combustion/Direct Vent Systems

The MACH® boilers are also certified for operation with a sealed combustion air and pressurized venting system. Such a system employs a sealed combustion air intake duct leading from outdoors and a sealed exhaust vent terminating outdoors. Air flow through the system is maintained by the combustion air fan. Allowable configurations of vent and air intake terminations are illustrated below.

The combined pressure drop of the air supply duct and exhaust vent must not exceed 0.44" W.C. This total pressure drop can be distributed over the intake or exhaust as needed for the installation

3.5.5.1 Intake Duct Materials and Sizes

Table 3.5 Air Requirements – SCFM

MACH® Boiler MODEL	Required SCFM
C750	175
C900	210
C1050	245


The air intake duct can be fabricated from PVC, CPVC, single wall galvanized steel, or other suitable materials. The duct must be rigid enough to maintain the full required cross sectional area under all operating conditions. Proper sealing of the intake ductwork is necessary to prevent infiltration of air from conditioned space. Joints in PVC or CPVC must be cemented. For galvanized duct, wrap each joint and seam with adhesive aluminum tape or other sealant. Connect the air supply duct to the

inlet air collar on the boiler. Fasten the duct to the collar with sheet metal screws and seal with aluminum tape or sealant. The installation of a bird screen on the intake termination is recommended. Ensure that the screen does not become blocked with snow, ice, insects etc.


3.5.5.2 Intake/Exhaust Layout

Four basic configurations for the intake/exhaust may be used for the C750/C900/C1050. Refer to Section 3.5 for required clearances for all terminations.


NOTICE! Drains have been omitted for clarity.




Sidewall Vent, Sidewall Air Inlet (above)



Vertical Vent, Room Air Inlet (above)



Vertical Vent, Sidewall Air Inlet (above)



Vertical Vent, Vertical Air Inlet (above)

3.5.6 Removing an Existing Boiler

When an existing boiler is removed from a common venting system, the common venting system is likely to be too large for proper venting of the appliances remaining connected to it.

At the time of removal of an existing boiler, while the other appliances remaining connected to the common venting system are not in operation, the following steps should be followed with each appliance remaining connected to the common venting system placed in operation:

1. Seal any unused openings in the common venting system.
2. Visually inspect the venting system for proper size and horizontal pitch and determine that there is no blockage or restriction, leakage, corrosion or other deficiency which could cause an unsafe condition.
3. Insofar as is practical, close all building doors and windows and all doors between the space in which the appliances remaining connected to the common venting system are located and other spaces of the building. Turn on clothes dryers and any appliances not connected to the common venting system. Turn on any exhaust fans, such as range hoods and bathroom exhausts, so they will operate at maximum speed. Do not operate a summer exhaust fan. Close fireplace dampers.
4. Place the appliance being inspected in operation. Follow the lighting instructions. Adjust the thermostat so that the appliance will operate continuously.
5. Test for spillage at the draft hood relief opening after 5 minutes of main burner operation. Use the flame of a match or candle or smoke from a cigarette, cigar or pipe.
6. After it has been determined that each appliance remaining connected to the common venting system properly vents when tested as outlined above, return doors, windows, exhaust fans, fireplace dampers and any other gas-burning appliance to their previous conditions of use.

Any improper operation of the common venting system should be corrected so the installation conforms with the National Fuel Gas Code, ANSI Z223.1 and CSA B149 Installation Code. When resizing any portion of the common venting system, the common vent system should be resized to approach the minimum size as determined using the appropriate tables in part 11 of the National Fuel Gas Code, ANSI Z223.1/NFPA 54 and/or CAN/CSA B149.1 Natural Gas and Propane Installation Code.

3.6 GAS PIPING

Before making the gas hook-up, make sure the boiler is being supplied with the type of fuel shown on the boiler nameplate.


The boiler shall be installed such that the gas ignition system components are protected from water (dripping, spraying, rain, etc.) during appliance operation and service (circulator replacement, control replacement, etc.)

The boiler is factory fire-tested and adjusted for proper combustion. The gas train components are certified to handle a minimum inlet pressure of 3.5" W.C. and a maximum inlet pressure of 14" W.C. (1/2 psig.). Typical gas pressure supply for natural gas is 7" W.C. (11" W.C. for propane). If the available gas pressure exceeds 14" W.C., a suitable additional intermediate gas pressure regulator of the "lock up" type must be provided to reduce the pressure to less than 14" W.C.



WARNING

All threaded connections must be made using a pipe compound that is resistant to the action of liquefied petroleum gases. **Do not use Teflon tape on gas line threads.**



Gas Piping Schematic (left)

Install a sediment trap (drip leg) and a union connection ahead of the primary manual shutoff valve on the boiler. Gas piping should be installed in accordance with National Fuel Gas Code, ANSI Z223.1, latest edition, and any other local codes which may apply; in Canada see CAN/CSA-B.149.1, latest edition. In the Commonwealth of Massachusetts, the gas cock must be a "T-handle type."

NOTICE! See Pipe Capacity for Natural Gas chart below for required pipe size, based on overall length of pipe from meter plus equivalent length of all fittings. Approximate sizing may be based on 1 cubic foot of natural gas per 1,000 Btu per hour input, i.e., 500,000 Btu per hour requires about 500 cubic feet per hour. (See "Typical Boiler Operating Conditions," Section 4.3, for more information.)

Pipe Capacity for Natural Gas

Nominal Iron Pipe Size (Inches)	Internal Diameter (Inches)	Equivalent Pipe Length		Maximum Capacity in Cubic Feet of Natural Gas per Hour Pressure Drop of 0.5 inch Water Column/Equivalent Length of Pipe (in feet)						
		90° Ell (Feet)	Tee (Feet)	20	40	60	80	100	150	200
1/2	0.622	1.55	3.1	120	82	66	57	50	40	35
3/4	0.824	2.06	4.12	250	170	138	118	103	84	72
1	1.049	2.62	5.24	465	320	260	220	195	160	135
1- 1/4	1.380	3.45	6.9	950	660	530	460	400	325	280
1- 1/2	1.610	4.02	8.04	1460	990	810	690	620	500	430
2	2.067	5.17	10.3	2750	1900	1520	1300	1150	950	800
2- 1/2	2.469	6.16	12.3	4350	3000	2400	2050	1850	1500	1280
3	3.068	7.67	15.3	7700	5300	4300	3700	3250	2650	2280
4	4.026	10.1	20.2	15800	10900	8800	7500	6700	5500	4600

3.6.1 Gas Supply Piping by Installer

The boiler and all gas piping connections should be pressure-tested and must be checked for leaks before being placed into service. Test with compressed air or inert gas if possible.

The boiler must be **disconnected** at the boiler manual shut-off valve (located at the end of the supplied gas train) from the gas supply piping system during any pressure testing of the system at pressures in excess of 1/2 psig (14" W.C.).

During any pressure testing of the gas supply piping system at pressures equal to or less than 1/2 psig (14" W.C.), the boiler should be isolated from the gas supply piping system by closing the manual shut-off.

Some leak test solutions, including soap and water, may cause corrosion. These solutions should be rinsed-off with water after testing.

3.7 BOILER WATER PIPING

3.7.1 Piping Design

Water Flow in System/Pumping Requirements


See the charts below for proper water flow requirements. Incorrect flow may result in eventual damage or premature failure of the equipment that may not be covered by warranty.

Proper flow rates may be achieved through a combination of primary and secondary flow loops. Multiple zones and pumps may result in different flow rates at different times. Consideration must be given to all possible conditions and their consequences.


Maximum Fire Rate

Model	Max Flow GPM	Min Flow GPM	Pressure Drop (ft.) at max flow
	20°F ΔT	40°F ΔT	
1050	105	52	12
900	90	45	12
750	75	37	12

For minimum flow rates at other than maximum firing rate, see MACH® Boiler Variable Pumping Graph (below)



Delta pressure loss in pressure at a flow rate




3.7.1.1 Piping with Refrigeration Machines

When installed in a two-pipe system that provides both chilled and hot water, the control system should be configured so as to limit the time rate of change of temperature at the boiler. Consult your authorized Harsco Industrial, Patterson-Kelley boiler representative for application guidance.

3.7.1.2 Piping with Air Handling Units

The boiler piping system of a hot water heating boiler connected to heating coils located in air handling units, where they may be exposed to refrigerated air circulation, must be equipped with flow control valves or other automatic means to prevent gravity circulation of the boiler water during the cooling cycle.

3.7.2 Boiler Inlet and Outlet Connections



All water connections should be in compliance with national, state and local code requirements.

NOTICE! The boiler is furnished with 2" grooved connections and Victaulic Style 75 Couplings. These couplings must be used with the EPDM Victaulic seals. Isolating valves must be installed in both water connections.

Adapters from Victaulic to NPT are available from Harsco Industrial, Patterson-Kelley.

The bottom connection to the boiler is the INLET and must be used for the return from the system.

The top connection to the boiler is the OUTLET and must be connected as the supply to the system.

NOTICE! Condensate Trap must be piped to drain in accordance with all national, state and local codes. If installed outdoors, it must be field heat traced.

3.7.3 Boiler Water Piping by Installer

Strainer

To avoid possible contamination of the boiler with dirt, rust or sediment from the system, a strainer near the boiler inlet is strongly recommended. Even new systems may contain sufficient foreign material to eventually reduce the performance of the heat exchanger. Adequate circulation of good clean water is essential for maximum efficiency and long life of the boiler.

Relief Valve Piping

Each boiler is supplied with a pressure-relief valve sized in accordance with ASME requirements. The relief valve must be piped to an acceptable drain. Reducing couplings or other restrictions are not permitted in the discharge line.

Low Water Cut-off

The boiler is furnished with a probe-type low water cut-off; no field piping is required. If the water level in the boiler drops below the probe, the boiler will shut down and a LOCKOUT LOW WATER LEVEL will be displayed on the control panel. The low water cut-off will automatically reset when the low water condition clears; however the boiler control will retain the lockout condition until the reset button on the display is pressed.

NOTICE! The low water cut-off probe only prevents boiler operation when the water level in the boiler is insufficient. It does not detect low water conditions in other parts of the system. Installation of high point vents or additional low water safety devices to protect the system should be considered.

Installation of external limit controls may be required by certain codes or in certain installations. Review applicable local codes for details.

Drain Valve and Piping

A drain valve is factory installed in the boiler inlet (system return) piping. Prior to draining the boiler, electrical power and gas supply must be turned off to the boiler, and the boiler must be isolated from the system at the supply and return connections.

NOTICE! This drain valve is factory installed for draining of the boiler water only, not the entire system. Draining of the system through the boiler will result in depositing sediment from the system in the boiler which will result in poor heat transfer characteristics of the boiler and early boiler failure.

Condensate Drain

The condensate is acidic (pH between 3.0 and 5.0) and may be corrosive to some building drain systems. A condensate neutralization system may be required and is available from Harsco Industrial, Patterson-Kelley.

Disposal of condensate must comply with all state and local codes.

The boiler could generate up to one gallon of condensate per 100,000 BTU input. See table below for typical condensate loading.

MACH® Boiler	Typical Condensate (Gal/hr)
C750	7.5
C900	9
C1050	10.5

3.7.4 Flushing and Filling

Water Quality

The MACH® boiler heat exchanger is made of an aluminum alloy. The heat exchanger requires proper water conditions to remain efficient and function properly.

NOTICE! Glycol or other treatment chemicals added to the system must be certified by the chemical manufacturer for use in multi-metal systems that include cast aluminum boilers.

NOTICE! Under no circumstances should petroleum based cleaning or sealing compounds be used in the boiler system.

NOTICE! Under no circumstances should the hydronic system be flushed while the boiler is attached to the system since the debris or corrosion products could accumulate in the boiler and plug the boiler heat exchanger.

NOTICE! If the piping system attached to this unit will be chemically cleaned, the boiler must be disconnected from the system and a bypass installed so that the chemical cleaning solution does not circulate through the boiler. Following chemical cleaning, the system should be thoroughly rinsed to remove cleaning agents prior to reconnecting the boiler to the system.

3.8 PRE-START CHECK LIST

Before attempting to start the boiler, make sure the following items have been completed.

1. Inspect the gas train, blower, ignition electrode and boiler in general to be sure there was no damage during shipment or installation.
2. Flue gas from the boiler is properly vented; (refer to Section 3.5)
3. Gas connection has been made, pressure tested for leakage and the line purged of air. Make sure all required vents have been installed. (refer to Section 3.6)
4. Water connections are complete and the boiler and system have been filled and purged of air. (refer to Section 3.7)
5. The boiler is connected to a 120 volt power source with a disconnect having adequate overload protection. (refer to Section 3.4)
6. Combustion air openings are not obstructed in any way and have adequate capacity. (refer to Section 3.5)
7. The boiler is placed the proper distance from any combustible walls, in accordance with Section 3.3.3.
8. Relief valves have been piped to an acceptable drain. (refer to Section 3.7)
9. Condensate piping is properly connected. (refer to Section 3.7)
10. Verify system water quality is within specifications.

3.9 SAFETY CHECKS

The following checks of safety systems must be made before putting the boiler into operation.

Before firing the boiler refer to Sections 4.1 and 4.2 for information on the use of the controls, lighting, and shut-down procedures.

⚠ WARNING

Never attempt to operate a boiler that has failed to pass all the safety checks described below.

⚠ WARNING

If a control setting is changed manually during testing, return the control to its original setting.

NOTICE! If the expected error code(s) do not appear, call for qualified service.

3.9.1 Test of Ignition Safety System

Test the ignition system safety shutdown as follows:

- 1) Cycle the boiler on by generating a heat request. (See Section 3.10)
- 2) Place the boiler in operation at the high fire setting.
- 3) Smoothly close the downstream manual isolation valve to reduce the gas flow and cause flame failure.
- 4) The display will show LOCKING FLAME FAILURE indicating a flame failure. The lockout will remain until the control is reset.

After completing this test, turn off the boiler and open the downstream manual isolation valve and turn the boiler back on.

3.9.2 Test of Low Water Cut-off

The boiler is furnished with a probe-type low water cut-off in the outlet nozzle. Test as follows:

Push and hold the red "Push to test" button for at least 5 seconds. A manual lockout reset error, displaying LOCKOUT LOW WATER LEVEL on the display panel, should occur. The LED indicator on the low water cut-off will no longer be illuminated.

(Optional Test Method)

First turn the boiler off, and then turn the pump off. Isolate the boiler from the system. Drain the water level below the low water cut-off probe. Turn the boiler back on. It should not operate, and a manual lockout reset error, displaying LOCKOUT LOW WATER LEVEL on the display panel, should occur. The LED indicator on the low water cut-off will no longer be illuminated.

Return the system to normal operation by refilling and restarting the boiler and pump.

3.9.3 Test of High-Limit Control

Fire the boiler and test the high limit control as follows:

With the main burner operating, turn down the temperature setting on the "high-limit" thermostat until the main burner shuts off. A manual reset lockout, displaying LOCKING HIGH LIMIT on the display panel, will occur. The high-limit switch must be manually reset prior to resetting the boiler at the display panel. Readjust the high-limit thermostat to the desired setpoint.

3.9.4 Test of Gas Pressure Switches

Low Gas Pressure Switch


The boiler is furnished with a low gas pressure switch. The operation of this switch must be checked by slowly closing the main gas cock while the burner is operating. The switch should shut down the main burner. When the gas pressure switch opens, a manual reset lockout displaying LOCKING LOW GAS PRESSURE on the display panel will occur. Upon re-opening the main gas cock, the LOCKING LOW GAS PRESSURE will remain on until the display panel is manually reset.

High Gas Pressure Switch

The boiler is furnished with a high pressure switch that must be checked by closing the downstream gas cock with the boiler off. When the boiler is started, it should enter its normal starting cycle and fail on high gas pressure when the automatic gas valves open. The boiler locks out and displays LOCKING HIGH GAS PRESSURE on the display panel. Upon re-opening the gas cock, the LOCKING HIGH GAS PRESSURE indicator will remain on until the display panel is manually reset.

3.10 INITIAL ADJUSTMENTS

3.10.1 Operating Temperature Controller




The MACH® boiler C750-1050 is equipped with ENVI® control; an intelligent control system with advanced features such as text-based display, communication capabilities, and boiler sequencing. Errors are date and time stamped providing built-in history of boiler status and performance. This control constantly tracks the load by recording burner high, low and mid run hours. One control to do it all – temperature control, flame safeguard, firing rate control, blocked flue protection, outdoor air reset, freeze protection, built-in cascade sequencing, MODBUS communication and more.

CAUTION

The user should become thoroughly familiar with the operation of the boiler and controls before attempting to make any adjustments.

The boiler control has a text display panel. The display panel is used to setup and monitor boiler operation by means of six push buttons MENU, BACK, ENTER, UP, DOWN, and RESET as shown above. The buttons across the bottom are used to navigate through the various screens. The four line screen shows boiler operating information on various screens. The display screen is backlit for ease of viewing. Pressing any key will illuminate the backlight.

The standby screen is shown upon startup. This screen shows the date, time, boiler status, supply temp and setpoint temp. Pushing the menu button displays a menu of options.



The menu includes access to the Standby, Information, Errors, Program Parameters, Configuration, Cascade, and Service Menu. The Up and Down buttons are used to position the arrow next to the desired option and the enter button is pushed to enter that option. The list is displayed and may have more than four lines. Use the down arrow to view the complete list.

⚠ CAUTION

Changing parameters requires an understanding of the parameters and the functionality of the boiler. The boiler may not function properly if parameters are changed from the factory values.

3.10.2 Boiler Setpoint

The factory default setpoint is 180 °F. If a different setpoint is desired, push the menu button and then select PROGRAM PARAMETERS from the menu. A screen opens that allows the user to view and change operating parameters (see screenshot below.)

Parameters

→ CH settings
DHW settings
Boiler settings

Select the CH settings to adjust parameters related to the boilers Comfort Heat function.

CH settings

→ Setpoint 180°F
BLR OP 1
CH mode 0

For example, selecting the Setpoint parameter opens up a screen that allows the setpoint to be changed.

CH settings

Setpoint
Value: 180° F
Range: 45° F – 185° F

The UP or DOWN buttons are used to adjust the CH setpoint up or down as desired. The ENTER button is pushed once the desired temperature is reached.

3.10.3 Other CH Parameters

Other settings include the following items:

Description	Value	Units
CH Setpoint	###	°F
BLR OP (Off = 0, On = 1, Off/Pump On = 2, and On/Pump On = 3)	#	0-3
CH Mode	#	0-8
Hysteresis On (On Differential)	##	°F
Hysteresis Off (Off Differential)	##	°F
Post Pump time	###	Sec

Additional CH Parameters are available and used for the various CH Modes other than mode 0, the standard Setpoint & Stat control mode. These modes are further described in the ENVI® Control Advanced User's Guide.

3.10.4 Other Parameters

Other parameters include the settings for DHW (Domestic Hot Water), Boiler Settings and OEM Settings. Boiler and OEM Settings are used during the initial programming of the control and are not accessible.

3.10.5 Additional Menu Items

In the main menu, Standby, Information, Errors, Program Parameters, Configuration, Cascade, and Service Menus are available. They are used for various functions of the boiler. These functions are described further in the ENVI® Control Advanced User's Guide.

These menu items will be described briefly here:

- STANDBY is the default screen and is shown during normal boiler operation.
- The INFORMATION menu lists items that the boiler monitors such as temperatures, operating conditions, and status of switches and components.
- The ERRORS menu has information about the boiler status at the time of an error.
- The PARAMETERS menu allows the user to set up selected boiler functions and operating modes.
- The CONFIGURATION menu covers basic display information such as language, units, date/time, etc.
- The CASCADE menu is used to sequence multiple boilers (up to 24) in a Master/Member network system. Use of this function is described in detail in the ENVI® Control Advanced User's Guide.
- The SERVICE menu is described below.

3.10.6 Service Menu:

Two test modes are available in the service menu.

BNR ON TEST HI LOW

BNR OFF FAN HI LOW

	Service				
→	BNR	ON	Test	HI	LOW
	BNR	OFF	Fan	HI	LOW

The first test mode allows the service technician to hold the boiler in high or low fire during firing operation so that the combustion adjustment can be performed as indicated below. The second test mode checks the fan rate with the burner off at high speed or at low speed.

These test modes will automatically terminate after 15 minutes of inactivity or can be terminated from the control/display panel by pressing the cancel/reset button.

3.11 BURNER ADJUSTMENT

NOTICE! Adjustments shall only be performed by service representative specifically trained and certified to perform maintenance on the Harsco Industrial, Patterson-Kelley MACH® boiler. Verify proper operation after servicing.

See rating plate for the minimum and maximum inlet gas pressure of the boiler. The supply pressure during main burner operation must be greater than the minimum indicated on the rating plate. Nominal gas supply pressure is 7" W.C. for natural gas. The gas pressure must not exceed 14" W.C. which is the maximum allowable pressure on the gas train components. Each boiler is furnished with a manual shut-off valve which has an integrated test port. This port is located on the upstream side of the valve body for measuring supply pressure. (See figure right.)

The air flow is pre-set at the factory prior to shipment. Gas flow is dependent primarily on fan speed not upstream gas pressure. The air/gas ratio may have to be adjusted to obtain proper combustion readings for specific local conditions. A combustion analyzer must be used. The probe must be placed in the boiler exhaust vent immediately after the boiler. Combustion should be adjusted in accordance with Table of Combustion Exhaust Settings.



NOTICE! For high altitude adjustments (greater than 2,000 feet above sea level), see Appendix 2 at the end of this manual.

Table of Combustion Exhaust Settings

Fuel	Nominal Inlet Gas Pressure*	High Fire Setting		Low Fire Setting	
		% O ₂	% CO ₂	% O ₂	% CO ₂
Natural Gas	7" W.C	5.0 ± 0.2	9.0 ± 0.2	5.2 ± 0.2	8.8 ± 0.2
Propane	11" W.C	5.0 ± 0.2	10.4 ± 0.3	5.2 ± 0.2	10.3 ± 0.3


3.11.1 Combustion Setup and Adjustment

Boiler Test Mode for High and Low fire:

Set the combustion using the Service Menu BNR ON TEST HI & BNR ON TEST LOW modes.

These test modes should be used when checking and setting the gas safety shut off / control valves on the MACH® boiler. In this mode a heat request is required. Once the boiler cycles on, use the arrow keys to access the Service Menu and select the BNR ON TEST HI/LOW mode and push enter. Then select BNR ON TEST HI or the BNR ON TEST LOW mode and push enter. The boiler will ramp to high or low fire.

NOTICE! There must be sufficient load to operate the boiler at high fire to perform the following adjustments. Start the boiler and observe proper operating parameters for the system.



C750/900/1050 Adjusting Screws for Low and High Fire

Required Tools: TORX® T40 or 5 mm hex wrench, 3 mm or 7/64 in hex wrench, Combustion analyzer

The MACH® boilers are equipped with a combined gas/air control and gas safety shut off control valves. The valve functions with the variable speed combustion blower to supply the correct gas air ratio for optimum performance and efficiency.

High Fire Setting

Set boiler to the “BNR ON TEST HI”, as described above, to achieve maximum firing rate of the boiler. Check combustion readings using a combustion analyzer. If combustion readings are not in accordance with Table of Combustion Exhaust Settings, adjust as follows:

Remove the flat, round, blue plastic cap from the gas valve. Using a 3mm (7/64”) hex wrench, adjust the high fire screw (see the figure below) on each of the gas control valves by turning clockwise or counterclockwise to achieve the desired CO₂ or O₂ level; see table for Combustion Exhaust Settings for correct settings. (There will be a time delay between the adjustment and the response of the CO₂/O₂ combustion analyzer). Adjust the settings in small increments. When desired adjustments are complete, reinstall the blue plastic cap on the gas valve. Clockwise rotation decreases gas flow. Counterclockwise rotation increases gas flow.

Low Fire Setting

Set boiler to the “BNR ON TEST LOW”, as described above, to achieve minimum firing rate of the boiler. Check combustion readings using a combustion analyzer. If combustion readings are not in accordance with Table of Combustion Exhaust Settings, adjust as follows:

Remove the gray cap on the gas regulator using a slotted screwdriver. This will expose the low fire adjustment screw. Using a TORX® T40 or a 5 mm hex wrench, adjust the low fire screw on the pressure regulator (see the figure below) to achieve the correct CO₂ /O₂ level. Adjustments to low fire should not exceed ¼ turn at a time before allowing the readings to respond and stabilize. Clockwise rotation increases gas flow. Counterclockwise rotation decreases gas flow. After the low fire adjustment is made, reinstall the slotted cap on the regulator.

NOTICE! The rotation of the Low Fire adjustment screw is opposite to the High Fire adjustment screw.


Following all gas valve adjustments, check for proper light-off and verify correct fuel/air mix and combustion quality throughout the entire firing range (from low fire to high fire).

3.11.2 Checking Flame Signal

Using the control panel, enter the information mode and scroll down to FLAME SIGNAL. When the boiler is firing, the FLAME SIGNAL will be “yes” or a 0-10 uA signal and when the boiler is not firing, the FLAME SIGNAL will be “no” or a 0-10 uA signal.

4 OPERATION

4.1 GENERAL



4.1.1 Control Panel

Become familiar with the basic operation of the boiler. The operating instructions are located inside the gray door at the front of the boiler.

4.1.2 Tests

All Harsco Industrial, Patterson-Kelley boilers are fire tested at the factory prior to shipment. This procedure includes testing of the limits and adjustment of combustion parameters. This testing and setup information is recorded on the “Factory Fire test” label located on the back of the boiler.

4.2 NORMAL LIGHTING AND SHUT-DOWN PROCEDURES

⚠ WARNING

Do not use this boiler if any part has been under water. Immediately call a qualified service technician to inspect the boiler and to replace any part of the control system and any gas control which has been under water.

4.2.1 Initial Lighting Procedures

1. Make sure the system is filled with water and water is circulating in the system. Turn on electrical supply and open the gas supply valves to the boiler.
2. Turn the on/off switch to the on position. If an error is indicated, see Section 5.5 of this manual to troubleshoot the problem and take the necessary corrective action before proceeding.
3. Set the desired high temperature limit and operating temperature. The controller will now complete the automatic firing sequence.

4.2.2 Normal Shut Down Procedures

1. Turn the on/off switch to the off position.
2. Close all manual gas valves. (For extended period.)

4.2.3 Emergency Shut-Off

⚠ WARNING

If overheating occurs or the gas supply fails to shut off, do not turn off or disconnect the electrical supply to the pump. Instead, shut off the gas supply at a location external to the boiler.

Main Gas Cock



4.3 TYPICAL BOILER UTILITY REQUIREMENTS

Model Number	Input Rating (Btu/hr)	Natural Gas *(1030 Btu/cu. ft.)		LP Gas **(2500 Btu/cu. ft.)		Total Amperage (15 amp breaker required)
		Gas Rate (CFH)	Output Capacity (Btu/hr)	Gas Rate (CFH)	Output Capacity (Btu/hr)	
750	750,000	728*	712,500	300**	712,500	8 amps or less
900	900,000	873*	846,000	360**	846,000	8 amps or less
1050	1,050,000	1019*	987,000	420**	987,000	8 amps or less

NOTICE! The heat exchanger is constructed and stamped for 80 psig maximum operating pressure and/or 200 ° F maximum temperatures.

5 MAINTENANCE

5.1 MAINTENANCE AND INSPECTION SCHEDULE

This schedule applies when the boiler is in use. Verify proper operation after servicing.

⚠ WARNING

Proper lockout/ tag out procedure must be employed when servicing this unit.

⚠ WARNING

Label all wires prior to disconnection when servicing controls. Wiring errors can cause improper and dangerous operation.

⚠ WARNING

Use care when reassembling main gas line to assure all connections are tight.

⚠ WARNING

Use care when servicing boiler in order to prevent the accumulation of gas in or around the combustion chamber.

⚠ WARNING

Determine the cause of any lockout or errors before resetting the boiler. If able to determine cause of lockout, then appropriate corrective action should be taken. If unable to determine cause of the problem, call a qualified service technician.

5.1.1 Daily

Observe operating temperature and general conditions. Make sure that the flow of combustion and ventilating air to the boiler is not obstructed. Determine the cause of any service codes or lockouts on the display panel. Observe any unusual noises or operating conditions and make the necessary corrections. Notify responsible individuals for required corrective action or repair.

⚠ WARNING

Check daily to be sure that the boiler area is free and clear of any combustible materials, including flammable vapors and liquids.

5.1.2 Weekly

Observe the appearance of the main flame. If the flame appearance changes from what was observed after proper combustion adjustment, corrective action should be taken. A qualified service person should check and adjust combustion as needed.

Correct air adjustment is essential to the efficient operation of this boiler. Ensure that the flow of combustion and ventilation air is not obstructed. If an adjustment in the combustion appears necessary, the flue gas composition should be checked with a carbon dioxide (CO₂) or oxygen (O₂) analyzer and compared to the values stated in section 3.10.4. Refer to Table of Combustion Exhaust Settings. If an adjustment in the combustion is necessary, call a qualified and knowledgeable installer or service agency that has been trained on the MACH® boilers.

5.1.3 Monthly

1. Using the control panel, enter the information mode and scroll down to view the flame signal. When the boiler is firing, the signal will be "yes" and when the boiler is not firing, the signal will be "no".
2. Test high-limit Control. (refer to Section 3.9)
3. Test operating temperature controls by reducing or increasing temperature setting as necessary to check burner operation.
4. Test the low water cut-off. Refer to Section 3.9.
5. Test low gas pressure switch. Refer to Section 3.9.
6. Check the condensate drain system. Clean and flush as necessary.

Installation and service must be performed by a qualified installer or service agency that has been trained on the MACH® boiler.

5.1.4 Semi-Annually

In addition to the recommended monthly service:

1. Clean burner of any accumulated dust or lint. See Section 5.2 on "Cleaning the Burner."
2. Inspect burner for any signs of deterioration or corrosion. Replace immediately if deterioration or corrosion is evident.
3. Check the pH level of the system fluid (refer to section 3.7.4)
4. Inspect and clean the condensate system and check for leaks. If a condensate neutralization kit is present, open the lid and inspect the limestone rocks. If they are absent or have been significantly worn away, replace them with new limestone rocks. Use hi-calcium (or pure) limestone.

Installation and service must be performed by a qualified installer or service agency that has been trained on the MACH® boiler.

The blower motor is permanently lubricated and does not require periodic lubrication.

5.1.5 Annually

In addition to the recommended monthly and semi-annual service:

1. Inspect and clean the inlet screen of any accumulated dust or lint.

2. Check burner and clean off any soot or foreign material that may have accumulated. See Section 5.2 on "Cleaning the Burner." Check for corrosion of the burner and its parts. If there is evidence of deterioration or corrosion, replace immediately. Inspect combustion chamber when the burner is removed for inspection. Note any signs of deterioration. Clean as necessary.
3. Inspect and clean heat exchanger. Remove the various covers to inspect the flue gas passageways. Clean the combustion side casting pins by flushing with clean water and blowing dry with compressed air. Do not use any cleaning agents or solvents. Do not use soap. A soft nylon brush may be used in accessible areas. Be sure to inspect the condensate collection pan that is the lowest part of the heat exchanger.
4. Replace the igniter and gasket.
5. Drain and flush the water side of the heat exchanger as required (separate from system flush) using clean water only.
6. Inspect and clean the condensate system and check for leaks. If a condensate neutralization kit is present, open the lid and inspect the limestone rocks. If they are absent or have been significantly worn away, replace them with new limestone rocks. Use hi-calcium (or pure) limestone.
7. Examine the venting system at least once a year. Refer to the vent manufacturer's instructions for requirements in addition to those listed below.
 - a. Check all joints and pipe connections for tightness.
 - b. Check pipe for corrosion or deterioration. If any piping needs replacing, do so immediately.
 - c. Inspect and clean any screens in the vent terminal
8. Qualified service personnel should thoroughly inspect the heating system and correct any problems prior to re-starting the boiler.
9. Perform combustion analysis and readjust as necessary according to section 3.11. It is recommended that a copy of this report be filed for future reference.
10. Perform a leak test of the gas valves in accordance with the manufacturer's instructions.

Installation and service must be performed by a qualified installer or service agency that has been trained on the MACH® boiler.

5.2 CLEANING THE BURNER


1. Lockout and tag out gas supply to the boiler.
2. Lockout and tag out electrical power to the boiler.
3. Remove the front door.
4. Disconnect the electrical connections to the blower and gas safety shut off / control valves.
5. Unbolt burner hood and remove the gas train & blower assembly.
6. Carefully remove the burner. Use water to rinse the burner clean. Using a soft clean cloth, wipe the inside surface of the burner. DO NOT wipe the mesh side (flame side) of the burner. DO NOT use compressed air or high pressure water to clean the burner.

5.3 AFTER ALL REPAIRS OR MAINTENANCE

1. Follow "Pre-Start Check List" (Section 3.8) and all "Safety Checks" (Section 3.9).
2. Check gas pressure. (Section 3.11)
3. Perform combustion check. Adjust if necessary. (Section 3.11).

5.4 SEQUENCE OF OPERATION

1. When the Boiler On/Off switch is turned on, power is provided through a circuit breaker to the boiler control and the combustion blower.
2. If the high gas, low gas or low water level control is open, the boiler control locks out and displays an error.
3. When the water temperature is below the boiler control setpoint minus the hysteresis (On Differential), a heat request is generated.
4. Provided all limits are made, the boiler will attempt to start.
5. The controller checks that the air pressure switch is open indicating no airflow. The blower is driven towards the prestart fan speed. When the air pressure switch closes, the 25 second pre-purge time is started. After the pre-purge, the blower is driven to the ignition speed.
6. A trial for ignition begins. The sequence of events is illustrated graphically below.
7. After ignition, the fan may be driven to low fire before the boiler is released to modulation.
8. The control modulates the firing rate between low and high fire to maintain the desired outlet water temperature.
9. The burner will continue firing until the outlet water temperature reaches set point plus hysteresis (Off Differential). At this temperature the fuel supply is shut off and the combustion air fan continues to run for a 30 second post-purge.
10. When the water temperature is reduced by the load on the system, a heat request is generated. The operating sequence will recycle to step 4.



NOTICE! Once the boiler begins the ignition sequence, the firing sequence will continue until main flame is reached regardless of heat request. The sequence can be interrupted by turning the power switch off.

5.5 TROUBLESHOOTING

WARNING

If any "Manual Reset" limit device trips, **DO NOT** reset without determining and correcting the cause. (Manual Reset Limits include: Flame safeguard, high or low gas pressure, high temperature limit, stack temperature, low water level.)

The ENVI® control will display text based error descriptions to indicate problems with the boiler. There are two types of lockouts: **Locking** - manual reset lockouts requiring an operator to press the reset button, and **Blocking** - automatic reset lockouts that will self reset when the error condition clears. A listing of errors and their service codes is included at the end of this section.

NOTE: The ENVI® control will automatically reset itself every 24 hours when the boiler has been either firing for 24 hours or in standby for 24 hours to check the safety circuitry.

If the unit fails to operate, call a qualified service technician to troubleshoot the problem and implement corrective actions.

5.5.1 The Loss of Power

In the event of a power failure, the entire system is de-energized, closing all automatic valves and halting all boiler operations. When power is restored the sequence of operation will resume at Step 4. If any error/lockout is present when the power is lost, the control will retain that error/lockout and display the error/lockout when the power is restored.

5.5.2 Loss of Water Level

The low water cut-off switch opens when there is insufficient water level in the boiler. Lockout LOW WATER LEVEL is shown on the display, the burner operation is interrupted, and the boiler locks out. When the correct water level is re-established, press the control reset button and the sequence of operation will resume at Step 4.

5.5.3 Low Gas Pressure

The low gas pressure switch opens when there is insufficient gas pressure available for proper operation of the boiler. If an external gas-supply shut-off valve is closed, a low gas condition will result. Locking LOW GAS PRESSURE is shown on the display, the burner operation is interrupted, and the boiler locks out. When proper gas pressure is restored, press the control reset button and the sequence of operation will resume at Step 4.

5.5.4 High Gas Pressure

The high gas pressure switch opens when there is excessive manifold gas pressure for the proper operation of the boiler. Locking HIGH GAS PRESSURE is shown on the display, the burner operation is interrupted, and the boiler locks out. When proper gas pressure is restored, press the control reset button and the sequence of operation will resume at Step 4.

5.5.5 High Water Temperature

When the boiler water exceeds the high limit temperature switch setting, the high limit temperature switch opens and Locking HIGH LIMIT is shown on the display. When the water temperature falls below the high limit temperature switch setting, the boiler will remain locked out until the high limit temperature switch is manually reset and the control reset button is pressed. Once reset, the sequence of operation will resume at Step 4.

5.5.6 Low Air

Error messages Locking AIR SWITCH NOT OPEN or Locking AIR SWITCH NOT CLOSED indicate improper airflow through the boiler. Check the hoses leading to the air switches. Verify proper blower operation. An air switch error does not necessarily mean that the air switch is defective.

When AIR SWITCH NOT OPEN is shown on the display, check that the air switch is open when the fan is off. Check that there is no air flow through the boiler when the fan is off.

When AIR SWITCH NOT CLOSED is shown on the display, check that the air switch is closed when the fan is running. If the air switch does not close within 5 minutes during purge, the boiler locks out. Check that the burner is clean (refer to "Cleaning the Burner," Section 5.2) and that there are no obstructions to airflow in the intake or exhaust ducts.

5.5.7 Flame Failure

In the event of a flame failure, the main fuel valves are de-energized and a manual reset lockout occurs. Locking IGNITION FAILURE or Lockout FLAME FAILURE is shown on the display. The cause of flame failure must be diagnosed and repaired before the control is reset.

When IGNITION FAILURE is shown on the display, the boiler did not light during a trial for ignition. Check that the spark, electrode, ignition wire, and gas valve are functioning properly.

When FLAME FAILURE is shown on the display, the boiler lost the flame during run. Check that the combustion is setup properly (see section 3.11), the gas pressure is correct (see section 3.6), as well as other combustion parameters.

5.5.8 Flame Error

Flame error is indicated by Locking LATE FLAME or Blocking FALSE FLAME. This may be caused by a failed or leaky gas valve or a flame detector malfunction. If gas valve leakage is suspected, the unit must be isolated by turning off the main gas supply line. Qualified and knowledgeable service personnel must be called to evaluate and repair/replace the failed parts.

5.5.9 Blocked Flue

High exhaust back pressure is indicated by BLOCKED FLUE. The cause may be a blocked stack, a blocked air inlet, or a blocked condensate system. When the blockage is removed, the boiler will automatically restart.

5.5.10 Manual Reset Error Codes – A##

A Code	Error	Int. nr	Description
A01	IGNIT ERROR	1	Three unsuccessful ignition attempts in a row
A02	TOO MANY FLAME FAILURES	24	Three times flame was lost during on demand
A03	T MAX LOCK ERROR	18	Overheat stat is open
A05	GV RELAY ERROR	5	Problems with gas valve relay= internal hardware error (pump not running)
A06	SAFTEY RELAY ERROR	6	Problems with gas valve relay = internal hardware error (pump not running)
A09	RAM ERROR	9	Internal software error
A09	FLAG BYTE INTEGRITY ERROR	27	Internal software error
A09	AD HI CPL ERROR	28	Internal software error
A09	AD LO CPL ERROR	29	Internal software error
A09	REGISTER ERROR	33	Internal software error
A10	E2PROM ERROR	12	No communication with E2prom
A12	WRONG EEPROM SIGNATURE	10	Contents of Eprom is not up-to-date
A13	STATE ERROR	13	Internal software error
A14	ROM ERROR	14	Internal software error
A15	15MS XRL ERROR	16	Internal software error
A16	20 MS XLR ERROR	22	Internal software error
A18	STACK ERROR	19	Internal software error
A19	FLAME OUT TOO LATE ERROR	20	Flame still present 10 sec. after closing the gas valve
A20	FLAME ERROR I	21	Flame detected just before gas valve opened
A30	HIGH GAS PRESSURE ERROR	32	Gas pressure is to high
A31	LOW GAS PRESSURE ERROR	31	Gas pressure is to low
A32	41MS ERROR	23	Internal software issue
A33	FAN ERROR	8	Fan deviation more than 300 rpm longer than 1 minute (when fan speed > 4200 rpm this error is ignored)
A34	AIR PRESS SW NOT OPEN ERROR	25	Air pressure switch doesn't open within 30 seconds
A35	AIR PRESS SW NOT CLOSED ERROR	26	Air pressure switch doesn't close within 30 seconds
A37	UV SENSOR BROKEN	11	UV scanner not functioning
A38	MOD BACK DIFF ERROR	4	Large difference between return and flow temperatures
A39	RAPID RISE ERROR LOCK RET	15	Return temperature rise too rapidly
A40	RAPID RISE ERROR LOCK FLOW	7	Flow temperature rise to rapidly
A41	RAPID RISE ERROR LOCK HX	17	Heat exchanger rise to rapidly
A43	LOW WATER CUTOFF ERROR	30	Water pressure is to low
A44	FLAME CKT ERROR	34	Ionization (flame rod)wire lost for more than 15 seconds

NOTICE! When an Internal Error occurs, as identified above, the failure is internal to the ENVI® control and replacement of the ENVI® control is required. A qualified service technician must replace the ENVI® control.

5.5.11 Auto-reset Error Codes – E##

A Code	Error	Int. nr	Description
A01	IGNIT ERROR	1	Three unsuccessful ignition attempts in a row
A02	TOO MANY FLAME FAILURES	24	Three times flame was lost during on demand
A03	T MAX LOCK ERROR	18	Overheat stat is open
A05	GV RELAY ERROR	5	Problems with gas valve relay= internal hardware error (pump not running)
A06	SAFTEY RELAY ERROR	6	Problems with gas valve relay = internal hardware error (pump not running)
A09	RAM ERROR	9	Internal software error
A09	FLAG BYTE INTEGRITY ERROR	27	Internal software error
A09	AD HI CPL ERROR	28	Internal software error
A09	AD LO CPL ERROR	29	Internal software error
A09	REGISTER ERROR	33	Internal software error
A10	E2PROM ERROR	12	No communication with E2prom
A12	WRONG EEPROM SIGNATURE	10	Contents of Eprom is not up-to-date
A13	STATE ERROR	13	Internal software error
A14	ROM ERROR	14	Internal software error
A15	15MS XRL ERROR	16	Internal software error
A16	20 MS XLR ERROR	22	Internal software error
A18	STACK ERROR	19	Internal software error
A19	FLAME OUT TOO LATE ERROR	20	Flame still present 10 sec. after closing the gas valve
A20	FLAME ERROR I	21	Flame detected just before gas valve opened
A30	HIGH GAS PRESSURE ERROR	32	Gas pressure is to high
A31	LOW GAS PRESSURE ERROR	31	Gas pressure is to low
A32	41MS ERROR	23	Internal software issue
A33	FAN ERROR	8	Fan deviation more than 300 rpm longer than 1 minute (when fan speed > 4200 rpm this error is ignored)
A34	AIR PRESS SW NOT OPEN ERROR	25	Air pressure switch doesn't open within 30 seconds
A35	AIR PRESS SW NOT CLOSED ERROR	26	Air pressure switch doesn't close within 30 seconds
A37	UV SENSOR BROKEN	11	UV scanner not functioning
A38	MOD BACK DIFF ERROR	4	Large difference between return and flow temperatures
A39	RAPID RISE ERROR LOCK RET	15	Return temperature rise too rapidly
A40	RAPID RISE ERROR LOCK FLOW	7	Flow temperature rise to rapidly
A41	RAPID RISE ERROR LOCK HX	17	Heat exchanger rise to rapidly
A43	LOW WATER CUTOFF ERROR	30	Water pressure is to low
A44	FLAME CKT ERROR	34	Ionization (flame rod) wire lost for more than 15 seconds

6.0 PARTS/TECHNICAL SUPPORT

Spare parts and replacement parts can be ordered from Harsco Industrial, Patterson-Kelley by calling toll free (877) 728-5351. The fax number is (570) 476-7247. Technical information is also available at the above number and at the Harsco Industrial, Patterson-Kelley website www.harscopk.com.

WARNING

Use of Non-Factory Authorized replacement parts are not recommended for this equipment. All control components are engineered for safety and are designed to work in unison with each of the other components. Use of non-factory authorized replacement parts jeopardizes the functionality of the safety features as well as the performance of the boiler.

When ordering replacement parts please have the **model number** and **serial number** of your boiler available. Drawings showing boiler components are displayed on the following pages. Drawings specific to your particular boiler model can also be supplied by your local Harsco Industrial, Patterson-Kelley representative.

5.6 WIRING DIAGRAMS


5.6.1 Terminal Block Assignments – High Voltage (120 VAC) Circuit (TB2)

Terminal Number	Label	Description
1	120 VAC LINE	Boiler Supply Power, 120 VAC, 1 ph , 60 Hz
2	120 VAC NEUTRAL	Boiler Supply Neutral, 0 VAC
3	120 VAC NEUTRAL	Neutral for use with TB2-10, Switched Output
4	120 VAC NEUTRAL	Neutral for use with TB2-11, 3 Way Valve
5	120 VAC NEUTRAL	Neutral for use with TB2-12, DHW Pump Contactor
6	120 VAC NEUTRAL	Neutral for use with TB2-13, CIRC Pump Contactor
7	120 VAC NEUTRAL	Neutral for use with TB2-14, Damper Output
8	GROUND	Boiler Supply Ground, 0 VAC
9	GROUND	Boiler Supply Ground, 0 VAC
10	120VAC SW OUTPUT	120VAC output when boiler is switched on (pilot duty only)
11	120VAC 3 WAY VALVE	120VAC output during CH Mode. 3 way valve is normally closed (not powered) for DHW, and powered open for CH Mode.
12	120VAC DHW PUMP CNTR	120VAC output when boiler is in DHW Mode (pilot duty only)
13	120VAC CIRC PUMP CNTR	120VAC output when boiler is in CH Mode (pilot duty only)
14	120VAC DAMPER	120VAC output when boiler is enabled (pilot duty only)
15	MASTER ALARM RELAY	This circuit closes when the boiler is in an alarm state
16	MASTER ALARM RELAY	
17	FLAME DETECTED RELAY	This circuit closes when the boiler is firing
18	FLAME DETECTED RELAY	

5.6.2 Terminal Block Assignments – Low Voltage (Less than 32VAC) Circuit (TB1)


Terminal Number	Label	Description
1	ENABLE / DISABLE	Boiler Enable, Contact Closure. DO NOT ENERGIZE.
2	ENABLE / DISABLE	
3	EXTERNAL INTERLOCK	External Limit, Contact Closure. DO NOT ENERGIZE.
4	EXTERNAL INTERLOCK	
5	OUTDOOR TEMP SENSOR	Outdoor temperature sensor
6	OUTDOOR TEMP SENSOR	
7	DHW STAT OR SENSOR	Domestic Hot Water sensor or thermostat
8	DHW STAT OR SENSOR	
9	HEADER TEMP SENSOR	Header temperature sensor
10	HEADER TEMP SENSOR	
11	DHW FLOW SWITCH	Domestic Hot Water flow switch output
12	DHW FLOW SWITCH COMMON	DHW flow switch closes and indicates potable water flow/usage
13	0-10V ANALOG INPUT	Variable Input (VDC) for remote control of boiler (+)
14	0V ANALOG INPUT	0V for use with TB1-13 (-)
15	For Future Use	Not Used
16	For Future Use	
17	MODBUS COM 1A	Modbus connection to boiler
18	MODBUS COM 1B	
19	CASCADE A TO A	Cascade connection between boilers
20	CASCADE B TO B	

5.6.3 Wiring MACH® Boilers C750/900/1050




5.7 BOILER PARTS LIST

5.7.1 MACH® Boiler 750-900-1050 Main Assembly




Mark	Description
1	Heat Engine
2	Boiler Gas Train
3	Cabinet
4	Control Panel


5.7.2 Control Panel



Mark	Description
1	Control Panel Aluminum Door
2	Display Label
3	Display Cover
4	ENVI® Control Display Module
5	Circuit Breaker
6	On/Off Switch
7	ENVI® Control Interface Board
8	Low Water Cut-off
9	ENVI® Control Board
10	TB1 Low Voltage (right rear of boiler)
11	TB2 High Voltage (left rear of boiler)
12	Terminal Strips (w/dividers)




5.7.3 MACH® Boiler C750/900/1050 Heat Engine



Mark	Description
1	Gasket, Blower to Burner Hood
2	Burner Hood
3	Burner Hood Gasket
4	Burner
5	View Glass Assembly
6	Heat Exchanger Sectional Castings
7	Exhaust Gasket
8	Condensate Collector
9	Inspection Cover w/ gasket
10	Water Manifold Gaskets
11	Boiler Outlet
12	Boiler Inlet
13	Condensate Trap
14	Manifold Mounting Plate

5.7.4 MACH® Boiler C750/900/1050 Gas Train



Mark	Description
1	Main Gas Shut-off Valve
2	Low Gas Pressure Switch
3	High Gas Pressure Switch
4	Dual Main Gas Valve / Regulator
5	Gas Manifold Shut-off Valve
6	Flex Hose with Gas Valve Adaptor
7	Venturi
8	Premix Combustion Blower
9	Burner Hood
10	Burner

7 LIMITED WARRANTY

Subject to the terms and conditions herein, Harsco Industrial, Patterson-Kelley, Seller warrants to the original owner at the original installation site that products manufactured by Seller will be free from defects in materials and workmanship for a period of one (1) years from date of start up (the "Warranty Period"), provided that startup is completed within six months from the date of shipment. The heat exchanger and burner will be warranted for a period of five (5) years from the date of shipment (the "Warranty Period").

REMEDY

The sole remedy of this warranty is expressly limited to the repair or replacement of any part found to be defective under conditions of normal use within the Warranty Period. Installation is not included.

WARRANTY

The owner must notify the original installer of the Product and Seller (Attention: Harsco Industrial, Patterson-Kelley, 100 Burson Street, East Stroudsburg, PA 18301), in writing, within the Warranty Period, providing a detailed description of all claimed defects. Transportation to the factory or other designated facility for repairs of any products or items alleged defective shall, in all events, be the responsibility and at the cost of the owner.

EXCLUSIONS

Seller shall have no liability for and this warranty does not cover:

- A. Incidental, special or consequential damages, such as loss of the use of products, facilities or production, inconvenience, loss of time or labor expense involved in repairing or replacing the alleged defective Product.
- B. The performance of any Product under conditions varying materially from those under which such Product is usually tested under industry standards at of the time of shipment.
- C. Any damage to the Product due to abrasion, erosion, corrosion, deterioration, abnormal temperatures or the influence of foreign matter or energy.
- D. The design or operation of owner's plant or equipment or of any facility or system of which any Product may be made a part.
- E. The suitability of any Product for any particular application.
- F. Any failure resulting from misuse, modification not authorized by Seller in writing, improper installation or lack of or improper maintenance.
- G. Equipment furnished by the owner, either mounted or unmounted, or when contracted for by the owner to be installed or handled.
- H. Leakage or other malfunction caused by:
 - 1. Defective installations in general and specifically, any installation which is made:
 - a. in violation of applicable state or local plumbing housing or building codes,
 - b. contrary to the written instructions furnished with the unit
 - 2. Adverse local conditions in general and, specifically, sediment or lime precipitation in the tubes and/or headers or corrosive elements in the atmosphere.
 - 3. Misuse in general and, specifically, operation and maintenance contrary to the written instructions furnished with the unit, disconnection, alteration or addition of components or apparatus, not approved by Seller, operation with fuels or settings other than those set forth on the rating plate or accidental or exterior damage.
- I. Production of noise, odors, discoloration or rusty water.
- J. Damage to surrounding area or property caused by leakage or malfunction.
- K. Costs associated with the replacement and/or repair of the unit including: any freight, shipping or delivery charges, any removal, installation or reinstallation charges, any material and/or permits required for installation, reinstallation or repair, charges to return the boiler and or components. Seller's liability under this warranty shall not in any case exceed the amount paid for the Product found to be defective.

THIRD PARTY WARRANTIES

For goods or components not manufactured by Seller, the warranty obligations of Seller shall, in all respects, conform and be limited to one (1) year from the date of shipment.

SEVERABILITY

To the extent that any provision of this warranty would be void or prohibited under applicable law, such provisions shall be limited in effect to the minimum extent necessary to render the remaining provisions hereof enforceable.

NO OTHER WARRANTIES

Seller makes no implied warranty of merchantability or fitness for a particular purpose or other warranties with respect to any products or services except as expressly set forth in this limited warranty.

8 MACH® BOILER FIRE TEST REPORT



MACH® BOILER FIRE-TEST REPORT

Date: _____

Boiler Serial # _____ Model # _____

Installation: Name: _____ City: _____

State: _____ Zip: _____ Contact _____ Phone: _____

Installer Name: _____ Type of Installation: _____ (Hotel, School, etc.)

Fuel: Natural Gas _____ Propane _____

Outdoor Temperature Sensor Connected Yes: _____ No: _____

1. Factory Fire-Test : (copy from boiler label)

	<u>High</u>	<u>Low</u>
Inlet Gas	"w.c.	"w.c.
Oxygen (O2)	%	%
Carbon Dioxide (CO2)	%	%
Carbon Monoxide (CO)	ppm	ppm
Gross Stack Temp.	° F	° F

Field Fire-Test:

DATE: _____

	<u>High</u>	<u>Low</u>
Inlet Gas	"w.c.	"w.c.
Oxygen (O2)	%	%
Carbon Dioxide (CO2)	%	%
Carbon Monoxide (CO)	ppm	ppm
Nox	ppm	ppm
Gross Stack Temp.	° F	° F
Combustion Air Temp.	° F	° F
Stack Press.(exhaust)	"w.c.	"w.c.
Main Flame Signal	Yes/No	Yes/No
Efficiency	%	%
Comb. Air Pres. (intake)	"w.c.	"w.c.

2. Water Inlet temperature: ° F Water Outlet temperature: ° F
3. Flow through boiler: GPM
4. Operating Temperature Setpoint: ° F (from internal OR external control)
5. Stack Pressure (measured where stack exits boiler): "w.c. (High) "w.c. (Low)
6. Approximate stack lengths: Ft. Horizontal Ft. Vertical Flue Pipe Diameter
7. Incoming Electrical Power Volts a.c. Less than 1 volt between neutral and ground
8. Sytem Water pH level
9. Comments:


Performed by: _____
(Print Name)

Please return a copy to Harsco Industrial, Patterson-Kelley, ATTN: Boiler Technical Service
Harsco Industrial, Patterson-Kelley • 100 Burson Street • E. Stroudsburg, PA 18301
Phone: (570) 476-7261 • Fax: (570) 476-7247 • www.harscopk.com

[illegible]

APPENDIX 2 – MACH® BOILER ALTITUDE DERATE SCHEDULE

For installations over 2000 ft elevations, a de-rate schedule is applied. The boiler input rating must be reduced by 4% per 1000 ft above sea level, as illustrated using the following graph.



De-rate procedure is as follows:

With the boiler at high fire, adjust the gas valves (as described in section 3.10.4) to get 5% O₂ in the flue gas. If this cannot be achieved, perform the following steps:

- If the O₂% is too high, then the inlet gas pressure should be adjusted to the minimum pressure allowed, typically 5" w.c. The gas valve should be adjusted to obtain approximately 5% O₂. If the O₂% is still too high, the fan speed may be lowered. This procedure should only be performed by factory trained personnel.
- If the O₂% is too low, the gas valve settings should be reduced.

This procedure is also described in Bulletin 06-08.

Multi-Metal Systems Water Quality Standards

HARSCO Industrial, Patterson-Kelley boilers are designed to be incorporated into any multi-metal hydronic heating system. All multi-metal hydronic systems require that attention be paid to water treatment. The chemical additives for any multi-metal system must be specifically formulated for use with all the various metals used in that system.

Any closed, hydronic heating systems should include a meter, to monitor water addition to the recirculating loop, and a filter, pursuant to ASHRAE Standard 189.1 and the AWT Handbook. Water added to a closed hydronic system should not exceed more than 10% of the system volume per year and meter readings should be recorded, at least monthly, to ensure system losses are minimized and corrective actions shall be taken when needed.

Treatment programs for multi-metal systems should meet or exceed the following generally accepted best practices water quality guidelines:

1. Proper cleaning and surface preparation must be completed prior to system start-up.
2. pH must be maintained in a range that is appropriate for the metals contained in the system (see chart below).
3. Total Alkalinity between 100-500 ppm as CaCO_3 .
4. Filtration at or below 5 micron.
5. Total suspended solids below 10 ppm.
6. Corrosion inhibiting compounds to protect metals at or below:
 - a. Aluminum <0.25 MPY
 - b. Copper <0.1 MPY, soluble copper <0.25 ppm
 - c. Steel <3.0 MPY


According to ASTM D 2688
7. Addition of strong acids is not recommended.

Prior to initiating any treatment program, a water sample of the proposed fill water should be sampled for analysis. Once filled and bled of air, a pH neutral, industrial cleaner for use in multi-metal systems should be used to clean the entire hydronic system. Samples of the system water with cleaner should be taken and analyzed to ensure proper cleaner strength. Once cleaned, the system should be flushed with fresh (fill) water until the system water is within 100 micro Siemens in conductivity of the fresh water. When flushing is complete, a treatment program that is designed for use in that multi-metal system, after consideration of the metals it contains, must be used. Treatment programs should also comply with the standard water quality guidelines listed above.

Multi-Metal Systems with Aluminum	Multi-Metal Systems with Stainless Steel	Multi-Metal Systems with Copper
Proper surface cleaning required	Proper surface cleaning required	Proper surface cleaning required.
pH maintained between 6.0-8.5*	pH maintained between 7.0-9.5*	pH range may vary ***
Total Alkalinity 100-500 ppm as CaCO_3	Total Alkalinity 100-500 ppm as CaCO_3	Total Alkalinity 100-500 ppm as CaCO_3
Best Practices Filtration	Best Practices Filtration	Best Practices Filtration
Suspended solids below 10 ppm	Suspended solids below 10 ppm	Suspended solids below 10 ppm
Corrosion rates below: 0.1 MPY copper 3.0 MPY steel 0.25 MPY aluminum	Corrosion rates below: 0.1 MPY copper 3.0 MPY steel	Corrosion rates below: 0.1 MPY copper 3.0 MPY steel Max. MPY other metals
Addition of strong acid not recommended	Addition of strong acids not recommended	Addition of strong acids not recommended
<i>When freeze protection is required, automotive grade glycols are not recommended and decomposition products should be monitored and maintained below concentrations that present corrosive conditions. For existing boiler water systems, additional requirements and operational conditions may be required to mitigate pre-existing conditions.</i>		
* Other system components may have more restrictive ranges.		
**Copper has a broad range of acceptable pH and the other metallic components may require a tighter range		

MACH® Model C-1050

ENVI® Control



Service Clearances:

24" [610mm] Above

36" [914mm] Front

The MACH® Boiler requires category II venting (condensing-negative pressure) or category IV venting (condensing-positive pressure) as defined in ANSI Z223.1/NFPA 54/CSA-B.149 Latest Edition. Harsco Industrial, Patterson-Kelley reserves the right to make changes at any time without notification.

BOILER CONNECTIONS:

(A) Combustion Air Inlet	6" dia stub
(C) Condensate Drain	3/4"
(E) Exhaust Vent	200mm ID (8"nom ID)
(G) Main Gas Connection	1" NPT-F
(J) Wiring Junction Boxes	as marked
(P) Pressure Relief Valve	see list for selection
(R) Boiler Water Return, Victaulic® clamp	2" pipe, grooved
(S) Boiler Water Supply, Victaulic® clamp	2" pipe, grooved

Victaulic is a registered trademark of Victaulic Company, Easton, PA, USA

BOILER CONTROLS: ASME CSD-1 is standard.

Complies with GE GAP (IRI) guidelines GAP.4.1.0 and GAP.4.1.3.

Complies with FM Global 6-4/12-69 Section 1.0

Main Gas Train: see gas train submittal

Integrated Boiler Control, ENVI® Series

Operating Thermostat, 70°-195°F (21°-91°C)

High Limit Thermostat, Manual Reset, 100-200°F (38°-93°C)

High Exhaust Pressure Switch, Manual Reset

LWCO, Probe Type, Manual Reset

Air Switch, Differential Pressure Type

Combustion Blower, Variable Speed, 300 watt (0.4 hp)

C.S.A. CERTIFIED RATINGS AND CAPACITIES

Fuel	<input type="checkbox"/> Natural Gas(NG) <input type="checkbox"/> Propane(LP)
Input, BTU/hr	1,050,000
Output, BTU/hr	987,000
Boiler HP:	29.5
Maximum Inlet Gas Pressure:	14"w.c.
Minimum Inlet Gas Pressure:	3.5"w.c.

Electrical Requirements

120v, 1ph, 60hz

Total Operating Amps

less than 5 amps

Operating Weight

780 lbs.

Water Content

7.3 gallons

A.S.M.E. Section IV Design Data

Maximum Pressure	80 psig
Maximum Allowable Temperature	200°F
Maximum Operating Temperature	194°F
Heated Wet Surface Area:	25.69 sq.ft.
Flow rate @ 20°F ΔT	100 GPM
Flow rate @ 40°F ΔT	50 GPM

Pressure Relief Valve

Press/Temp Gauge

<input type="checkbox"/> 80 PSIG 3/4" x 1" (standard)	0-240psi/30-240°F
<input type="checkbox"/> 30 PSIG 1"	0-100psi/30-240°F
<input type="checkbox"/> 50 PSIG 3/4" x 1"	0-100psi/30-240°F
<input type="checkbox"/> 60 PSIG 3/4"	0-100psi/30-240°F
<input type="checkbox"/> 75 PSIG 3/4" x 1"	0-240psi/30-240°F

HARSCO
INDUSTRIAL
Patterson-Kelley