SILENT KNIGHT by Honeywell

Model IFP-100 Basic Operating Instructions

These Instructions must be framed and displayed next to the IFP-100 p
accordance with NFPA 72 fire code for Local Protected Fire Alarm Sy
Test the system in accordance to NFPA 72.

Reviewed for Code Compliance
Inspections Division
Approved with Conditions
Date: 06/08/17

Operation	Task to Perform
Silence Alarms and Troubles	Press SILENCE then enter a code if prompted. Silence LED will light.
Reset Alarms	Press RESET then enter a code if prompted.
Acknowledge Alarms and Troubles	Press ACK then enter a code if prompted. When the Alarm or Trouble is acknowledged an A will appear in the annunciator display as shown Below. TROUBLE: SMOKE-ION MODULE_33 POINT_1 [Z001] [M33:001] A MISSING 1 OF 1 Acknowledge Mark
View Alarms, Supervisories, and Troubles	For each type of condition press the ▽ or △ button associated for Alarms, Supervisories, or Troubles.
Conduct a Fire Drill	Press the DRILL button enter a code if prompted. or 1. Press ENTER to access Main Menu. 2. Then press 1 to select System Tests. 3. Enter code if prompted, then press 1 to select Fire Drill. 4. Press ENTER to start the fire drill. 5. Press ENTER to end the fire drill.
View a Point's Status	1. Press ENTER to access Main Menu. 2. Then press 2 to select Point Functions. 3. Enter code if prompted, then press 2 to select Point Status. 4. Select the module the device is located on by using the ▽ or △. Then press ENTER. 5. Enter the point number.
Check Detector Sensitivity	1. Follow steps 1 through 5 for viewing a point status. 2. Press ▷ to view detector sensitivity.
Set Time and Date	1. Press ENTER to access Main Menu. 2. Then press 4 to select Set Time & Date. Enter a code if prompted 3. Make changes in the fields on the screen as necessary. 4. Press ENTER if you wish to keep the changes. 5. Press ENTER to set the entered time and date.
Enable / Disable a Point	1. Rotate the key or enter a code to access to access Main Menu. 2. Press 2 to select Point Functions. 3. Press 1 for Disable / Enable Pt 4. Press 7 for Disable / Enable Pt. 5. Use the ▽ or △ to move through the list. Then press ENTER to select the module where the point you want to disable/enable is located 6. Enter the point or circuit number that you want to disable/enable. 7. Press ▷ key to toggle between NORMAL (enable) or DISABLE.
View Event History	1. Press ENTER to access Main Menu. 2. Press 3 to select Event History. 3. Press the ▽ or △ to view events in the history buffer.

P/N 151279 Rev. C

Cut Along the Dotted Line