
1. THE EROSION CONTROL MIX SHALL CONFORM TO THE FOLLOWING STANDARDS AND IN ACCORDANCE WITH THE MAINE DEP'S EROSION AND SEDIMENT CONTROL BMPS SECTION B-1:


- A. THE ORGANIC PORTIONS SHALL BE FIBROUS AND ELONGATED TO ALLOW FOR THE INTERLOCKING OF MATERIAL
- B. pH 5.0 8.0. PARTICLE SIZE BY WEIGHT SHALL BE 100% PASSING A 6" SCREEN AND A MINIMUM OF 70% TO A MAXIMUM
- 85% PASSING A 0.75" (3/4") SCREEN. D. THE ORGANIC MATTER CONTENT SHALL BE BETWEEN 80 AND 100% DRY WEIGHT BASIS
- NO STONES LARGER THAN 4" IN DIAMETER. LARGE PORTIONS OF SILTS, CLAYS OR FINE SANDS ARE NOT ACCEPTABLE IN THE MIX.
- 2. THE BERM SHOULD BE PLACED, UNCOMPACTED, ALONG A RELATIVELY LEVEL CONTOUR, WHEN NECESSARY THE BERM MAY BE PLACED PERPENDICULAR TO THE SLOPE ALONG THE PROPERTY LINE TO CONTAIN THE SEDIMENT PROVIDED A BERM IS LOCATED AT THE BASE OF THE SLOPE.

3. THE BERM MAY BE USED IN LIEU OF SILTATION FENCE, AT THE TOE OF SHALLOW SLOPES, ON FROZEN GROUND, LEDGE OUT CROPS, VERY ROOTED FORESTED AREA OR AT THE EDGE OF GRAVEL PARKING AREAS.


4. BERMS SHALL REMAIN IN PLACE UNTIL UPSTREAM AREA IS STABILIZED OR 90% CATCH OF VEGETATION IS ATTAINED. BERMS SHALL BE REMOVED OFFSITE OR BY SPREADING SUCH THAT NATIVE EARTH CAN BE SEEN BELOW.



EROSION CONTROL MIX BERM DETAIL NOT TO SCALE



SOIL FILTER CROSS SECTION



1. THE SIDESLOPES SHALL BE STABILIZED WITH A MIN. OF 4" LOAM, EROSION CONTROL BLANKETS SC150BN BY NORTH AMERICAN GREEN OR APPROVED EQUAL AND A CONSERVATION SEED MIX. THE BOTTOM OF THE VEGETATED UNDERDRAIN SHALL BE STABILIZED WITH EROSION CONTROL BLANKETS SC150BN BY NORTH AMERICAN GREEN OR APPROVED EQUAL AND A CONSERVATION SEED MIX

- 2. LIGHT COMPACTION SOIL FILTER AND PIPE BEDDING MATERIAL. (90 TO 92% STANDARD PROCTOR). TESTING SHALL BE PERFORMED BY A QUALIFIED MATERIAL TESTING FIRM.
- 3. THE SOIL FILTER MEDIA SHALL NOT BE CONSTRUCTED UNTIL THE AREA DRAINING TO THE BASIN HAS BEEN PERMANENTLY STABILIZED.
- 4. A LANDSCAPE DESIGNER OR ARCHITECT SHALL SELECT THE APPROPRIATE PLANTS FOR THE BIORETENTION CELL FOR THE SITE CONDITIONS. PLANTING PLAN BY OTHERS.
- 5. MINIMUM UNDERDRAIN SLOPE 0.0025.
- 6. TESTING: SIEVE ANALYSIS INCLUDING HYDROMETER TESTING FOR CLAY CONTENT FOR EACH LAYER SHALL BE PERFORMED BY A QUALIFIED SOIL TESTING LABORATORY AND SUBMITTED TO THE PROJECT ENGINEER FOR APPROVAL 2 WEEKS PRIOR TO CONSTRUCTION. ALL TESTING AND SUBMITTALS SHALL BE IN ACCORDANCE WITH THE MOST RECENT VERSION OF THE MAINE DEP - TECHNICAL DESIGN MANUAL SECTION 7.2.5 TESTING AND SUBMITTALS.
- 7. ACORN ENGINEERING, INC., RECOMMENDS THE SOIL FILTER LAYER BE SUPPLIED BY JONES ASSOCIATES, INC., AUBURN, ME.

6" LOAM TOPSOIL LAYER SPECIFICATION		
SIEVE SIZE	% PASSING BY WEIGHT	
#4	75-95	
#10	60-90	
#40	35-85	
#200	20-70	
1. CLAY FRACTION #200 SIEVE.*	<10% PASSING THE	

#200 SIEVE. LOAM SHALL BE LOOSE AND

FRIABLE AND SHALL BE FREE FROM ADMIXTURE OF SUBSOIL. REFUSE. LARGE STONES, CLODS OR ROOTS OR RHIZOMES OR "WITCH GRASS" OR OTHER UNDESIRABLE GRASSES. *<10% CLAY PASSING THE #200 SIEVE ALLOWED PER EMAIL FROM MARIANNE HUBERT - MDEP TO WILL

SAVAGE DATED 9/20/13

SOIL FILTER BED -UPERHUMUS OR EQUIV. SPECIFICATION SIEVE SIZE WEIGHT 100 #200 0-5 MINIMAL CLAY CONTENT, NO MORE THAN 3-5% PASSING #200 SIEVE

BLENDED SAND, SIEVE SIEVE SIZE #10 #20 #60 #200 8-15 CLAY FRACTION <2% PASSING THE . SUPERHUMUS OR EQUIVALENT


12" SOIL

RAIN GARDEN OR BIORETENTION CELL DETAIL

NOT TO SCALE

		SOIL FILTER BED — TRANSISTION ZONE (TYPE B)		
			SIEVE SIZE	% PASSING BY WEIGHT
FILTER BED — LOAM, SUPERHUMUS E ANALYSIS		1"	90-100	
			1/2"	75–100
			#4	50-100
	% PASSING BY WEIGHT		#20	15-80
	85-100		#50	0-15
	70-100		#200	0-5
	15-40			
	9_15		SOIL FILTER BED -	

SOIL FILTER BED — UNDERDRAIN BEDDING (TYPE C)		
SIEVE SIZE	% PASSING BY WEIGHT	
1"	100	
3/4"	90-100	
3/8"	0-75	
#4	0-25	
#10	0-5	




- US FOUNDRY COVER USF NO.

7621, OR APPROVED EQUAL

1. REFER TO THE REFER TO THE GRADING &

DRAINAGE PLANS AND UTILITY PLANS FOR

ADDITIONAL INFORMATION.



EROSION CONTROL BLANKET CHANNEL INSTALLATION

NOT TO SCALE

CHANNEL

INSTALLATION DETAIL 1.PREPARE SOIL BEFORE INSTALLING ROLLED EROSION CONTROL BLANKET (ECB), INCLUDING ANY NECESSARY APPLICATION OF LIME, FERTILIZER, AND


2.BEGIN AT THE TOP OF THE CHANNEL BY ANCHORING THE ECB IN A 6"(15CM) DEEP X 6"(15CM) WIDE TRENCH WITH APPROXIMATELY 12"(30CM) OF ECB EXTENDED BEYOND THE UP-SLOPÉ PORTION OF THE TRENCH. USE SHOREMAX MAT AT THE CHANNEL/CULVERT OUTLET AS SUPPLEMENTAL SCOUR PROTECTION AS NEEDED. ANCHOR THE ECB WITH A ROW OF STAPLES/STAKES APPROXIMATELY 12"(30CM) APART IN THE BOTTOM OF THE TRENCH. BACKFILL AND COMPACT THE TRENCH AFTER STAPLING. APPLY SEED TO THE COMPACTED SOIL AND FOLD THE REMAINING 12"(30CM) PORTION OF ECB BACK OVER THE SEED AND COMPACTED SOIL. SECURE ECB OVER COMPACTED SOIL WITH A ROW OF STAPLES/STAKES SPACED APPROXIMATELY 12"

APART ÁCROSS THE WIDTH OF THE ECB. 3.ROLL CENTER ECB IN DIRECTION OF WATER FLOW IN BOTTOM OF CHANNEL. ECB WILL UNROLL WITH APPROPRIATE SIDE AGAINST THE SOIL SURFACE. ALL ECB MUST BE SECURELY FASTENED TO SOIL SURFACE BY PLACING STAPLES/STAKES IN APPROPRIATE LOCATIONS AS SHOWN IN THE STAPLE PATTERN GUIDE.


4.PLACE CONSECUTIVE ECB END-OVER-END (SHINGLE STYLE) WITH A 4"-6" OVERLAP. USE A DOUBLE ROW OF STAPLES STAGGERED 4" APART AND 4" ON CENTER TO SECURE ECB. THE TOP LAYER SHALL GO OVER THE DOWNSTREAM LAYER. 5.FULL LENGTH EDGE OF ECB AT TOP OF SIDE SLOPES MUST BE ANCHORED WITH A ROW OF STAPLES/STAKES APPROXIMATELY 12"(30CM) APART IN A 6"(15CM) DEEP X 6"(15CM) WIDE TRENCH. BACKFILL AND COMPACT THE TRENCH AFTER

6.ADJACENT ECB MUST BE OVERLAPPED APPROXIMATELY 2"-5" (5-12.5CM) (DEPENDING ON ECB TYPE) AND STAPLED. 7.IN HIGH FLOW CHANNEL APPLICATIONS A STAPLE CHECK SLOT IS RECOMMENDED AT 30 TO 40 FOOT (9 -12M) INTERVALS. USE A DOUBLE ROW OF STAPLES STAGGERED 4"(10CM) APART AND 4"(10CM) ON CENTER OVER ENTIRE WIDTH OF THE CHANNEL.

8.THE TERMINAL END OF THE ECB MUST BE ANCHORED WITH A ROW OF STAPLES/STAKES APPROXIMATELY 12" (30CM) APART IN A 6"(15CM) DEEP X 6"(15CM) WIDE TRENCH. BACKFILL AND COMPACT THE TRENCH AFTER STAPLING.



SILTATION FENCE DETAIL NOT TO SCALE



1.PREPARE SOIL BEFORE INSTALLING ROLLED EROSION CONTROL PRODUCTS (ECB), INCLUDING ANY NECESSARY APPLICATION OF LIME, FERTILIZER, AND SEED.

2.BEGIN AT THE TOP OF THE SLOPE BY ANCHORING THE ECB IN A 6" DEEP X 6" WIDE TRENCH WITH APPROXIMATELY 12" OF ECB EXTENDED BEYOND THE UP-SLOPE PORTION OF THE TRENCH. ANCHOR THE ECB WITH A ROW OF STAPLES/STAKES APPROXIMATELY 12" APART IN THE BOTTOM OF THE TRENCH. BACKFILL AND COMPACT THE TRENCH AFTER STAPLING. APPLY SEED TO THE COMPACTED SOIL AND FOLD THE REMAINING 12" PORTION OF ECB BACK OVER THE SEED AND COMPACTED SOIL. SECURE ECB OVER COMPACTED SOIL WITH A ROW OF STAPLES/STAKES SPACED APPROXIMATELY 12" APART ACROSS THE WIDTH OF THE ECB.

3.ROLL THE ECB (A) DOWN OR (B) HORIZONTALLY ACROSS THE SLOPE. ECB WILL UNROLL WITH APPROPRIATE SIDE AGAINST THE SOIL SURFACE. ECB MUST BE SECURELY FASTENED TO SOIL SURFACE BY PLACING STAPLES/STAKES IN APPROPRIATE LOCATIONS AS SHOWN IN THE STAPLE PATTERN GUIDE.

4.THE EDGES OF PARALLEL ECB MUST BE STAPLED WITH APPROXIMATELY 2" - 5" OVERLAP DEPENDING ON THE

5.CONSECUTIVE ECB SPLICED DOWN THE SLOPE MUST BE END OVER END (SHINGLE STYLE) WITH AN APPROXIMATE 3" OVERLAP. STAPLE THROUGH OVERLAPPED AREA, APPROXIMATELY 12" APART ACROSS ENTIRE ECB WIDTH.

IN LOOSE SOIL CONDITIONS, THE USE OF STAPLE OR STAKE LENGTHS GREATER THAN 6" MAY BE NECESSARY TO PROPERLY SECURE THE ECB.

EROSION CONTROL BLANKET SLOPE INSTALLATION

NOT TO SCALE

PERMIT DRAWINGS NOT FOR CONSTRUCTION

HEIGHT MUNJOY 占

ISSUED FOR WORKSHOP #2

FINAL SUBMISSION

MAINE DEP MCGP

REVISION


REV. STANDARD DETAIL

STAFF COMMENTS

FILE: CIVIQ47DRAWINGS DATE: 7/11/13 302-001

SCALE: NTS DESIGN BY: WHS DRAWN BY: ZRJ

CHECKED BY: WHS



DRAWING NO.