



Block the dead corner for toe kick

Install BEP and WEP flush with cabinet doors