



NOTE: SPLICE SHALL OCCUR WITHIN MID 1/3 OF OVERALL BM SPAN. INSTALL BM SUCH THAT TOP FLANGE IS SNUG TO UNDERSIDE OF FLOOR DECK, TYP.

TYP W-BM FIELD SPLICE
N.T.S.

BECKER
structural engineers, inc.

75 York Street
Portland, ME 04101-4701
info@beckerstructural.com

Tel 207-879-1838
Fax 207-879-1822
www.beckerstructural.com

Designed	<i>NRM</i>
Drawn	<i>CHF</i>
Checked	<i>PBB</i>
Scale	<i>AS NOTED</i>
Date	<i>6/15/09</i>

*POWERPAY OFFICE
PORTLAND, ME*

Becker Job Number <i>2036</i>

SKS-12