

Objective: Secure the Windspire to the foundation with standard height locknuts.

Contents:

1. The Windspire utilizes updated parts to implement standard height locknuts to secure it to the foundation. This addendum should complement a unit installation with foundation studs that protrude 4.5" from the concrete surface.
2. Secure the bottom hinge plate to the foundation with four of the eight supplied standard $\frac{3}{4}$ -10 nylock nuts.
3. Add to the top of the four nylock nuts one metal washer, four rubber washers, then one more metal washer, as seen in the figure below.
4. Continue with normal installation, and after raising the Windspire, use one metal washer, one rubber washer, one metal washer, and then the remaining four standard height locknuts to secure the Windspire to the foundation studs.

