



**General Notes**

1. Remove all existing exterior signage from building face and windows
2. Remove all existing exterior lighting
3. Coordinate final location (including height off grade) of new knock box and storz connection with the Portland Fire Department