



NOTE 1: ATTACH TOP OF SHORING JACKS TO TEMP W8x28 TO PREVENT ACCIDENTAL FALLING OFF DURING CONSTRUCTION FOR SAFETY.

ARTHUR LIN CONSULTING ENGINEER	575 CONGRESS STREET MODIFICATION	CONSTRUCTION SHORING PLAN. SHEET 4 OF 5
-----------------------------------	-------------------------------------	---