

existing

bathroom

........  GENERAL NOTES

DEMOLITION: 1. REMOVE ALL NON-STRUCTURAL WALLS AS SHOWN.

2. REMOVE ALL ELEVATOR EQUIPMENT.

3. FLOOR AND CEILNG FINISHES IN NEW APARTMENTS TO BE DETERMINED BY OWNER.

4. ALL EXISTING PANELING ON BOTH SIDES OF STAIR 200 ENCLOSURE TO BE REMOVED EXPOSING EXISTING PLASTER, APPLY F1 FINISH OVER PLASTER.

5. ALL EXISTING OPENINGS TO STAIR 200 TO BE INFILLED, F1.

6. DIMENSIONS ARE FOR NEW PARTITIONS AND OPENINGS ONLY. OVERALL APARTMENT DIMENSIONS ARE FOR FIELD VERIFICATION. NOTIFY THE ARCHITECT OF ANY DISCREPANCIES BEFORE STARTING WORK.

7. DISCONNECT AND REMOVE ALL GAS PIPING.

James Sterling AIA Architect 142 High Street Portland, Maine

SHWARTZ BUILDING RENOVATIONS

FOURTH LEVEL



10 February 2010 revision: 19 April 2010 22 October 2010

