

## SECTION 07 26 16

## BELOW-GRADE VAPOR RETARDERS

## PART 1 - GENERAL

## 1.1 RELATED DOCUMENTS

- A. Drawings and general provisions of the Contract, including General and Supplementary Conditions and Division 01 Specification Sections, apply to this Section.

## 1.2 SUMMARY

- A. This Section includes the following:
  - 1. Vapor retarders under slabs-on-grade.

## 1.3 DEFINITIONS

- A. Vapor Retarder: Material with a water vapor transmission rating of not over 0.04g per square foot per hour.
- B. Vapor Barrier: Material with a water vapor transmission rating of not over 0.015g per square foot per hour.

## 1.4 SUBMITTALS

- A. Product Data: For each type of product indicated.
- B. Samples for Verification: 12 inch (300 mm) square units for each type of vapor retarder, vapor barrier, or air barrier indicated.

## 1.5 DELIVERY, STORAGE, AND HANDLING

- A. Protect materials from physical damage and from deterioration by moisture, soiling, and other sources. Store inside and in a dry location. Comply with manufacturer's written instructions for handling, storing, and protecting during installation.

## 1.6 PROJECT CONDITIONS

- A. Separate and recycle waste materials.

## PART 2 - PRODUCTS

## 2.1 MANUFACTURERS

- A. Available Manufacturers and Products: Subject to compliance with requirements, manufacturers offering products that may be incorporated into the Work include, but are not limited to, the following products listed in Part 2 of this Section.

## 2.2 VAPOR RETARDERS FOR UNDER SLABS

- A. Vapor Retarder for VCT and other moisture vapor sensitive flooring applications having the following qualities:
1. Minimum Permeance: ASTM E-96, not greater than 0.04 perms.
  2. Tensile Strength: ASTM E154 or D638, Class B – over 30 lbs/in.
  3. Puncture Resistance: ASTM E-154, Class C – over 475 grams.
  4. Water Vapor Barrier: ASTM E-1745, meets or exceeds Class C.
  5. Thickness of Barrier (Plastic) ACI 302.1R-96, not less than 10 mils.
- B. Available Products: Subject to compliance with requirements, products that may be incorporated into the Work include, but are not limited to, the following:
1. Stego Wrap, 10 mil thick vapor retarder by Stego Industries LLC, (877) 464-7834.
  2. Griffolyn Type-65 by Reef Industries.
  3. Vapor Block 10 by Raven Industries.
  4. MoistStop Ultra A by Fortifiber.
  5. Sealtight Perminator 10 mil Underslab Vapor-Mat by W.R. Meadows, Inc.
  6. Viper VaporCheck 10 by Insulation Solutions, Inc.
- C. Vapor-Retarder Tape (for slabs): Stego Warp red polyethylene tape or tape as recommended by the manufacturer.
- D. Double-Stick Edge Tape: Preformed 1-1/2" wide two-sided adhesive. Available products include "Fab Tape" by Reef Industries.

## PART 3 - EXECUTION

### 3.1 EXAMINATION

- A. Examine substrates and conditions, with Installer present, for compliance with requirements for Sections in which substrates and related work are specified and other conditions affecting performance.
- B. Proceed with installation only after unsatisfactory conditions have been corrected.

### 3.2 PREPARATION

- A. Clean substrates of substances harmful to vapor retarders, including removing projections capable of puncturing vapor retarders, or of interfering with attachment.

### 3.3 INSTALLATION, GENERAL

- A. Comply with manufacturer's written instructions applicable to products and application indicated.
- B. Extend retarders in thickness indicated to envelop entire area to be covered. Cut and fit tightly around obstructions. Remove projections that interfere with placement.

### 3.4 INSTALLATION OF UNDER-SLAB VAPOR RETARDERS

- A. Moisture vapor retarder system shall be installed at all interior floor slabs and as otherwise indicated in the drawings in strict accordance with the manufacturer's printed instructions and as follows:
  - 1. Snap chalk line along inside perimeter of foundation walls at top of slab elevation.
  - 2. Without wetting, clean a 3" wide band on the surface of the concrete below the chalk line at approximately mid-slab height. Remove dirt, residual form release, or other bond inhibiting surface contaminants. Grind smooth any surface projections within the band.
  - 3. While removing the contact paper on the backside, firmly press 2" wide double-stick edge tape onto wall, parallel to the chalk line on the cleaned band at mid-slab elevation.
  - 4. Remove contact paper on the face side.
  - 5. Apply a 12" wide strip of vapor retarder covering only the bottom 1" of contact surface on the edge tape. Cut, fit, and seal corner details with vapor retarder seaming tape.
  - 6. Align top edge of Iso-Strip isolation joint material to chalk line, and press material onto remaining 1" of exposed perimeter strip adhesive.
  - 7. Roll out vapor retarder material, overlapping edge rolls and all seams by 3". Tape all seams with vapor retarder seaming tape.
  - 8. All tears, punctures, etc. to be repaired and taped as required to maintain the watertight integrity of the vapor retarder system.

### 3.5 PROTECTION

- A. Protect installed vapor retarders from damage due to harmful weather exposures, physical abuse, and other causes. Provide temporary coverings or enclosures where vapor retarders are subject to abuse and cannot be concealed and protected by permanent construction immediately after installation.

END OF SECTION 07 26 16