



FOR REVIEW
02/25/2005

- ① RUN 2"V TIGHT UNDER COUNTER TOP TO WALL, THEN UP IN WALL TO ABOVE CEILING
- ② RUN 2"V IN WALL, OFFSET AROUND BEAM ABOVE CEILING

B9	KEY NOTES
NOT TO SCALE	

