



**REMOVALS KEYED NOTES**

- 1 REMOVE EXISTING METAL STUD FRAMED DRYWALL PARTITION. PREPARE ROUGH OPENING FOR PROPOSED DOOR WHERE SHOWN.
- 2 REMOVE EXISTING DOOR AND FRAME. SAVE HARDWARE FOR REUSE.
- 3 REMOVE HOLLOW METAL BORROWED LITE FRAME.
- 4 REMOVE EXISTING COUNTER. BASE CABINETS TO REMAIN.
- 5 REMOVE EXISTING COUNTER AND BASE CABINETS.
- 6 REMOVE EXISTING SHELVING.
- 7 REMOVE EXISTING SINK.
- 8 REMOVE EXISTING VCT FLOORING IN THIS SPACE. PREPARE CONCRETE SLAB FOR PROPOSED FLOORING.
- 9 REMOVE EXISTING CARPETING IN THIS SPACE.
- 10 REMOVE EXISTING ACT CEILING IN THIS SPACE.

- 11 REMOVE EXISTING VINYL BASE IN THIS SPACE. PREPARE DRYWALL FOR PROPOSED VINYL BASE.
- 12 REMOVE EXISTING CERAMIC TILE FLOORING IN THIS SPACE. GRIND FLOOR SMOOTH.
- 13 REMOVE EXISTING MEDICAL HEADWALL UNIT. DISCONNECT EXISTING OXYGEN, VACCUUM AND ELECTRICAL UTILITIES. SAVE UNIT FOR REUSE.
- 14 REMOVE EXIST 2 X 12 PROJECTED OAK WALL RAIL. PROVIDE WALL RETURNS WHERE SHOWN.
- 15 REMOVE EXIST WARDROBE OR TALL CABINET UNIT.
- 16 REMOVE EXIST OXYGEN AND VACCUUM OUTLETS.
- 17 REMOVE EXISTING GLASS / ALUMINUM SLIDING DOOR AND FRAME.
- 18 REMOVE EXISTING HPDL WARDROBE UNIT AND SAVE FOR REUSE.

- 19 REMOVE EXISTING COUNTER.
- 20 REMOVE CERAMIC TILE WALL FINISH. EXISTING GWB TO REMAIN.
- 21 REMOVE CABINET DOOR AND HINGES. CABINET TO REMAIN. PATCH CUP HINGE CUTOUTS IN CASE TO MATCH EXISTING.
- 22 REMOVE EXISTING CORNER GUARD.
- 23 REMOVE EXISTING TOILET. REMOVE WASTE AND CW PIPING TO MAINS AND CAP OFF. GRIND FLOOR SLAB AND PATCH TO MATCH EXIST.
- 24 REMOVE EXISTING MEDICAL HEADWALL UNIT. DISCONNECT EXISTING OXYGEN, VACCUUM AND ELECTRICAL UTILITIES. TURN UNIT AND PARTS OVER TO OWNER.
- 25 REMOVE EXISTING WALL PROTECTION OVERLAY WAINSCOTTING.

- 26 SAVE METAL VISION PANEL FRAME FOR REUSE. SAND SMOOTH AND SPRAY PAINT TO MATCH EXIST COLOR.
- 27 GRIND CONC SLAB IN THIS AREA. CUT 8 EMBEDDED BOLTS TO 1/2" BELOW FLOOR LINE. PATCH SLAB TO MATCH EXIST.
- 28 REMOVE EXIST HOT, COLD, WASTE AND VENT PIPING TO MAINS AND CAP OFF.
- 29 REMOVE EXIST MED GAS RAIL. SAVE FOR REUSE.
- 30 REMOVE EXIST ICE MAKER AND SODA DISPENSER. REMOVE WATER SUPPLY AND BACKFLOW PREVENTERS. SAVE FOR REINSTALLATION FOLLOWING COMPLETION OF KITCHEN COUNTER.
- 31 REMOVE RUBBER FLOORING IN THIS AREA. SAVE FOR PATCHING AND REUSE.

Richards Wing

Fifth Floor

Renovations

Maine Medical Center  
 Portland, Maine 04102

Architect  
 Winton Scott Architects, PA  
 Portland, Maine

Mechanical Design / Build  
 Johnson & Jordan  
 Portland, Maine

Removals Plan

D 1.1

Scale: 1/4" = 1' - 0"

August 28, 2009