



- ① REMOVE ALL INTERIOR NON BEARING WALLS IN HATCHED AREA AS INDICATED
- ② REMOVE EXISTING PLASTER AND LATH TO STUD WALL
- ③ REMOVE EXISTING PLASTER AND LATH TO CEILING JOIST
- ④ ALL ELECTRIC TO REMAIN. DE-ENERGIZE CIRCUIT BACK AT MAIN PANEL. SECURE LOOSE WIRING BACK INTO STUD WALL. CAP ALL OPEN ENDED WIRING. MAINE LICENSED ELECTRICIAN TO PARTIALLY REWIRE HOUSE UNDER SEPARATE PERMIT
- ⑤ MAINE LICENSED PLUMBER TO CAP AND DISCONTINUE ALL WASTE LINE TO BELOW FLOOR FOR FUTURE USE
- ⑥ MAINE LICENSED PLUMBER TO CAP AND DISCONTINUE ALL DOMESTIC WATER LINES FOR FUTURE USE
- ⑦ GAS COMPANY TO DISCONNECT GAS STOVE. CAP LINE FOR FUTURE USE.
- ⑧ CONTRACTOR TO REMOVE ALL APPLIANCES AND LAV FIXTURES STORE OR DISCARD AS PER OWNER'S INSTRUCTION
- ⑨ REMOVE ALL EXISTING MAPLE FLOORING. PREPARE DECK FOR NEW FLOORS
- ⑩ REMOVE WALL TO WALL CARPET IN ALL AREAS
- ⑪ REMOVE DOOR AND HARDWARE SAVE FOR RE-USE
- ⑫ REMOVE DOOR, FRAME AND TRIM SAVE FOR RE-USE PREP OPENING FOR NEW WALL INFILL
- ⑬ REMOVE STAIR FROM SECOND TO THIRD FLOOR
- ⑭ REMOVE SECTION OF EXISTING FLOOR FOR NEW STAIRWAY. FLUSH FRAME NEW LVL SUPPORTS AS SHOWN ON FRAMING PLAN