



## 7. DOOR AND SOLID END PANEL INSTALLATION

- Hold end panel at the top center with white inner surface facing inside of the shelter. Wrap the edges of the fabric panel around the end rib.
- Disconnect top rail from the end rib. Pass the top cross rail through the gap in the fabric, in between the webbing and rib frame. Re-attach top cross rail to end rib. Repeat Step B for side cross rails.
- At the bottom, where the webbing exits the pocket on each side of end panel, pull webbing to remove the slack. **Be careful not to pull the webbing through the other side of the webbing pocket.**
- Insert the "S"-Hook on ratchet into hole on the leg bend. Insert the webbing into the spindle of the ratchet and pull tight. Wind the ratchet so that the webbing overlaps itself.  
*Position the end panel so that it is centered on the building before fully tightening the end panel.*
- Tighten ratchets, alternating from one side to the other, until the end panel is centered and tight.  
**Zipper Door Panels: Zippers must be closed when tightening end panel.**

