

Notes:

- If Frost wall goes to over 4' a third row of #4 rebar will need to be added
   When frost walls have to be on ledge then the will need to be pinned and epoxied into the
- When frost walls have to be on ledge then they will need to be pinned and epoxied into the ledge useing a #6 rebar 24" long with 12" embeded into the ledge. Spaced a 24" OC.
   When footing need to be pinned, use #6 rebar 16" with 8" embeded and epoxied into the ledge.

Peter Pleong
Nickbocker Rd.
PEAKS ISLAND, MAINE
Foundation Detail

Scale:

1,-0,

Date:

Phase One Framing Plan Only

Sheet No.

Drawn By:

10/12/2013