

38. Longfellow

INSULATION :

- ① UNDER NEW CEMENT FLOOR - 2" STYROFOAM R-10
- ② WALLS OF NEW FOUNDATION - 2" STYROFOAM - R-10
- ③ RIM JOISTS - Spray foam - R10
- ④ EXTERIOR WALLS - 2x6 w/ dense PACK Cellulose
& 1" FOAM ON EXTERIOR - R-26
- ⑤ ALL CEILINGS R50 (Loose fill Cellulose)
- ⑥ ALL MEP Penetrations Air Sealed
- ⑦ ^{Proper} VENT Channels as needed
- ⑧ Soffit vent & RIDGE VENT ON NEW Addition Roof