

windows: existing sash + custom made flankers (marlin windows)

□ = 2"

side elevation of proposed window

