

This Installation Guideline is intended to give the installer a general overview on how to correctly install a Basement Egress Window, a Basement Egress Window Well and Window Well Cover. This Installation Guideline is not intended to replace the Manufacturer's Installation Instructions, but to supplement and expand on them. An Installer must follow the Manufacturer's Installation Instructions when ever they vary from these Guidelines to keep the Manufacturers Warranty Enforce.

Note:

1. It is the responsibility of the owner, architect, contractor and or builder to select products that comply with applicable, state and local building codes that is appropriate for the application and use. A building permit may be needed.
2. REDDCO Inc is not responsible for claims resulting from the failure of the contractor or homeowner to properly install or maintain the Egress Window, Window Well, and Cover.
3. Call your local diggers hotline before beginning excavation to avoid accidental contact with underground utility lines
4. Gutters, Down Spouts, Faucets on exterior walls, Sprinkler Heads and Sump Pump Outlets must be at least 6 to 10 feet away from the window well. All water must be directed away from the well to assure proper drainage.
5. Grading around the house must be sloped away from the Window Well at a slope of 1"per foot for proper drainage.

[View and Print Complete Installation Guidelines \(PDF\)](#)

[Related Links](#) [Testimonials](#) [Contact Us](#) [Sitemap](#)
Call us at (877) 788-9428

© 2014 Redi-Exit

This site created and powered on the web by
DN McMillan & Associates, Inc.