



1. Verify-in-Field (VIF) existing Anchor Bolts (A.B). Add additional expansion bolts ( $\frac{1}{2}$ "  $\phi$  typ.) such that there are a minimum of:
  - a) Two A.B. between window openings
  - b) One A.B. @ 4' o.c. at west foundation wall.

SK-3

WEST FOUNDATION WALL - ELEVATION