



Mount cabinets at 84" off finish floor.
Use 2 part molding to bring crown to ceiling.

Pull fridge cabinet & pantry cabinet forward to give fridge built in look.

All dimensions & size designations given are subject to verification on job site and adjustment to fit job conditions.

Lisa Clement
Interior Designer

This is an original design and must not be released or copied unless applicable fee has been paid or job order placed.

Designed: 1/24/2018
Printed: 1/24/2018

