

SHEET NOTES

AT BASE PLATES WITH SHEAR LUGS, USE LEVELING NUTS INSTEAD OF LEVELING PLATES. FOR 1"Ø RODS GROUT NEEDS TO BE 1 1/2" THICK TO ALLOW FOR ADJUSTMENT OF LEVELING NUTS.

Portland International Jetport

1001 Westbrook Street Portland, Maine 04102

Gensler

Suite 200 Washington, DC 20006 Telephone 202.721.5200 Facsimile 202.872.8587

2020 K Street, NW

343 Gorham Road, South Portland, ME 04106 P: (207) 761-1770 F: (207) 774-1246 www.oest.com engineers · architects · surveyors · construction managers

By Check __ 01 09/22/08 JDE --DESIGN DEVELOPMENT *--* 02 12/03/08 JDE --75% CONSTRUCTION DOCUMENTS <u>-- 03 01/23/09</u> JDE --95% CONSTRUCTION DOCUMENTS *--* 04 10/26/09 JDE --ISSUED FOR PERMIT

PWM Terminal Enhancement

Project Number 09.6395.000 CAD File Name

T: \5330101\SHEETS\S12.10.DWG FOUNDATION SECTIONS & DETAILS

AS NOTED

S12.10

©2009 Gensler