© 2015 Gensler

PATTERN NAME:STEPPIN OUT, 5T031

NOTE:SEE SHAW DIAGRAM FOR INSTALLATION