



ORDER OF INSTALLATION OF WATER PROOFING AT WINDOWS. WATER PROOFING AT STOREFRONT AND DOORS USE STEPS 1-3

- NOTES:
1. INSTALL AIR INFILTRATION BARRIER IN ORDER AS SHOWN BY NUMBERS.
2. IF APPLICABLE, LEAVE RELEASE PAPER ON LOWER HALF OF SILL FLASHING UNTIL FUTURE TIE-IN.
3. INSTALL FLASHING AND AIR INFILTRATION BARRIER TO FORM WATER SHEDDING LAPS
4. COORDINATE WITH FLASHING REQUIREMENTS OF WINDOW MANUFACTURER
5. FOLLOW MANUFACTURERS RECOMMENDATIONS FOR INSTALLATION.

1 ORDER OF INSTALLATION OF WATERPROOFING AT WINDOWS
3/8" = 1'-0"

