

## SECOND FLOOR

- NO RE-STRUCTURING
- TILE MASTER SHOWER
- REMOVE CHIMNEY AS PREVIOUS NOTES.
- OPEN UP DRYWALL AND NON-BEARING STUDS TO REMOVE BLOCKS CHIMNEY
- PATCH/REPAIR WALL WITH SAME DRYWALL AND STUD DESIGN.
- CHANGE DOOR SLABS + HARDWARE
- REPLACE OLD CARPET W/ NEW CARPET
- SMOKES / CARBON DET. ARE CURRENT HARDWIRES AND TO NATIONAL ELECTRIC CODE



SECOND FLOOR