

1. 3x STUDS AT ADJOINING PLY'WD PANEL EDGES. 2. 3x STUDS AND SILL PLATES. STAGGER PLY'WD PANEL EDGES. 3. 3x DF/L STUDS AND SILL PLATES. STAGGER PLY'WD PANEL EDGES.

4. 5/8" GYPSUM SHEATHING TO BE SECURED WITH 6d COOLER NAILS OR #6-1|" TYPE "W" OR "S" SCREWS DIRECTLY TO STUDS.

SHEARWALL SCHEDULE

CONNECTION

SHT'G. TYPE SHT'G. NAIL

INFO.

& THICKNESS

5. PLY'WD PANEL EDGES ARE TO BE STAGGERED TO FALL ON DIFFERENT FRAMING

6. NAILS ARE TO BE COMMON or HOT DIPPED GALVINIZED U.O.N.

7. 3x SILL PLATES REQUIRED AT FOUNDATION ONLY. SHEAR PANEL NOTES

* SHEAR VALUES ARE ADJUSTED FOR SPRUCE-PINE-FIR STUDS @ 16" oc U.O.N. * ALL APA SHEATHING SHEARWALLS TO BE BACKED WITH 2" NOMINAL OR WIDER

* WHEN APA RATED PANELS ARE INSTALLED TO BOTH SIDES OF WALL PANEL JOINTS OFFSET TO FALL ON DIFFERENT FRAMING MEMBERS. * NAILING NOT TO PENETRATE THE OUTER VENEER LAYER.

* WHEN USING A NAIL GUN, CONTRACTOR SHALL ENSURE THAT GUN IS SET TO INSTALL NAIL SLIGHTLY PROUD OF SURFACE BEING NAILED. NAIL SHALL THEN BE SET BY HAMMER. DO NOT ALLOW NAIL TO OVER PENETRATE WOOD SURFACE ESPECIALLY ON SHEARWALLS.

* ALL EDGES ON APA RATED PANELS TO BE BLOCKED TO MAINTAIN STRENGTH. * ALL PANELS LISTED MAY NOT BE USED ON ALL PROJECTS. REFER TO THE SHEARWALL LAYOUT PLANS FOR SIZE, TYPE AND LOCATION OF PANELS. * GYPSUM WALLBOARD LOAD IS REDUCED IN HIGH SEISMIC LOCATIONS.

* SEE DETAIL #14/S2.5 FOR STAPLES TO NAIL EQUIVALENT TABLE. * 7/16 OSB (PS2-92 GRADE) MAY BE USED IF APPLIED DIRECTLY TO FRAMING WHEN STUDS ARE SPACED A MAXIMUM OF 16" o.c. OR PANELS ARE APPLIED WITH LONG DIMENSION ACROSS STUDS. 15/32 OSB SHALL BE USED WHEN STUDS ARE SPACED A MAXIMUM OF 24" o.c.

* USE EITHER 16d NAILS OR 'LTP4' CLIPS WHEN SHT'G IS ATTACHED TO LOWER TOP * ALL ANCHOR BOLTS AT SHEARWALLS TO HAVE A 3x3x1/4 THICK PLATE WASHER.

> SEE S1.7 - S1.9b FOR ADDITIONAL FRAMING MEMBERS LOCATION AND INFORMATION.

SEE DETAIL 1 AND 3 ON S2.3 FOR ALLOWABLE BORING / NOTCHING OF MEMBERS.

> SHEARWALLS ARE FROM 2ND FLOOR TO 3RD FLOOR / LOWER ROOF HOLDOWNS ARE LOCATED AT 2ND FLOOR

DRAG STRUTS ARE LOCATED AT 2ND FLOOR

REVISED DATE 1 9/22/2015

> SHEET S0.3

8/28/2015

2ND FLOOR SHEARWALL PLAN 2ND FLOOR HOLDOWN PLAN

SHEARWALL TO

CONC. CONN.

ALL ANCHOR

BOLTS TO BE 1

ANCHOR

BOLT DIA.

6/S2.3 1/2" DIA. @ 48"

5/S2.6 5/8" DIA. @ 48"

6/S2.3 1/2" DIA. @ 36"

5/S2.6 5/8" DIA. @ 48"

ମ୍ବର/S2.3 |1/2" DIA. @ 24"

6/S2.6 5/8" DIA. @ 36"

6/S2.3 1/2" DIA. @ 10"

or or 5/8" DIA. @ 16"

₹6/S2.3 1/2" DIA. @ 8"

₹ 7/S2.6

1/2" DIA. @ 12"

5/8" DIA. @ 18"

1/2" DIA. @ 10"

5/8" DIA. @ 15" 1/2" DIA. @ 8" 5/8" DIA. @ 10" 1/2" DIA. @ 6"

& SPACING

SIDENCE, MAINE 04103 POR RETIREMEN 802 OCEAN AVE. PO