



FOUNDATION TIE-DOWN MUST BE CONNECTED ON-SITE BY POINT LOAD LOCATIONS AS NOTED (BY OTHERS). ALTERNATIVE TIE DOWN CONNECTION METHODS APPROVED BY A LOCAL ENGINEER MAY BE USED. REFER TO THE IRC FOR FOUNDATION TIE DOWN REQUIREMENTS FOR 100 MPH OR LESS WIND ZONES