



- ROOF NOTES:**
- 1) DESIGN LOAD: GROUND SNOW LOAD = SIXTY PSF.
 - 2) INSTALL WATERPROOF MEMBRANE AT VALLEYS AND ALONG EAVES.
 - 3) ROOF OVERHANGS = 4'-6" GABLE AND 12" SOFFIT.
 - 4) SEE BUILDING SECTIONS SHEET 3 FOR ADDITIONAL INFORMATION.

