

Solitaire™

15 X 15 Solitaire™ FRAME

We recommend :

- two people for set up,
- that you wear gloves,
- that whenever you assemble a tent with hardware at or above the shoulders, you wear a hard hat.

Our frame parts are color-coded for fast, easy set up.

LAY OUT THE PARTS:

Open the parts bags and separate and, using the drawing, organize the pieces of the frame on the ground. Start with the 4-way crown and the corner brackets.

RAFTERS:

Align the rafters [GREEN] to the 4-way crown and the corner brackets. Pin the rafters to the 4-way crown. Pin the other end of the rafters to the corner brackets .

PERIMETER:

Start at corner bracket and build the perimeter of the tent. Work clockwise and install the perimeter sections in sequence by connecting the perimeter tubing [RED] from one bracket to the next. Work your way around until the entire frame is complete.

Note. Raising the 4-way crown will help draw last corner together.

CANOPY TOP:

- Unroll the canopy onto a drop cloth. Lay the canopy out over the frame.
- Square the canopy on the frame. Check the corners, hip areas and crowns to make sure the top and frame are correct. Pull the canopy corner ropes to align the corners.

LEGS:

- Insert and connect each top leg section [BLACK] to a corner bracket — work clockwise around your tent.
- When complete, stand under the canopy and fasten the fabric in place by securing the straps and buckles around the perimeter of the frame. Snap the buckles together. Pull the straps to tighten and secure in place.
- Attach a foot plate to each leg of the tent and pin it in place.
- Stake each foot plate.

STAKES AND GUY ROPES:

We recommend that stakes, foot plates and optional guy ropes be used to secure the tent to the site.

SEE SCHEMATICS ON FOLLOWING PAGE.

To disassemble the Solitaire Frame Tent, reverse the above procedure.

Solitaire™

15 X 15

