

Panel: PP-2		Location: Service 109							
Amps/Mains:		K.A.I.C.:							
Volts / Phase:		Mounting:							
125A, MLO		22							
208/120V, 3φ		Flush							
Pos.	AMP	POLES	LOAD DESCRIPTION	Phase	Phase	Phase	POLES	AMP	Pos.
				A	B	C			
1	20	1	323						2
2	20	1	326						3
3	20	3	316						4
4	20	1							5
5	20	1							6
6	20	1							7
7	20	1	319						8
8	20	1	325						9
9	20	1	309						10
10	20	1	327						11
11	20	1	340B						12
12	20	1	340A						13
13	20	1	315A						14
14	20	1	328						15
15	20	1	335						16
16	20	1							17
17	20	2							18
18	20	1							19
19	20	1							20
20	20	1							21
21	20	1	Shunt-Trip						22
22	20	1	449						23
23	20	1	435						24
24	20	1	Spare						25
25	20	1	Spare						26
26	20	1	Spare						27
27	20	1	Spare						28
28	20	1	704						29
29	20	1	115						30
30	20	1	704						31
31	20	1	704						32
32	20	1	KEF-3						33
33	20	1	346						34
34	20	1	Shunt-Trip						35
35	20	1	Spare						36
36	20	1	Spare						37
37	20	1	Spare						38
38	20	1	Spare						39
39	20	1	Spare						40
40	20	1	Spare						41
41	20	1	Spare						42
42	20	1	Spare						43

Panel: PP-3		Location: Service 109							
Amps/Mains:		K.A.I.C.:							
Volts / Phase:		Mounting:							
125A, MLO		22							
208/120V, 3φ		Flush							
Pos.	AMP	POLES	LOAD DESCRIPTION	Phase	Phase	Phase	POLES	AMP	Pos.
				A	B	C			
1	20	1	709A						2
2	20	1	701						3
3	20	1	713						4
4	20	1	703A						5
5	20	1	717						6
6	20	1	703B						7
7	20	1	101B						8
8	20	1	444						9
9	20	1	103						10
10	20	3	055A						11
11	20	1	056B						12
12	20	1							13
13	20	3	Door Openers						14
14	20	1	095C						15
15	20	1	095C						16
16	20	1	095C						17
17	20	1	095C						18
18	20	1	095C						19
19	20	3							20
20	20	1							21
21	20	1							22
22	20	1							23
23	20	1							24
24	20	1							25
25	20	1	028B						26
26	20	1	820A						27
27	20	1	318						28
28	20	1	720A-B						29
29	20	1							30
30	20	1	Spare						31
31	20	1	Spare						32
32	20	1	Spare						33
33	20	1	Spare						34
34	20	1	Spare						35
35	20	1	Spare						36
36	20	1	Spare						37
37	20	1	Spare						38
38	20	1	Spare						39
39	20	1	Spare						40
40	20	1	Spare						41
41	20	1	Spare						42
42	20	1	Spare						43

Panel: PP-4		Location: Corr. 121							
Amps/Mains:		K.A.I.C.:							
Volts / Phase:		Mounting:							
125A, MLO		22							
208/120V, 3φ		Flush							
Pos.	AMP	POLES	LOAD DESCRIPTION	Phase	Phase	Phase	POLES	AMP	Pos.
				A	B	C			
1	20	3	625						2
2	20	3	644						3
3	20	1	644						4
4	20	3	615A						5
5	20	3							6
6	20	3							7
7	20	3							8
8	20	3							9
9	20	3							10
10	20	3							11
11	20	3							12
12	20	3							13
13	20	3							14
14	20	3							15
15	20	3							16
16	20	3							17
17	20	3	601						18
18	20	3							19
19	20	3							20
20	20	3							21
21	20	3							22
22	20	1							23
23	20	1							24
24	20	1							25
25	20	1	605						26
26	20	1	624B						27
27	20	1	514A						28
28	20	2							29
29	20	2							30
30	20	1							31
31	20	1	627						32
32	20	1							33
33	20	1	570						34
34	20	1	Big Lights						35
35	20	1							36
36	20	3							37
37	20	3							38
38	20	3							39
39	20	3							40
40	20	1							41
41	20	1							42
42	20	1							43

Panel: GL-1		Location: Electrical 211							
Amps/Mains:		K.A.I.C.:							
Volts / Phase:		Mounting:							
125A, MLO		22							
208/120V, 3φ		Surface							
Options:		3P-SN contactor, 120V control							
Pos.	AMP	POLES	LOAD DESCRIPTION	Phase	Phase	Phase	POLES	AMP	Pos.
				A	B	C			
1	20	1	Sales Floor						2
2	20	1	Sales Floor						3
3	20	1	Alleles						4
4	20	1	Alleles						5
5	20	1	Sales Floor						6
6	20	1	Sales Floor						7
7	20	1	Registers						8
8	20	1	Sales Floor						9
9	20	1	Sales Floor						10
10	20	1	Specialty/Bakery						11
11	20	1	Sales Floor						12
12	20	1	Sushi/Pizza						13
13	20	1	Sales Floor						14
14	20	1	Conditon/Laws						15
15	20	1	Sales Floor						16
16	20	1	Sales Floor						17
17	20	1	Sales Floor						18
18	20	1	Sales Floor						19
19	20	1	Sales Floor						20
20	20	1	Sales Floor						21
21	20	1	Sales Floor						22
22	20	1	Sales Floor						23
23	20	1	Sales Floor						24
24	20	1	Sales Floor						25
25	20	1	#REF!						26
26	20	1	#REF!						27
27	20	1	Sales Floor						28
28	20	1	Sales Floor						29
29	20	1	Sales Floor						30
30	20	1	Sales Floor						31
31	20	1	Sales Floor						32
32	20	1	Sales Floor						33
33	20	1	Sales Floor						34
34	20	1	Sales Floor						35
35	20	1	Spare						36
36	20	1	Spare						37
37	20	1	Spare						38
38	20	1	Spare						39
39	20	1	Spare						40
40	20	1	Spare						41
41	20	1	Spare						42
42	20	1	Spare						43

Panel: GL-2 (A)		Location: Electrical 211							
Amps/Mains:		K.A.I.C.:							
Volts / Phase:		Mounting:							
125A, MLO		22							
208/120V, 3φ		Surface							
Options:		3P-SN contactor, 120V control							
Pos.	AMP	POLES	LOAD DESCRIPTION	Phase	Phase	Phase	POLES	AMP	Pos.
				A	B	C			
1	20	1	Sales Floor Track						2
2	20	1	Sales Floor Track						3
3	20	1	Sales Floor Track						