



BASEMENT/FOUNDATION PLAN
 NOTES: SCALE 1/4"=1'-0"
 1. VERIFY ALL EXISTING CONDITIONS IN FIELD, CONTACT SI, INC IF CONDITIONS IN FIELD DO NOT MATCH PLAN
 2. IF MEMBER IS NOT INDICATED AS <E>, <N> OR <R> MEMBER IS TO BE CONSIDERED A NEW, <N>, MEMBER
 3. SEE ARCH. FOR DIMENSIONS AND ELEVATIONS OF NEW FLOOR PLANS

FRAMING PLAN SYMBOLS KEY	
□	WOOD POST
⊗	NUMBER OF WOOD STUDS IN POST BELOW
△	COLUMN ABOVE THIS LEVEL
△	COLUMN CONTINUOUS THROUGH THIS LEVEL
←	TRUSS OR JOIST BEARING
—	FLUSH FRAMED JOIST BEARING WITH HANGER
—	INDICATES OVER FRAMING, SEE PLAN
—	WOOD STUD BEARING WALL BELOW
—	SHEAR WALL
—	NUMBER OF TRIM STUDS UNDER HEADER
—	NUMBER OF KING STUDS ADJACENT TO HEADER
<E>	INDICATES EXISTING MEMBER TO REMAIN
<N>	INDICATES NEW MEMBER
<R>	INDICATES EXISTING MEMBER TO BE REMOVED

