



Notes

- 1) All conduit must be water tight and pitched downward to allow condensation to drain away from motor conduit box, therefore, do not run the conduit through the fan deck.
- 2) All wiring must conform to local and national electrical codes. Junction box/safety switch and all conduit from fan motor conduit box to be sized, provided and installed by others.
- 3) Rigid conduit outside casing panel must turn down to junction box.
- 4) On multi-cell units, use separate conduit lines for each fan motor. Run conduit through adjacent cell to junction box and/or disconnect switch.

ORDER NO: **U150762301**

DATE: **3/6/2015 1:19:51 PM**



**BALTIMORE
AIRCOIL COMPANY**

**Motor and Conduit Location
Single Fan Standard Motor System**

DRAWING NUMBER:
ML-U150762301