

TYPICAL FLEXIBLE CONNECTION DETAIL / NO SCALE




TYPICAL ELBOW DETAIL NO SCALE




DUCT TO GRILLE/REGISTER CONNECTION


NO SCALE (TYP. FOR ALL GRILLE/REGISTERS)



DIFFUSER CONNECTION








BALANCING DAMPERS SHALL BE PROVIDED AS SHOWN IN ADDITION TO THOSE INDICATED ON THE PLANS.

BRANCH CONNECTION DETAILS


NO SCALE
















** LOCATE AIR VENT VALVES ABOVE CEILING EXCEPT WHERE INACCESSABLE OR EXPOSED PIPING LOCATE IN UNIT CABINET

* THE FLOW CONTROL BALANCING VALVES SHALL BE INSTALLED BY THE CONTRACTOR CONFORMING WITH VALVE MFGR'S RECOMMENDED SPACING UP/DOWNSTREAM FROM PIPE CHANGES IN DIRECTION AND/OR OTHER VALVES/COMPONENTS IN THE PIPING.

UP FEED HOT WATER FINTUBE PIPING DETAIL NO SCALE

ISSUE DATE
10/25/1
SHEET SCALE
NTS

M500