SECTION 237200 - AIR-TO-AIR ENERGY RECOVERY EQUIPMENT

PART 1 - GENERAL

1.1 RELATED DOCUMENTS

- A. Drawings and general provisions of the Contract, including General and Supplementary Conditions and Division 1 Specification Sections, apply to this Section.
- B. Alternate #6: Refer to Section 012300 "Alternates".

1.2 SUMMARY

A. Section Includes: Packaged Energy Recovery Units – Fixed Plate Enthalpic

1.3 SUBMITTALS

- A. Product Data: For each type of product indicated. Include rated capacities, furnished specialties, and accessories.
- B. Detail equipment assemblies and indicate dimensions, weights, loads, required clearances, method of field assembly, components, and location and size of each field connection.
- C. Wiring Diagrams: For power, signal, and control wiring.
- D. Operation and Maintenance Data: For air-to-air energy recovery equipment to include in maintenance manuals.

1.4 QUALITY ASSURANCE

- A. Electrical Components, Devices, and Accessories: Listed and labeled as defined in NFPA 70, by a qualified testing agency, and marked for intended location and application.
- B. ARI Compliance: Capacity ratings for air-to-air energy recovery equipment shall comply with ARI 1060, "Rating Air-to-Air Energy Recovery Equipment."
- C. ASHRAE Compliance:
 - 1. Applicable requirements in ASHRAE 62.1-2004, Section 5 "Systems and Equipment" and Section 7 "Construction and Startup."
 - 2. Capacity ratings for air-to-air energy recovery equipment shall comply with ASHRAE 84, "Method of Testing Air-to-Air Heat Exchangers."
- D. UL Compliance: UL 1812.

PART 2 - PRODUCTS

2.1 PACKAGED ENERGY RECOVERY UNITS – FIXED PLATE ENTHALPIC

- A. Manufacturers: Subject to compliance with requirements, provide products by one of the following:
 - 1. Mitsubishi Electric Sales Canada Inc.
 - 2. RenewAire LLC.

B. Quality Assurance

- 1. The energy recovery cores used in these products shall be third party Certified by AHRI under its Standard 1060 for Energy Recovery Ventilators. AHRI published certifications shall confirm manufacture's published performance for airflow, static pressure, temperature and total effectiveness, purge air (OACF) and exhaust air leakage (EATR). Products that are not currently AHRI Certified will not be accepted.
- 2. Manufacturer shall be able to provide evidence of independent testing of the core by Underwriters Laboratory (UL), verifying a maximum flame spread index (FSI) of 25 and a maximum smoke developed index (SDI) of 50 thereby meeting NFPA 90A and NFPA 90B requirements for materials in a compartment handling air intended for circulation through a duct system. The method of test shall be UL Standard 723.
- 3. Unit shall be Listed under UL 1812 Standard for Ducted Air to Air Heat Exchangers. Some exceptions to UL Listing may apply. Units intended for "Outdoor Use" shall be listed using the specific UL requirements for rain penetration, corrosion protection and seal durability and shall be so labeled.
- 4. The ERV core shall be warranted to be free of manufacturing defects and to retain its functional characteristics, under circumstances of normal use, for a period of ten years from the date of purchase. The balance-of-unit shall be warranted to be free of manufacturing defects and to retain its functional characteristics, under circumstances of normal use, for a period of two years from the date of purchase.

C. Performance

- 1. Energy Transfer: The ERV shall be capable of transferring both sensible and latent energy between airstreams. Latent energy transfer shall be accomplished by direct water vapor transfer from one air stream to the other, without exposing transfer media in succeeding cycles directly to the exhaust air and then to the fresh air.
- 2. Passive Frost Control: The ERV core shall perform without condensing or frosting under normal operating conditions (defined as outside temperatures above -10°F and inside relative humidity below 40%). Occasional more extreme conditions shall not affect the usual function, performance or durability of the core. No condensate drains will be allowed.
- 3. Continuous Ventilation: Unit shall have the capacity to operate continuously without the need for bypass, recirculation, pre-heaters, or defrost cycles under normal operating conditions.
- 4. Positive Airstream Separation: Water vapor transfer shall be through molecular transport by hydroscopic resin and shall not be accomplished by "porous plate" mechanisms. Exhaust and fresh airstreams shall travel at all times in separate passages, and airstreams shall not mix.
- 5. Laminar Flow: Airflow through the ERV core shall be laminar over the products entire operating airflow range, avoiding deposition of particulates on the interior of the energy exchange plate material.

D. Construction

- 1. The energy recovery component shall be of fixed-plate cross-flow construction, with no moving parts.
- 2. No condensate drain pans or drains shall be allowed and unit shall be capable of operating in both winter and summer conditions without generating condensate.
- 3. The unit case shall be constructed of G90 galvanized, 20-gauge steel, with lapped corners and zinc plated screw fasteners. The unit roof shall be one piece or have watertight standing seam joints and shall overlap wall panels and doors in order to positively shed water.
- 4. Access doors shall provide easy access to blowers, ERV cores, and filters. Doors shall have an airtight compression seal using closed cell foam gaskets rated for outdoor exposure. Pressure taps, with captive plugs, shall be provided allowing cross-core pressure measurement allowing for accurate airflow measurement.
- 5. Case walls and doors shall be insulated with 1 inch, 4 pound density, foil/scrim faced, high-density fiberglass board insulation, providing a cleanable surface and eliminating the possibility of exposing the fresh air to glass fibers, and with minimum R-value of 4.3 (hr·ft2·°F/BTU).
- 6. The ERV cores shall be protected by a MERV-8 rated, 2" nominal, pleated, disposable filter in both airstreams.
- 7. Unit shall have single-point power connection and a single-point 24 VAC contactor control connection
- 8. Blower motors shall be Premium Efficiency, EISA compliant for energy efficiency. The blower motors shall be totally enclosed (TEFC) and shall be supplied with factory installed VFD's.
- 9. Blowers shall be quiet running, belt drive. Belt drive motors shall be provided with adjustable pulleys and motor mounts allowing for blower speed adjustment, proper motor shaft orientation and proper belt tensioning.
- 10. The unit electrical box shall include a factory installed, non-fused disconnect switch and a 24 VAC, Class II transformer/relay package.
- E. Options:
 - 1. Provide unit and duct connection orientation per the plans.
 - 2. Provide factory installed disconnect fuses.
 - 3. Provide factory installed Variable Frequency Drives allowing either preset or variable speed operation with appropriate 0-10 volt DC or DDC control signal.
 - 4. Provide factory installed isolation dampers for both air streams. The insulated dampers shall be of a low leakage design and shall not restrict the airstream, reducing airflow, in any way. The dampers shall be opened with a motor actuator powered by the standard unit transformer package and have a spring return for low off- position power consumption.

PART 3 - EXECUTION

3.1 EXAMINATION

A. Examine areas and conditions, with Installer present, for compliance with requirements for installation tolerances and other conditions affecting performance of the Work.

- B. Examine casing insulation materials and filter media before air-to-air energy recovery equipment installation. Reject insulation materials and filter media that are wet, moisture damaged, or mold damaged.
- C. Examine roughing-in for electrical services to verify actual locations of connections before installation.
- D. Proceed with installation only after unsatisfactory conditions have been corrected.
- E. Locate and orient unit to provide the shortest and most straight duct connections. Provide service clearances as indicated on the plans. Locate units distant from sound critical occupancies.

3.2 INSTALLATION

- A. Install units with clearances for service and maintenance.
- B. Suspend and brace units from structural-steel support frame using threaded steel rods and spring hangers.
- C. Install new filters at completion of equipment installation and before testing, adjusting, and balancing.

3.3 CONNECTIONS

- A. Comply with requirements for ductwork specified in Division 23 Section "Ductwork."
- B. Install piping adjacent to machine to allow service and maintenance.

3.4 FIELD QUALITY CONTROL

- A. Test and Balancing: Test and Balancing may not begin until 100% of the installation is complete and fully functional.
- B. Manufacturer's Field Service: Engage a factory-authorized service representative to inspect, test, and adjust components, assemblies, and equipment installations, including connections.
- C. Perform tests and inspections.
- D. Inspect components, assemblies, and equipment installations, including connections, for conformance with manufacturer's installation manual.
- E. Tests and Inspections:
 - 1. Operational Test: After electrical circuitry has been energized, start units to confirm proper motor rotation and unit operation.
 - 2. Test and adjust controls and safeties. Replace damaged and malfunctioning controls and equipment.
 - 3. Set field-adjustable switches and circuit-breaker trip ranges as indicated.

AIR-TO-AIR ENERGY RECOVERY EQUIPMENT

- F. Air-to-air energy recovery equipment will be considered defective if it does not pass tests and inspections.
- G. Prepare test and inspection reports.

3.5 DEMONSTRATION

A. Engage a factory-authorized service representative to train Owner's maintenance personnel to adjust, operate, and maintain air-to-air energy recovery units.

END OF SECTION 237200