






3. ASSEMBLE LEGS & ATTACH TO ROOF FRAME *Use bolts as shown in illustrations.*

- Assemble Corner and Middle legs.
- Attach legs with bolts on one side of roof frame, let the other side of roof frame rest on the ground.
- Attach remaining legs with bolts to opposite side of roof frame.



4. ASSEMBLE COVER RAILS

- Place the cover rail (13344, 13345) at each leg and secure it at each leg with a cover clamp as shown below.
- Slide the cover rails so they are 8" up from the ground and **hand tighten bolts on clamps.**

