## **SEQUENCE OF OPERATION MATRIX**

	Alarm Signal to Can.	Alarm Signal to Fire 5	Radio Master Box Activate Exter:	Annunciate at F.	m Acivate Evac.	Record Event	Supervisory Signal	Trouble Signal to Central Station Dicition Signal to Communicator (DACT)	Station via Communicator (DACT)
System Inputs	Α	В	С	D	E	F	G	Н	System Inputs
System Waterflow	х	х	х	х	х	х			System Waterflow
System Tamper Switch				х			х		System Tamper Switch
Manual Pull Station	х	х	х	х	х	х			Manual Pull Station
Area Smoke Detector	х	x	х	x	х	х			Area Smoke Detector
Area Heat Detector	х	х	х	х	х	х			Area Heat Detector
Fire Alarm - AC Failure				х				х	Fire Alarm - AC Failure
Fire Alarm - Low Battery				х				х	Fire Alarm - Low Battery
Signal Line Open Circuit				х				х	Signal Line Open Circuit
Signal Line Ground Fault				x				х	Signal Line Ground Fault
Horn/Strobe Circuit Open				х				х	Horn/Strobe Circuit Open
Horn/Strobe Circuit Ground				х				х	Horn/Strobe Circuit Ground
System Ground Fault				х				х	System Ground Fault
	Α	В	С	D	Е	F	G	Н	