

1 ALARM

ALARM

↓

2 DISPLAY

CURRENT NUMBER OF TIME MESSAGES EVENT TIME

14:55:18	M:001	10:23
1ST FIRE ALARM		407
4 FL SPRINKLER VALVE		
MAINT ROOM M400		

EVENT TYPE EVENT MESSAGE ZONE NUMBER

↓

2A OPTIONAL LED DISPLAY

LOCATION

↓

3 LOCAL SILENCE

↓

4 ALARM REVIEW

ALARM

LED LEGEND

- = OFF
- ★ = ON STEADY
- ★/★ = FLASH

FIRE ALARM

1 AC POWER

6 ALARM

5 SUPERVISORY

3 TROUBLE

2 MONITOR

2A REVIEW

4 ALARM

6 SYSTEM RESET

5 ALARM SILENCE

RESET

ALARM SILENCE

DRILL

DISABLE

GND FAULT

CPU FAIL

TEST

ZONE 1

ZONE 16

STATUS

PROGRAM

ENABLE

DISABLE

ACTIVATE

RESTORE

REPORTS

TEST

OPTIONAL

UOPS2.CDR

(written instructions on opposite page)