

1 SUPERVISORY CONDITION

SUPERVISORY =

↓

2 DISPLAY

CURRENT TIME	NUMBER OF MESSAGES	EVENT TIME
14:55:18	A:001	10:23
SUPERVISORY		407
4 FL SPRINKLER VALVE		
MAINT ROOM M400		

EVENT TYPE	EVENT MESSAGE	ZONE NUMBER

↓

3 LOCAL SILENCE

↓

4 SUPERVISORY REVIEW

SUPVR

4TH (MOST RECENT) MSG.

3RD SUPERVISORY MESSAGE

2ND SUPERVISORY MESSAGE

1ST (EARLIEST) SUPERVISORY MESSAGE

SUPVR

4TH (MOST RECENT) MSG.

3RD SUPERVISORY MESSAGE

2ND SUPERVISORY MESSAGE

1ST (EARLIEST) SUPERVISORY MESSAGE

SUPVR

4TH (MOST RECENT) MSG.

3RD SUPERVISORY MESSAGE

2ND SUPERVISORY MESSAGE

1ST (EARLIEST) SUPERVISORY MESSAGE

SUPERVISORY CONDITION

LED LEGEND

- = OFF
- = ON STEADY
- = FLASH

5 SYSTEM RESET

(written instructions on opposite page)