



INSTALLATION NOTE
 IF SUBBASE FUEL TANK AND/OR SOUND HOUSING IS USED, REFER TO SUBBASE FUEL TANK ADV TO DETERMINE MOUNTING LOCATIONS.

- NOTES:**
- 1) WHEN SUBBASE TANK IS USED, CONDUIT MUST BE LOCATED OUTSIDE OF TANK AREA OR IN STUB-UP AREA FOR SUBBASE TANK. REFER TO SUBBASE ADV.
 - 2) DIMENSIONS IN [] ARE ENGLISH EQUIVALENTS.
 - 3) IF AN ENCLOSURE IS USED, THE FUEL LINE MUST BE STUBBED UP FROM DIRECTLY UNDER THE UNIT OR BROUGHT IN FROM THE END OF THE SKID. REFER TO ENCLOSURE ADV.
 - 4) MAXIMUM WET WEIGHT OF GENSET: 1923 KD [4240 LBS]
 - 5) IF IBC CERTIFICATION IS REQUIRED SEE SEISMIC ADV FOR INSTALLATION INSTRUCTIONS.

■ 4X25.4 [1.0] STANDARD MOUNTING
 ◆ 6X22.2 [0.88] IBC MOUNTING

200 MODEL 4UAG, 4UAK3 RECONNECTABLE IMPROVED MOTOR STARTING (IMS) RECONNECTABLE AND 600V ALTERNATORS JOHN DEERE 6068HF TIER III

REV	DATE	BY	DESCRIPTION
0-0-11	NEW DRAWING (91637-3)		

APPROVAL	DATE	SCALE	DATE
DESIGNER	DATE	SCALE	DATE
CHECKER	DATE	SCALE	DATE
APPROVER	DATE	SCALE	DATE

KOWLER CO. UNIT PRICE	
POWER SYSTEMS, KOWLER, WI 53044 U.S.A.	
THIS DRAWING IN DESIGN AND DETAIL IS KOWLER CO. PROPERTY AND MUST NOT BE USED EXCEPT IN CONNECTION WITH KOWLER CO. WORK. ALL RIGHTS OF DESIGN OR INVENTION ARE RESERVED.	
DIMENSION PRINT, 200 MODEL	
DATE	SCALE
ADV-8185	D