2×4 bolted to wall studs w/ 1¼" lag screws

3/4" plywood top

Scale 1/2" = 1 Ft

2×4 (Qty 2)

spacer

2×4 (Qty 2) corner brace

spacer

2×4 fixed to wall stud

2×4

2×4

2×4

2×4 spacer

16" 16" 16"

2×4 base

57"

SW corner

Wall 1 S-N view

2×4 lags to stud

plywood top

NW corner

2×4 (Qty 3)

pocket door slider kit

2×4

2×4 spacer (Qty 2)

pocket door space

metal 2×4 hanger braces on both ends

2×4 attached to wall stud

2×4 spacer

split pocket door 2×4

2×4 base

76"

2×4 base

Wall 2 E-W view

3" screws used

3/4" plywood top

2×4 sill attached by lag screws

2×4 sill lag screw into wall

2×4 (Qty 2)

Scale 1/2" = 1 Ft

2×4 joists w/ metal brace hangers on both ends

2×4

2×4 corner brace (Qty 2)

2×4

2×4 attached to wall stud

2×4 spacers

2×4 base

16" 16" 16"

48"

SW corner

3/4" plywood top

NW corner

2×4 (Qty 2)

2×4 door frame opening

2×4 spacers

2×4 attached to wall stud

42"

Wall 1 S-N view

Wall 2 W-E view

Reviewed for Code Compliance
Permitting and Inspections Department
Approved with Conditions
08/17/2018