

1 WINDOW ELEVATIONS
1/2" = 1'-0"



5 WINDOW HEAD AT CLAPBOARD
3" = 1'-0"



LAP STRIP HEAD, JAMB AND SILL FLASHING. INSTALL IN ORDER OF NUMBERING

ORDER OF INSTALLATION OF WATER PROOFING AT WINDOWS. WATER PROOFINGAT STOREFRONT AND DOORS USE STEPS 1-3

NOTE: MOCK-UP FIRST WINDOW TO BE APPROVED BY MSHA, AND ARCHITECT PRIOR TO ANY INSTALLATION

NOTES:
1. INSTALL AIR INFILTRATION BARRIER IN ORDER AS SHOWN BY NUMBERS.
2. IF APPLICABLE, LEAVE RELEASE PAPER ON LOWER HALF OF SILL FLASHING UNTIL FUTURE TIE-IN.
3. INSTALL FLASHING AND AIR INFILTRATION BARRIER TO FORM WATER SHEDDING LAPS
4. COORDINATE WITH FLASHING REQUIREMENTS OF WINDOW MANUFACTURER
5. FOLLOW MANUFACTURES RECOMMENDATIONS FOR INSTALLATION.

2 ORDER OF INSTALLATION OF WATERPROOFING AT WINDOWS
3/8" = 1'-0"



4 WINDOW JAMB AT CLAPBOARD
3" = 1'-0"



3 WINDOW SILL AT CLAPBOARD
3" = 1'-0"

LICENSED ARCHITECT
DAVID LLOYD NO. 936
STATE OF MAINE
Date: 07/05/17

Reviewed for Code Compliance
Inspections Division
Portland, Maine

Prepared For:
Bramhall Row, LLC

Consultant:

Architect:
ARCHETYPE architects
48 Union Wharf Portland, Maine 04101
(207) 772-6022ARCHETYPE@ARCHETYPEPA.COM

Project:
BRAMHALL ROW
749 CONGRESS ST
PORTLAND, MAINE

Revisions:
1 Date 1 Revision 1

Scale: As indicated

Date: JUNE 28, 2017

WINDOW SCHEDULE

A8.02