Inspections Division
Date: 06/27/14

Rinnai®

Direct Vent Tankless Water Heater

Operation and Installation Manual

R50LSi **REU-VA2019FFUD**
R75LSi ..... **REU-VA2528FFUD(A)**
R94LSi **REU-VA2535FFUD**
R98LSi **REU-VA3237FFU**
R98LSi-ASME **REU-VA3237FFU-ASME**

FOR INDOOR APPLICATIONS ONLY

Table of Contents 2
Consumer Safety Information ... 4
Operating Instructions 5
Maintenance..... 12
Error Codes..... 13
Installation Instructions..... 17
Consumer Support 42

INSTALLER: Leave this manual with the appliance.
CONSUMER: Retain this manual for future reference.

WARNING: If the information in these instructions is not followed exactly, a fire or explosion may result causing property damage, personal injury or death.

— **Do not store or use gasoline or other flammable vapors and liquids in the vicinity of this or any other appliance.**

— **WHAT TO DO IF YOU SMELL GAS**

- **Do not try to light any appliance.**
- **Do not touch any electrical switch; do not use any phone in your building.**
- **Immediately call your gas supplier from a neighbor's phone. Follow the gas supplier's instructions.**
- **If you cannot reach your gas supplier, call the fire department.**

— **Installation and service must be performed by a qualified installer, service agency or the gas supplier.**

ANS Z21.10.3
•
CSA 4.3