CITY OF PORTLAND, MAINE
RESURGAM
Reviewed for Code Compliance
Inspections Division
Approved with Conditions
Date: 07/10/14

8. INSTALLING COVER AND COVER RAILS

A. Lay the cover on the ground next to the frame with inside of the cover (the side with the pipe pockets) facing down and the webbing on the front and rear of the corner of the building.

B. Pull cover over the frame, making sure to center cover on frame. There should be an equal amount of overhang at all four corners.

C. Insert the "S"- Hook on ratchet into hole on the leg bend. Insert the webbing into the spindle of the ratchet and pull tight. Wind the ratchet so that the webbing overlaps itself.

D. Disassemble cover rails and slide through fabric pockets at each leg and reattach with clamps to each leg. Repeat this on other side. Push down on cover rails to tighten cover, before tightening bolts completely.

E. Check and tighten Ratchets and Cover Rails monthly to ensure the cover is tight.

NOTE: *The **ShelterLogic®** logo should be oriented as shown below.*