CITY OF PORTLAND, MAINE
RESURGAM
Reviewed for Code Compliance
Inspections Division
Approved with Conditions
Date: 07/10/14

3. ASSEMBLE LEGS & ATTACH TO ROOF FRAME *Use bolts as shown in illustrations.*

A. Assemble Corner and Middle legs.
B. Attach legs with bolts on one side of roof frame, let the other side of roof frame rest on the ground.
C. Attach remaining legs with bolts to opposite side of roof frame.

4. ASSEMBLE COVER RAILS

A. Place the cover rail **(13344, 13345)** at each leg and secure it at each leg with a cover clamp as shown below.
B. Slide the cover rails so they are 8" up from the ground and ***hand tighten bolts on clamps.***