CITY OF PORTLAND, MAINE
RESURGAM
Reviewed for Code Compliance
Inspections Division
Approved with Conditions
Date: 09/22/14

Detail Ⓐ and Ⓑ

Backer Block
Before installing backer to double joist, drive an additional (3) 10d nails into web where backer will fit. Clinch when possible. Install backer tight to top flange. Use (10) 10d nails, clinched when possible.

BACKER BLOCKS*

JOIST SERIES	JOIST DEPTH	MATERIAL	DEPTH
EPI 90, WI 80	14"	1½" net	10¾"

*Block must be long enough to permit required nailing without splitting.