6 STOREFRONT TYPES
1/4" = 1'-0"

3 TYP. WINDOW HEAD SECTION
3" = 1'-0"

LAP STRIP HEAD, JAMB AND SILL FLASHING.
INSTALL IN ORDER OF NUMBERING

ORDER OF INSTALLATION OF
WATER PROOFING AT WINDOWS.
WATER PROOFING AT STOREFRONT AND
DOORS USE STEPS 1-3

NOTE: MOCK-UP FIRST WINDOW TO BE APPROVED BY MSHA, AND ARCHITECT PRIOR TO ANY INSTALLATION

NOTES:
1. INSTALL AIR INFILTRATION BARRIER IN ORDER AS SHOWN BY NUMBERS.
2. IF APPLICABLE, LEAVE RELEASE PAPER ON LOWER HALF OF SILL FLASHING UNTIL FUTURE TIE-IN.
3. INSTALL FLASHING AND AIR INFILTRATION BARRIER TO FORM WATER SHEDDING LAPS
4. COORDINATE WITH FLASHING REQUIREMENTS OF WINDOW MANUFACTURER
5. FOLLOW MANUFACTURES RECOMMENDATIONS FOR INSTALLATION.

5 ORDER OF INSTALLATION OF WATERPROOFING AT WINDOWS
3/8" = 1'-0"

4 TYPICAL WINDOW
1/4" = 1'-0"

2 TYP. WINDOW JAMB SECTION
3" = 1'-0"

1 TYP. WINDOW SILL SECTION
3" = 1'-0"

LICENSED ARCHITECT
DAVID LLOYD NO. 936
STATE OF MAINE
Date: 02/07/17

Prepared For:
NORTHLAND MANAGEMENT
Address
City, State

Consultant:

Architect:
ARCHETYPE architects
48 Union Wharf Portland, Maine 04101
(207) 772-6022 ARCHETYPE@ARCHETYPEPA.COM

Project:
CLARK INSURANCE
1945 CONGRESS ST
PORTLAND, ME 04102

Revisions:

Scale: As indicated

Date: 06 OCT 2016

WINDOW SCHEDULE

A8.02