LAP STRIP HEAD, JAMB AND SILL FLASHING.
INSTALL IN ORDER OF NUMBERING

ORDER OF INSTALLATION OF
WATER PROOFING AT WINDOWS.
WATER PROOFING AT STOREFRONT AND
DOORS USE STEPS 1-3

NOTES:
1. INSTALL AIR INFILTRATION BARRIER IN ORDER AS SHOWN BY NUMBERS.
2. IF APPLICABLE, LEAVE RELEASE PAPER ON LOWER HALF OF SILL FLASHING UNTIL FUTURE TIE-IN.
3. INSTALL FLASHING AND AIR INFILTRATION BARRIER TO FORM WATER SHEDDING LAPS
4. COORDINATE WITH FLASHING REQUIREMENTS OF WINDOW MANUFACTURER
5. FOLLOW MANUFACTURES RECOMMENDATIONS FOR INSTALLATION.

1 ORDER OF INSTALLATION OF WATERPROOFING AT WINDOWS
3/8" = 1'-0"

NOTE: ALL WINDOWS TO HAVE A U-FACTOR OF .35 OR LESS.

2 WINDOW ELEVATIONS
1/4" = 1'-0"

LICENSED ARCHITECT
DAVID LLOYD
NO. 936
STATE OF MAINE
Date: 05/08/17

Reviewed for Code Compliance
Inspections Division
Portland, Maine

Prepared For: Owner
Address
City, State

Consultant:

Architect: ARCHETYPE architects
48 Union Wharf Portland, Maine 04101
(207) 772-6022 ARCHETYPE@ARCHETYPEPA.COM

Project: MEDICAL OFFICES
1945 CONGRESS STREET, PORTLAND MAINE

Revisions:

Scale: As indicated

Date: DEC. 27, 2016

WINDOW SCHEDULE

A8.02