You will need to have both collar ties (w/in top 1/3) and rafter ties (w/in bottom 1/3) per R802.3.1, unless a structural ridge is added.

FRAMING DETAILS

1" = 1' 0"

Date: 09/09/16

Reviewed for Code Compliance
Inspections Division
Approved with Conditions

PORTLAND, MAINE CITY OF PORTLAND