


RADIANT HEAT CEILING PANEL



HUMIDIFIER PIPING AT DUCT




PIPING CONNECTIONS FOR STEAM HUMIDIFIER




NOTES: 1. WHERE STRUCTURAL SLAB DOES NOT PERMIT INSERTS, SUPPORT PIPING FROM STRUCTURE WITH AUXILIARY STEEL IF REQUIRED.





CLEVIS ROLLER HANGER WITH SADDLE



1. ARRANGE PIPING TO PERMIT COIL REMOVAL BY ONLY REMOVING UNIONS AT COILS.

2. UNIONS (OR FLANGED BODY) INDICATED TO PERMIT REMOVAL OF CONTROL VALVES.

3. PIPING FROM COIL OUTLET TO F&T TRAP TO BE THE SAME SIZE AS COIL OUTLET. DO NOT BUSH UNTIL TRAP.


4. FOR PIPE SIZE "A" SEE PLANS.

5. INSTALL VACUUM BREAKER AS PER COIL MANUFACTURER'S RECOMMENDATIONS.

6. INSTALL STRAINER WITH BASKET PARALLEL TO GROUND.

7. ADD STRUCTURAL STEEL TO RAISE THE BOTTOM OF THE COIL TO ACCOMMODATE DRIP AND TRAP HEIGHT.

STEAM COIL CONNECTIONS, OPEN GRAVITY SYSTEM -ONE HIGH FOR A STEAM FLOW RATE LESS THAN 1000 LBS/HR




1" & 1¼" 1" & 11/4" 1½" & 2" 1½" & 2" 2½" & 3" 2½" & 3" 4" & 5" 4" & 5" 6" & 8" 10" & 12" 14" & 16" 8"

LOW PRESSURE STEAM DRIP ASSEMBLY


1. PROVIDE THIS PIPING ARRANGEMENT WHERE IS SHOWN ON THE DRAWINGS, AND FOR THE SPECIFIED 75 FT STEAM SUPPLY DRIP REQUIREMENT.

2. 'B' DIMENSION FOR EQUIPMENT AND PRV DRIP ASSEMBLIES, PROVIDE PIPE AND TRAP SIZES AS PER THE MANUFACTURER'S RECOMMENDATIONS OR AS NOTED.

3. FOR DRIP ASSEMBLY AT EVERY 75 FT OF STEAM SUPPLY, THE 'B' DIMENSION SHALL BE 3/4".



TYPICAL DETAIL OF PIPE THRU RATED WALL



1. LOCATE PIPE UNIONS AND ARRANGE PIPING TO FACILITATE COIL REMOVAL.

2. FOR SIZES "A" SEE PLANS AND FLOW DIAGRAMS.

3. PROVIDE DIELECTRIC FITTINGS FOR DISSIMILAR METALS.

IN-DUCT HOT WATER REHEAT COIL CONNECTIONS ONE HIGH

11 SONAL ENGILLI

PROJECT ACCU RELOCATION 22 Bramhall Street Portland, Maine 04102

225 Franklin Street, Suite 1100

CONSULTANTS

AKF GROUP LLC

99 Bedford St., 2nd Floor

Boston, MA 02111

t 617.737.1111

f 617.737.4311

STRUCTURAL

41 Seyon St.

f 781.907.9009

SGH INC.

Waltham, MA 02453 t 781.907.9000

Boston, MA 02110 t 617.478.0300 f 617.478.0321 www.perkinswill.com



MAINE MEDICAL CENTER 22 Bramhall Street Portland, Maine 04102

> 06.24.2016 **ISSUE CHART**

ISSUED FOR PERMIT 06.24,2016 NO ISSUE DATE B160089-000 TITLE

> **MECHANICAL DETAILS**

SHEET NUMBER

M00-22

Copyright @ 2016 Perkins+Will