

**OA Centers for Orthopedics
33 Sewall Sreet
Portland, Maine**

[Click Here to Return to
Bill of Material/Index](#)

System Narrative

In the event of an alarm from an actuated device, the following shall

occur: (Devices reporting an alarm: Manual Station, Pre-Action System Activation)

- 1) Notify the Central Station via Digital Alarm Communicator (DACT).
- 2) Annunciate audibly,visually, and in plain english the active initiating device at the Fire Alarm Control Panel.
- 3) Activate the exerior Strobe/Beacon
- 4) Flash all strobe appliance circuits in a synchronized manner until silenced. If Silenced, the strobes shall resound upon receipt of a new alarm.
- 5) Sound a Temporal Code 3 on all horn units until silenced. If Silenced, the evacuation tone shall resound upon receipt of a new alarm.

In the event of a supervisory condition from an actuated device, the following shall occur: (Devices reporting a supervisory: Pre-Action System Fault)

- 1) Notify the Central Station via Digital Alarm Communicator (DACT).
- 2) Annunciate audibly,visually, and in plain english the active initiating device at the Fire Alarm Control Panel.

In the event of a system trouble report, the following shall occur:

- 1) Notify the Central Station via Digital Alarm Communicator (DACT).
- 2) Annunciate audibly,visually, and in plain english the active initiating device at the Fire Alarm Control Panel.